Bubbacare K12

Bubbacare Ultrasonic Anti-Barking Device User Manual

Model: K12

Introduction

Thank you for choosing the Bubbacare Ultrasonic Anti-Barking Device. This device is designed to help manage excessive dog barking by emitting a harmless ultrasonic sound. Please read this manual carefully before use to ensure proper operation and to achieve the best results.

Package Contents



Image: Contents of the Bubbacare Anti-Barking Device package. It includes the main device, a USB charging cable, a lanyard for portability, and this user manual.

- 1 x Bubbacare Ultrasonic Anti-Barking Device
- 1 x USB Charging Cable
- 1 x Lanyard
- 1 x User Manual

Product Features



Image: A child and a dog next to the device, highlighting its safety for both humans and pets, and its purpose to stop barking.

- **Ultrasonic Technology:** Emits a high-pitched ultrasonic sound, inaudible to most humans, to deter unwanted barking.
- **Automatic Activation:** The device automatically detects dog barking within its range and activates the ultrasonic sound.
- **Safe and Humane:** Designed to be harmless to dogs and humans, providing a gentle deterrent without painful stimulation.
- **Wide Compatibility:** Effective for dogs of all sizes and breeds.

- **Rechargeable Battery:** Built-in 1500mAh lithium-ion battery provides up to 30 days of continuous operation on a full charge.
- **Portable Design:** Lightweight and compact with an included lanyard for easy indoor and outdoor placement.
- **Durable Construction:** IPX4 waterproof rating ensures durability and suitability for various weather conditions.

Device Components




Image: A detailed diagram of the device, labeling its key parts: 1. On/Off button, 2. LED light, 3. Ultrasonic Speaker, 4. Microphone, 5. Non-slip Silicone feet, and 6. Charging interface.

1. **On/Off Button:** Powers the device on or off.
2. **LED Light:** Indicates device status (e.g., charging, active).
3. **Ultrasonic Speaker:** Emits the high-frequency sound.
4. **Microphone:** Detects dog barking.
5. **Non-slip Silicone:** Provides stability when placed on surfaces.
6. **Charging Interface:** USB port for recharging the device.

Setup

1. Charging the Device



Image: The device being charged via its USB port, showing compatibility with various USB power sources like chargers, power banks, and computer USB ports.

- Before first use, fully charge the device using the provided USB cable.
- Connect the USB cable to the charging interface (6) on the device and to a standard USB power source (e.g., wall adapter, computer, power bank).
- The LED light (2) will indicate the charging status. Refer to the LED indicator section for details.

- A full charge typically provides up to 30 days of operation.

2. Placement



Image: The device positioned outdoors, showing its effective range of up to 25 feet for capturing a dog's attention or disrupting barking.

- Place the device in an area where the dog's barking is a concern.

- Ensure there are no significant obstructions (like thick walls or solid barriers) between the device and the dog, as these can block the ultrasonic sound.
- The effective range for detecting barking and emitting sound is up to 25 feet (approximately 7.6 meters).
- For outdoor use, the IPX4 waterproof rating allows for placement in various weather conditions, but avoid submerging the device.
- You can place it on a flat surface using its non-slip silicone feet or hang it using the included lanyard.

Operating Instructions

- **Power On/Off:** Press the On/Off button (1) to activate or deactivate the device.
- **Automatic Operation:** Once powered on, the device's microphone (4) will listen for dog barking.
- **Sound Emission:** When barking is detected within range, the ultrasonic speaker (3) will emit a high-frequency sound. This sound is designed to be startling and unpleasant to dogs, encouraging them to stop barking.
- **Training Period:** Some dogs may require a training period of up to 2 weeks to fully adapt to the device and associate the sound with their barking. Consistency is key.
- **Selective Use:** This device is intended to deter unwanted, excessive barking. It can be turned off when barking is acceptable (e.g., during play or when alerting to a visitor).

Important Considerations




Image: The device shown with a variety of dog breeds, indicating its broad applicability, alongside a note that it is ineffective for deaf or hearing-impaired dogs.

- **Hearing Impairment:** The device will not work on deaf or hearing-impaired dogs.
- **Individual Dog Reactions:** Different dog breeds and individual dogs may react differently to the ultrasonic sound. Some dogs may be more sensitive than others.
- **Obstructions:** Walls, fences, and other solid barriers can significantly reduce the effectiveness of the ultrasonic sound. Ensure a clear line of sight between the device and the dog whenever possible.

- **Aggressive Behavior:** This device is not intended to provide protection against aggressive dogs. It is a barking deterrent, not a safety device for aggressive encounters.
- **Children:** Keep the device out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
Device does not seem to work.	• Device is off. • Battery is low or depleted. • Obstructions blocking the sound. • Dog is deaf or hearing-impaired.	• Ensure the device is powered on. • Charge the device fully. • Relocate the device to an area with a clear line of sight to the dog. • Confirm the dog's hearing ability.
Dog continues to bark after activation.	• Dog needs more training time. • Device is too far from the dog. • Dog is not sensitive to ultrasonic sound.	• Allow up to 2 weeks for the dog to adjust. • Ensure the device is within 25 feet of the dog. • Consider alternative training methods if the dog shows no response after the training period.
LED indicator not working.	• Device is off or battery is completely drained. • Faulty unit.	• Turn on the device and charge it. • Contact customer support if the issue persists after charging.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge when the low battery indicator appears.

Specifications

Model:	K12
Brand:	Bubbacare
Dimensions (L x W x H):	3.54 x 2.83 x 3.34 inches (9 x 7.2 x 8.5 cm)
Weight:	5.3 ounces (150 grams)
Battery:	Built-in 1500mAh Lithium-ion
Operating Time:	Up to 30 days (fully charged)
Effective Range:	Up to 25 feet (7.6 meters)

Waterproof Rating:	IPX4
Color:	White

Warranty and Support

Bubbacare offers a lifetime warranty for this product. If you are not satisfied with your purchase for any reason, you may return it for a full refund. For further assistance or inquiries, please contact Bubbacare customer support through your purchase platform.

© 2023 Bubbacare. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question