

Merax HA497

Merax Full Over Full Metal Bunk Bed HA497 Instruction Manual

Model: HA497

INTRODUCTION

This manual provides detailed instructions for the safe assembly, operation, and maintenance of your Merax Full Over Full Metal Bunk Bed. Please read all instructions carefully before assembly and use. Retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the recommended mattress size and thickness to prevent falls. For the upper bunk, the mattress should not exceed 6 inches in thickness. For the lower bunk, the mattress should not exceed 8 inches in thickness.
- Ensure all connections are tight before use. Periodically check and tighten all bolts and fasteners.
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit more than one person on the upper bunk.
- Always use the ladder for entering and exiting the upper bunk. Do not use substitute parts. Contact Merax for replacement parts.
- The upper bunk is designed to support a maximum weight of 250 lbs. The lower bunk is designed to support a maximum weight of 350 lbs.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, or jump ropes.
- Keep these instructions for future reference.

ASSEMBLY INSTRUCTIONS

Assembly of the Merax Full Over Full Metal Bunk Bed typically requires two adults and takes approximately 0.5 hours. All necessary tools and hardware are included.

Before You Begin:

- Clear a spacious area for assembly.
- Unpack all components and verify against the parts list (not provided in this manual, refer to your product packaging).
- Ensure all hardware is present.

Step-by-Step Assembly:

1. **Assemble the Headboards and Footboards:** Attach the vertical support bars to the headboard and footboard panels using the provided bolts and washers. Do not fully tighten bolts until all sections are aligned.
2. **Connect Side Rails:** Attach the side rails to the assembled headboards and footboards for both the upper and lower bunks. Ensure the rails are correctly oriented.
3. **Install Slat Supports:** Place the metal slats onto the designated supports on the side rails. Secure each slat with the provided fasteners.
4. **Attach Ladder:** Securely attach the ladder to the designated side of the bunk bed frame. Ensure it is firmly connected and stable.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and fasteners using the included tools.
6. **Safety Check:** Verify that the bed is stable and all guardrails are securely in place.

SIZE:INCH




Image: Detailed dimensions of the Merax Full Over Full Metal Bunk Bed. The overall length is 77.1 inches, width is 55.9 inches, and height is 53.7 inches. The distance between the lower and upper bunk is 38.7 inches. The ladder steps are 9.8 inches apart.

OPERATING INSTRUCTIONS

Using your Merax Full Over Full Metal Bunk Bed safely and effectively.

- **Mattress Placement:** Place the appropriate size mattress on each bunk. Ensure the mattress on the upper bunk does not exceed the maximum recommended thickness of 6 inches to maintain guardrail effectiveness.
- **Ladder Use:** Always use the integrated ladder to access and exit the upper bunk. Ensure a clear path to the ladder.
- **Weight Limits:** Adhere strictly to the weight limits: 250 lbs for the upper bunk and 350 lbs for the lower bunk.
- **General Use:** Avoid rough play on or around the bunk bed. Do not jump on the bed.



Image: A fully assembled Merax Full Over Full Metal Bunk Bed in white, shown with mattresses and bedding in a room setting. This illustrates the bed in its intended use.

Maintenance and Care

Proper care will extend the life and maintain the safety of your bunk bed.

- **Cleaning:** Wipe the metal frame with a damp cloth to remove dust and dirt. Follow with a dry cloth to prevent water spots. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Checks:** Periodically (e.g., monthly or quarterly) inspect all bolts, screws, and fasteners to ensure they are tight. Re-tighten as necessary to maintain structural integrity and prevent wobbling.
- **Structural Integrity:** Regularly check for any signs of damage, bending, or stress on the metal frame. If any damage is found, discontinue use and contact customer support.

Troubleshooting

Common issues and their solutions for your Merax bunk bed.

Problem	Possible Cause	Solution
Bed is wobbly or unstable.	Loose bolts or fasteners.	Inspect all connections and tighten any loose bolts or screws. Ensure the bed is on a level surface.
Squeaking noises during use.	Loose connections or friction between metal parts.	Tighten all bolts. Apply a small amount of lubricant (e.g., silicone spray) to connection points if squeaking persists.
Missing parts during assembly.	Packaging error or lost during unpacking.	Carefully check all packaging materials. Contact Merax customer support with your model number and a description of the missing parts.

Product Specifications

Feature	Detail
Model Number	HA497
Size	Full over Full
Material	Metal
Color	White
Overall Product Dimensions (L x W x H)	77.1" x 55.9" x 53.7"
Upper Bed Weight Capability	250 lbs
Lower Bed Weight Capability	350 lbs
Recommended Upper Mattress Thickness	6 inches
Recommended Lower Mattress Thickness	8 inches
Assembly Time	Approximately 0.5 hours (Partial assembly)
Tools Required	All tools included

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need replacement parts, please contact Merax customer support. Have your model number (HA497) ready when contacting support.
For further assistance, please visit the official Merax store:[Merax Store on Amazon](#)

© 2023 Merax. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question