Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BrilliantHouse GTS2

BrilliantHouse GTS2 Fitness Tracker Replacement Wristbands User Manual

1. Introduction

This manual provides essential information for the installation, usage, and maintenance of your BrilliantHouse GTS2 Fitness Tracker Replacement Wristbands. Please read these instructions carefully to ensure proper use and longevity of your product.

1.1 Product Overview

The BrilliantHouse GTS2 Replacement Wristbands are designed to offer a comfortable and durable alternative for your GTS2 fitness tracker. Made from high-quality silicone with a stainless steel buckle, these bands are suitable for various activities and daily wear.

1.2 Compatibility

These replacement wristbands are specifically designed for the**GTS2 Fitness Tracker**. They are compatible with GTS2 models from BrilliantHouse and other brands. It is crucial to verify that your fitness tracker's model number is indeed GTS2 before proceeding with installation or purchase.



Image 1.1: This image illustrates how to verify your fitness tracker's model number on a smartphone application, confirming it is a GTS2 model for band compatibility.

2. Installation Guide

The replacement wristbands feature a simple quick-release mechanism, allowing for tool-free installation and removal.

2.1 Band Disassembly

1. Locate the spring bar pin on the underside of your current wristband where it connects to the fitness tracker.
2. Gently pull the spring bar pin inwards (towards the center of the band) to release it from the tracker's lug.
3. Carefully pull the band away from the fitness tracker. Repeat for the other side.

2.2 Band Assembly

1. Align one end of the new replacement band with the corresponding lug on the fitness tracker.
2. Insert one side of the spring bar pin into the lug hole.
3. While holding that side in place, pull the spring bar pin inwards and guide the other side into the opposite lug hole. Release the pin to secure the band.
4. Gently tug on the band to ensure it is securely attached before wearing. Repeat for the second band piece.




Image 2.1: This image demonstrates the simple disassembly process. Gently pull the spring bar pin (1) to detach the band, then pull the band away (2) from the tracker.

3. Features and Usage

3.1 Comfort and Durability

The wristbands are crafted from a soft, lightweight, and durable silicone material. This material is waterproof and sweat-proof, making it ideal for sports, swimming, and outdoor activities. It is also chemical-free, colorfast, tasteless, and harmless to the human body, ensuring comfort during extended wear.



Image 3.1: The image showcases the key features of the wristband: its waterproof nature, the durable stainless steel buckle, and the soft, flexible silicone material designed for comfort.

3.2 Adjustable Fit

Each strap is designed with multiple adjustment holes and a robust stainless steel buckle, allowing for a customizable and secure fit. The bands are suitable for wrists measuring between 4.7 inches and 7.9 inches in circumference.



Image 3.2: This diagram illustrates the adjustable nature of the strap, suitable for wrist sizes ranging from 4.7 inches to 7.9 inches, ensuring a comfortable fit for various users.

3.3 Color Options

The replacement wristbands are available in a selection of popular colors, including black, blue, grey, and pink. These options allow you to personalize your fitness tracker to match your style or outfit.




Image 3.3: This image displays the available color options for the GTS2 replacement wristbands: classic black, blue, grey, and pink, allowing for personalization.

4. Care and Maintenance

To maintain the quality and appearance of your BrilliantHouse GTS2 replacement wristbands, follow these simple care instructions:

- **Cleaning:** Wipe the bands regularly with a soft, damp cloth to remove sweat, dirt, and oils. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely before reattaching to your tracker.
- **Avoid Harsh Chemicals:** Do not expose the bands to strong chemicals, solvents, or abrasive cleaners, as these can damage the silicone material and affect its color.
- **Storage:** Store the bands in a cool, dry place away from direct sunlight when not in use to prevent material degradation.

5. Troubleshooting

5.1 Compatibility Check

If the bands do not fit your fitness tracker, please re-verify that your device is specifically a GTS2 model. These bands are

designed exclusively for the GTS2 and may not fit other models, even if they appear similar. Refer to Section 1.2 for guidance on checking compatibility.

5.2 Installation Difficulty

If you encounter difficulty installing the bands, ensure the spring bar pins are fully retracted when inserting them into the tracker's lugs. Make sure the band is aligned correctly with the lug holes. Do not force the band into place, as this may cause damage to the band or the tracker.

6. Product Specifications

Product Name	GTS2 Fitness Tracker Replacement Wristbands
Brand	BrilliantHouse
Material	Soft Silicone, Stainless Steel Buckle
Compatibility	GTS2 Fitness Tracker (All Brands)
Adjustable Wrist Size	4.7 - 7.9 inches
Features	Waterproof, Sweat-proof, Durable, Chemical-free, Colorfast

7. Warranty Information

BrilliantHouse products are manufactured with quality in mind. For specific warranty details regarding your replacement wristbands, please refer to the product packaging or contact customer support. Generally, manufacturing defects are covered for a limited period from the date of purchase.

8. Customer Support

If you have any questions, concerns, or require assistance with your BrilliantHouse GTS2 Fitness Tracker Replacement Wristbands, please contact our customer support team. You can typically find contact information on the product packaging or through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVG4LVP5

More documents and user manuals: **https://manuals.plus/**