

## JBL JBLBAR700PROBLKAM

# JBL Bar 700 User Manual

5.1-Channel Soundbar with Detachable Surround Speakers and Dolby Atmos®

Model: JBLBAR700PROBLKAM

## INTRODUCTION

The JBL Bar 700 is a high-performance 5.1-channel soundbar system designed to elevate your home entertainment experience. Featuring detachable battery-powered surround speakers and Dolby Atmos® technology, it delivers immersive 3D audio. With 620W of total output power and a powerful 10-inch wireless subwoofer, this system provides thrilling bass and clear dialogue through PureVoice technology. It also supports various streaming options including AirPlay, Alexa MRM, and Chromecast built-in™.

Key features include:

- **Dolby Atmos Surround Sound:** Immerse yourself in theater-quality 3D sound with detachable surround speakers.
- **Real Surround Sound:** Enjoy true surround sound without extra wires, thanks to battery-powered detachable rear speakers.
- **Built-In Wi-Fi:** Access over 300 online music streaming services via AirPlay, Alexa MRM, and Chromecast built-in™. Automatic software updates ensure the latest features.
- **620W Output Power:** Transforms movies, music, and games into immersive sound experiences.
- **10" Wireless Subwoofer:** Delivers thrilling, precise bass for action movies and music.

## WHAT'S IN THE BOX

Your JBL Bar 700 package includes the following components:

- JBL Bar 700 Soundbar
- Two (2) Detachable Wireless Surround Speakers
- One (1) Wireless Subwoofer
- One (1) Remote Control
- Power cables (region specific)
- HDMI cable

- Wall-mount bracket kit with screws
- Quick start guide
- Safety sheet
- Warranty card



Image: All components of the JBL Bar 700 system, including the soundbar, detachable speakers, subwoofer, and remote.

## SETUP

---

### 1. Placement

For optimal sound performance, place the soundbar centrally below your TV. The wireless subwoofer can be placed anywhere in the room, ideally near a power outlet. The detachable surround speakers should be placed behind your listening position for the best surround sound experience. Ensure clear line of sight between the soundbar and subwoofer for stable wireless connection.




Image: Recommended placement of the soundbar and subwoofer in a typical living room environment.



Image: Detachable surround speakers positioned behind the listening area for immersive audio.

## 2. Connections

Connect the soundbar to your TV using the provided HDMI cable. For the best audio quality, use the HDMI ARC/eARC port on your TV. This allows audio from your TV to be sent back to the soundbar. You can also connect other devices (e.g., Blu-ray player, game console) to the soundbar's HDMI input ports.

- **HDMI ARC/eARC:** Connect the HDMI OUT (TV ARC/eARC) port on the soundbar to the HDMI ARC/eARC port on your TV.
- **Optical:** For TVs without HDMI ARC, use an optical cable to connect the soundbar's OPTICAL port to your TV's optical output.
- **Power:** Connect the power cables to the soundbar, subwoofer, and then to a power outlet.



Image: Rear panel of the soundbar displaying connectivity options.

### 3. Initial Power On & Pairing

Once all connections are made, power on the soundbar. The subwoofer and detachable surround speakers should automatically pair with the soundbar. If pairing does not occur automatically, refer to the troubleshooting section for manual pairing instructions.

Ensure the detachable speakers are fully charged by attaching them to the main soundbar or by connecting them via USB-C cables (not included) for continuous power.

## OPERATING

---

### 1. Basic Controls

The soundbar can be controlled using the included remote control or the buttons on the top panel of the soundbar. The display on the front of the soundbar provides visual feedback on the current input, volume level, and other settings.



Image: Front display of the soundbar indicating the active input source.

- **Power Button:** Turns the soundbar on or off.
- **Source Button:** Cycles through input sources (HDMI, Optical, Bluetooth, Wi-Fi).
- **Volume Buttons (+/-):** Adjusts the master volume.
- **Mute Button:** Mutes or unmutes the sound.
- **Bass Button:** Adjusts subwoofer level.
- **Rear Speaker Level:** Adjusts the volume of the detachable surround speakers (Low, Medium, High).

### 2. Audio Calibration (PureVoice)

The JBL Bar 700 features PureVoice technology to enhance dialogue clarity. For optimal performance, perform the audio calibration as instructed in the quick start guide. This process adjusts the sound output to your room's acoustics and speaker placement.

### 3. Wireless Streaming

The soundbar supports various wireless streaming options:

- **Bluetooth:** Pair your mobile device via Bluetooth to stream audio wirelessly.
- **Wi-Fi (AirPlay, Alexa MRM, Chromecast built-in™):** Connect the soundbar to your home Wi-Fi network to access a wide range of online music streaming services and smart home integrations. Use the JBL One app for setup and

control.



Image: Demonstrates music streaming capabilities via various wireless technologies.

## MAINTENANCE

To ensure the longevity and optimal performance of your JBL Bar 700 system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and speakers. Avoid using liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the ventilation openings on the soundbar and subwoofer are not blocked. Do not place the units on soft surfaces that may impede airflow.
- **Battery Care (Detachable Speakers):** Regularly charge the detachable speakers. If not used for extended periods, charge them at least once every three months to maintain battery health.
- **Storage:** If storing the system for a long time, disconnect it from power and store it in a cool, dry place.

## TROUBLESHOOTING

If you encounter issues with your JBL Bar 700, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Sound from Soundbar	<ul style="list-style-type: none"><li>◦ Ensure power cables are securely connected.</li><li>◦ Verify correct input source is selected on the soundbar (e.g., HDMI, Optical).</li><li>◦ Check TV audio output settings (e.g., set to External Speakers, PCM).</li><li>◦ Ensure volume is not muted or set too low.</li></ul>

Problem	Possible Cause / Solution
<b>Subwoofer Not Pairing</b>	<ul style="list-style-type: none"> <li>◦ Ensure both soundbar and subwoofer are powered on.</li> <li>◦ Press and hold the pairing button on the subwoofer (usually on the back) until the indicator light flashes.</li> <li>◦ On the soundbar, press and hold the 'Bass' button for 5 seconds. The soundbar display should show 'PAIRING'.</li> <li>◦ Once connected, the indicator light on the subwoofer will turn solid.</li> </ul>
<b>Detachable Speakers Not Pairing / Low Battery</b>	<ul style="list-style-type: none"> <li>◦ Reattach the speakers to the main soundbar to recharge and re-establish connection.</li> <li>◦ Ensure speakers are fully charged (Battery Life: 10 Hours).</li> <li>◦ If issues persist, try a factory reset (refer to quick start guide for specific steps).</li> </ul>
<b>Bluetooth Connectivity Issues</b>	<ul style="list-style-type: none"> <li>◦ Ensure Bluetooth is enabled on your device and the soundbar is in Bluetooth pairing mode.</li> <li>◦ Move your device closer to the soundbar (Bluetooth Range: 10 Meters).</li> <li>◦ Clear the Bluetooth pairing list on your device and the soundbar, then try pairing again.</li> </ul>
<b>Wi-Fi / Streaming Problems</b>	<ul style="list-style-type: none"> <li>◦ Ensure your home Wi-Fi network is active and stable.</li> <li>◦ Check if the soundbar is connected to the correct Wi-Fi network via the JBL One app.</li> <li>◦ Restart your router, soundbar, and streaming device.</li> </ul>

## SPECIFICATIONS

Detailed technical specifications for the JBL Bar 700:

Feature	Detail
Model Name	JBL Bar 700
Speaker Type	Soundbar
Surround Sound Channel Configuration	5.1
Speaker Maximum Output Power	620 Watts
Subwoofer Diameter	10 Inches

Feature	Detail
Battery Life (Detachable Speakers)	10 Hours
Product Dimensions (Soundbar)	4.7"D x 46.2"W x 2.2"H
Item Weight	39.5 pounds (total system)
Connectivity Technology	Wi-Fi, Bluetooth, HDMI, Optical
Bluetooth Range	10 Meters
Audio Output Mode	Surround
Special Features	Bass Boost, Subwoofer, Stereo Pairing, Dolby Enabled, Detachable Speakers
Manufacturer	JBL
Item Model Number	JBLBAR700PROBLKAM
UPC	050036397049

## WARRANTY AND SUPPORT

The JBL Bar 700 comes with a limited warranty from the manufacturer. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, product registration, or further assistance, please visit the official JBL support website or contact their customer service. Keep your proof of purchase for warranty claims.

- **Online Support:** [Visit JBL Support](#)
- **Protection Plans:** Additional protection plans may be available for purchase to extend coverage beyond the standard manufacturer's warranty. Check with your retailer for options like 2-Year or 3-Year Protection Plans.