

CAT CAT-BTEARBUD

CAT Bluetooth Noise Canceling Ear Buds User Manual

Model: CAT-BTEARBUD

Brand: CAT

INTRODUCTION

This manual provides essential information for the safe and effective use of your CAT Bluetooth Noise Canceling Ear Buds. These rugged wireless earbuds are designed for demanding environments, offering dust-proof, shock-proof, and water-resistant features, compatible with both Apple and Android devices.

The advanced noise-canceling technology minimizes background noise from machinery, vehicles, and busy job sites, providing an immersive audio experience. Built to withstand tough work environments, these earbuds resist daily wear and tear, ensuring durable impact protection.



Image: CAT Bluetooth Noise Canceling Ear Buds and their rugged charging case, depicted with water splashing, highlighting their water-resistant feature.

WHAT'S IN THE BOX

Upon opening your CAT Bluetooth Noise Canceling Ear Buds package, you should find the following components:

- CAT Bluetooth Noise Canceling Ear Buds (Left and Right)
- Rugged Charging Case
- USB-C Charging Cable
- Carabiner Clip
- Extra Ear Gels (various sizes for optimal fit)
- User Manual (this document)



INCLUDES:

- ✓ CARABINER
- ✓ USB-C CHARGING CABLE
- ✓ EXTRA EAR GELS
- ✓ CHARGING CASE

Image: A visual representation of the package contents, showing the CAT Bluetooth Earbuds, their charging case, a USB-C charging cable, a carabiner, and extra ear gels.

SETUP

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case has a built-in 400mAh battery, and each earbud has a 40mAh battery.

1. Connect the provided USB-C charging cable to the charging port on the case.
2. Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED indicators on the charging case will illuminate to show charging status. A full charge for the case takes approximately 5 hours.
4. Place the earbuds into the charging case. They will begin charging automatically. The case can recharge the earbuds up to 8 times on a single full charge.

BATTERY CAPACITY



**EARBUD BATTERY:
BUILT IN 40MAH**

**CHARGING CASE BATTERY:
BUILT IN 400MAH**

Image: The CAT Earbuds charging case open with earbuds inside, illustrating the battery capacity of both the earbuds (40mAh) and the charging case (400mAh).

Pairing with a Device

The earbuds utilize Bluetooth 5.0 for a stable connection with an operating range of up to 39 feet.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Look for "CAT-BTEARBUD" or a similar name in the list of available devices and select it to pair.
5. Once paired, the earbuds will connect automatically to your device when taken out of the case and Bluetooth is enabled on your device.

OPERATING INSTRUCTIONS

Touch Controls

The CAT Bluetooth Ear Buds feature easy-to-use touch controls for managing music and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Control:** Adjust directly from your connected device.

Noise Canceling Functionality

These earbuds are equipped with active noise-canceling technology to reduce ambient sounds, ideal for noisy environments. The noise canceling feature is designed to minimize background noise from machinery, vehicles, and busy job sites.



Image: A graphic illustrating two CAT earbuds with sound wave patterns, emphasizing their advanced noise-canceling capabilities.

Battery Life

Enjoy up to 5 hours of playback time on a single charge. The rugged charging case provides additional charges, extending total listening time significantly.



Image: A woman using CAT earbuds, with overlaid text detailing key features such as "Up to 5 Hours of Playtime on a Single Charge," "Advanced Noise Cancelling," "Easy to Use Touch Controls," and "Recharge Up to 8 Times with Charging Case."

MAINTENANCE

To ensure the longevity and optimal performance of your CAT Bluetooth Noise Canceling Ear Buds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. For ear gels, remove them and clean with mild soap and water, then dry thoroughly before reattaching.
- **Water and Dust Resistance:** The earbuds are water-resistant and dust-proof (IP55 rated). While they can withstand sweat, rain, and dust, they are not designed for submersion in water. Ensure the charging port is dry before charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust, dirt, and physical damage.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and overall performance.



Image: A visual representation of the CAT earbuds' durability features, including icons for Water Resistant (IP55), Dust Resistant, and Shock Proof.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Earbuds not in pairing mode, out of range, or low battery.	Ensure earbuds are charged and case is open. Move closer to the device. Turn Bluetooth off and on again on your device. Forget the device in Bluetooth settings and re-pair.
No sound or low volume.	Volume too low on device, earbuds not properly seated, or connection issue.	Increase volume on your device. Ensure earbuds are correctly placed in your ears. Reconnect the earbuds.

Problem	Possible Cause	Solution
Earbuds not charging.	Charging cable or port issue, or earbuds not properly seated in case.	Check USB-C cable connection. Ensure earbuds are correctly placed in the charging case. Try a different charging cable or power source.
Noise canceling not effective.	Improper fit, or type of noise not fully attenuated.	Try different sized ear gels for a better seal. Active noise canceling is most effective against consistent low-frequency sounds.

SPECIFICATIONS

Model Name:	Cat Bluetooth Noise Canceling Earbuds
Model Number:	CAT-BTEARBUD
Connectivity Technology:	Bluetooth 5.0
Bluetooth Range:	Up to 39 Feet
Noise Control:	Active Noise Cancellation
Earbud Battery Life:	5 Hours (single charge)
Charging Case Battery:	400mAh (recharges earbuds up to 8 times)
Charging Time (Case):	5 Hours
Water Resistance Level:	Water Resistant (IP55)
Dust Proof:	Yes
Shock Proof:	Yes
Control Method:	Touch
Color:	Black and Cat Yellow
Item Weight:	2.08 ounces
Product Dimensions:	1.51 x 0.39 x 0.39 inches
UPC:	767322199125

OFFICIAL PRODUCT VIDEO

Watch the official product video for a visual guide on the features and usage of your CAT Bluetooth Noise Canceling Ear Buds.

Your browser does not support the video tag.

Video: An official product video showcasing the CAT Bluetooth Noise Canceling Ear Buds, demonstrating their features and design.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your CAT Bluetooth Noise Canceling Ear Buds, please refer to the contact information provided on the product packaging or visit the official CAT mobile accessories website.

Keep your proof of purchase for warranty claims.