

Manuals.plus /

› Acekool /

› Acekool Nugget Ice Maker IB01 Instruction Manual

Acekool IB01

Acekool Nugget Ice Maker Instruction Manual

Model: IB01

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Acekool Nugget Ice Maker. Retain this manual for future reference.

- Ensure the appliance is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the power outlet before cleaning or when not in use.
- Keep children away from the ice maker during operation.
- Use only potable water in the water reservoir.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is for household use only.

PRODUCT OVERVIEW

The Acekool Nugget Ice Maker (Model IB01) produces soft, chewable nugget ice, ideal for various beverages. It features a 3-quart water reservoir, self-cleaning function, and can produce up to 30 lbs of ice per day.



Image: The Acekool Nugget Ice Maker, Model IB01, in a kitchen setting, showcasing its compact design and stainless steel finish.

Key Features:

- **Chewable Nugget Ice:** Produces soft, compacted ice flakes.
- **Fast Ice Making:** First batch in 15-18 minutes, up to 30 lbs per day.
- **Dual Water Refill Options:** Automatic connection to home water system or manual 3Qt reservoir filling.
- **Self-Cleaning Feature:** Easy maintenance with a dedicated cleaning cycle.

SETUP

1. Unpacking and Placement

1. Remove all packaging materials and inspect the ice maker for any damage.
2. Place the ice maker on a flat, stable, and heat-resistant surface. Ensure there is at least 5 inches of space around the unit for proper ventilation.
3. Allow the unit to stand upright for at least 2 hours before plugging it in, especially if it was transported horizontally. This allows the refrigerant to settle.



Image: The Acekool Nugget Ice Maker with dimensions labeled, illustrating its portable size and water reservoir capacity.

2. Initial Cleaning

Before first use, it is recommended to clean the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions, or use the self-cleaning function.

3. Water Refill Options

The ice maker offers two methods for water supply:

- **Manual Fill:** Open the top lid and pour potable water directly into the 3-quart water reservoir. Do not exceed the MAX fill line.
- **Automatic Fill:** Connect the ice maker to your home water system using the provided hose (if applicable). Ensure all connections are secure to prevent leaks.

Countertop Nugget Ice Maker IB01

Let you enjoy restaurant-quality ice



Image: The Acekool Nugget Ice Maker producing ice, with an indication of 44 lbs output per day and ice ready in 10-15 minutes.

OPERATING INSTRUCTIONS

1. Starting Ice Production

1. Ensure the water reservoir is filled.
2. Plug the ice maker into a grounded electrical outlet.
3. Press the **"ICE/CLEAN"** button once to start the ice making cycle. The indicator light will illuminate.
4. The first batch of ice will be ready in approximately 15-18 minutes.



Image: A three-step visual guide showing how to add water, press the "ICE" button, and enjoy ice in 10-15 minutes.

2. Using the Timer Function

The timer function allows you to schedule when the ice maker starts or stops.

1. Press the **"TIMER"** button.
2. Use the **"UP"** and **"DOWN"** arrows to set the desired delay time (in hours) before the ice making starts or stops.
3. Confirm the setting by pressing the **"TIMER"** button again or waiting a few seconds.



Image: The Acekool Nugget Ice Maker in a kitchen, illustrating the timer function to schedule ice making.

3. Indicator Lights

- **Water Shortage Indicator:** Illuminates when the water reservoir needs refilling. The ice maker will pause operation until water is added.
- **Ice Full Indicator:** Illuminates when the ice basket is full. The ice maker will pause operation until ice is removed.



Image: The Acekool Nugget Ice Maker control panel, highlighting the Water Shortage and Ice Full indicators.

MAINTENANCE

1. Self-Cleaning Function

The ice maker is equipped with a self-cleaning cycle to simplify maintenance.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **"ICE/CLEAN"** button for 3 seconds. The cleaning cycle will begin.
3. The cleaning process will circulate water through the system. Once complete, drain the water from the unit.



Image: The Acekool Nugget Ice Maker demonstrating its auto self-cleaning function, showing water circulation and the drain hole at the bottom.

2. Regular Cleaning and Draining

- Regularly wipe the exterior of the ice maker with a soft, damp cloth.
- For thorough cleaning, unplug the unit and drain all water from the reservoir using the drain plug located at the bottom.
- Clean the interior components, including the ice basket and water tray, with a mild detergent and rinse thoroughly.
- Ensure all parts are dry before reassembling and operating the ice maker.

TROUBLESHOOTING

If you encounter issues with your Acekool Nugget Ice Maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	<ul style="list-style-type: none"> No water in reservoir. Power supply issue. Ambient temperature too high. 	<ul style="list-style-type: none"> Fill water reservoir. Check power connection and outlet. Ensure unit is in a cool, well-ventilated area.
Ice production is slow.	<ul style="list-style-type: none"> High room temperature. Poor ventilation. Water temperature too high. 	<ul style="list-style-type: none"> Move to a cooler location. Ensure adequate space around the unit. Use cold water for faster ice production.
"Water Shortage" indicator is on.	Water reservoir is empty or water level is too low.	Refill the water reservoir with potable water.
"Ice Full" indicator is on.	Ice basket is full.	Remove ice from the basket.
Loud noise during operation.	<ul style="list-style-type: none"> Unit not level. Internal components vibrating. 	<ul style="list-style-type: none"> Ensure the unit is on a stable, level surface. If noise persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Acekool
Model Name	Nugget Ice Maker (IB01)
Product Dimensions (D x W x H)	9.4"D x 13.1"W x 15.3"H
Ice Production Capacity	Up to 30 lbs per day
Water Reservoir Capacity	3 Quarts (approx. 2.8 Liters)
Voltage	115V
Refrigerant	R410a
Included Components	Nugget Ice Maker

WARRANTY & SUPPORT

Acekool provides the following support for your Nugget Ice Maker:

- **30 Days Unreasonable Return:** For returns within 30 days of purchase.
- **12 Months Free Maintenance:** Covers maintenance for 12 months from the date of purchase.
- **Parts Replacement:** Availability of replacement parts.
- **Technology Support:** Your questions will be responded to within 24 hours.

For further assistance or to claim warranty services, please contact Acekool customer support through the retailer where the product was purchased or visit the official Acekool website.

