

Septpenta Septpentar26iknx7sw

Septpenta 5KG Mini Portable Foldable Turbo Washing Machine User Manual

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, setup, and maintenance of your Septpenta 5KG Mini Portable Foldable Turbo Washing Machine. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INSTRUCTIONS

WARNING: Please read the product instructions carefully before use to ensure correct operation and to prevent injury or damage.

- Ensure the washing machine is placed on a stable, flat surface during operation.
- Do not immerse the USB power plug or the main unit (excluding the washing bucket) in water.
- Keep out of reach of children. Adult supervision is required when children are near the appliance.
- Use only the provided USB power cable.
- Do not overload the machine beyond its 5KG capacity (including water).
- Unplug the power cable before cleaning or when not in use.
- Avoid washing delicate items that require special care or dry cleaning.



Image: A warning symbol with text in several languages, including English, stating: "Please read the product instructions carefully before use to ensure correct use."

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Folding Washing Machine Unit (with integrated turbo pulsator)
- 1 x Folding Bucket
- 1 x USB Power Cable
- 1 x Suction Cup (for securing the pulsator)
- 1 x User Manual (this document)



Image: The complete set of components, including the blue and white foldable bucket, the white turbo pulsator with its attached USB power cable, and a clear suction cup accessory.

4. PRODUCT OVERVIEW

The Septpenta Mini Portable Foldable Turbo Washing Machine is designed for washing small, lightweight items such as baby clothes, socks, underwear, and bras. Its foldable design makes it ideal for travel and small living spaces.

MINI PORTABLE
BUSINESS TRIP
Small size
Suitable for students



Image: The folded washing machine neatly packed inside a suitcase, demonstrating its portability for business trips or student use.

SAY GOODBYE TO HAND WASHING AND MIXED WASHING
CLEAN WASH AND CARE FOR INTIMATE CLOTHING



Image: The washing machine in use, showing water swirling inside the blue foldable bucket, illustrating its function for cleaning intimate clothing.

HYGIENE AND HEALTH
WASH YOUR CLOTHES SEPARATELY
AVOID CROSS INFECTION



Image: A top-down view of the pulsator within the bucket, surrounded by undergarments, emphasizing the separate washing for hygiene.

WAVE WHEEL CENTRIFUGAL TECHNOLOGY
POWERFUL MOTOR DRIVEN CENTRIFUGAL FLOW
EFFECTIVELY PREVENT UNDERWEAR FROM WINDING DEFORMATION

Powerful drive, strong torsion wash
Noise reduction and low consumption
Higher durability



Image: Undergarments being agitated by the centrifugal water flow, highlighting the wave centrifugal technology that prevents deformation.

**MULTI OCCASION USE
LIGHTWEIGHT BODY
SOLVE LAUNDRY TROUBLES ANYTIME, ANYWHERE**



Student dormitory



Business trip



B&B Hotel



Home Care

Image: A collage showing various application scenarios for the portable washing machine, including student dormitories, business trips, B&B hotels, and home care.



Image: A diagram illustrating the dimensions of the washing machine bucket when expanded (32cm/12.5in diameter, 25cm/9.8in height) and folded (5cm/1.9in height).



1 Warning

Please read the product instructions carefully before use to ensure correct use.

2 Warnung

Bitte lesen Sie das Produkthandbuch vor dem Gebrauch sorgfältig durch, um sicherzustellen, dass es korrekt und gemäß den Anweisungen verwendet wird.

3 Avertissement

Euillez lire attentivement les instructions du produit avant utilisation pour garantir une utilisation correcte selon les instructions.

4 Advertencia

Por favor, lea detenidamente el manual del producto antes de usarlo para asegurarse de seguir correctamente las instrucciones.

5 Attenzione

Leggere attentamente il manuale del prodotto prima dell'uso per garantire il corretto utilizzo delle istruzioni.

6 Waarschuwing

Lees voor gebruik aandachtig de handleiding van het product om er zeker van te zijn dat het correct en in overeenstemming met de instructies wordt gebruikt.

7 Varning

Läs bruksanvisningen noggrant före användning för att säkerställa att produkten används på rätt sätt och i enlighet med instruktionerna.

8 Ostrzeżenie

Przed użyciem prosimy dokładnie przeczytać instrukcję obsługi produktu, aby upewnić się, że są przestrzegane poprawne wskazówki dotyczące użytkowania.

9 Uyarı

Lütfen doğru kullanım talimatlarını sağlamak için kullanmadan önce ürün kılavuzunu dikkatlice okuyun.

Image: The washing machine bucket shown in its compact, folded state, ready for storage or transport.

5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Expand Bucket:** Place the foldable bucket on a flat, stable surface and gently expand it to its full height.
3. **Attach Pulsator:** Place the turbo pulsator unit at the bottom center of the bucket. Secure it using the provided suction cup to prevent movement during operation. Ensure the pulsator is firmly attached to the bucket's base.
4. **Connect Power:** Insert the USB power cable into the pulsator unit and connect the other end to a compatible 5V USB power source (e.g., a USB wall adapter, power bank, or computer USB port).

6. OPERATING INSTRUCTIONS

1. **Add Water:** Fill the bucket with an appropriate amount of water, ensuring it covers the clothes but does not exceed the maximum fill line (if indicated) or overflow during washing.
2. **Add Detergent:** Add a small amount of suitable laundry detergent. Avoid excessive foaming detergents.

- 3. **Load Clothes:** Place up to 5KG of laundry (including water weight) into the bucket. Do not overload. This machine is ideal for small items like underwear, socks, and baby clothes.
- 4. **Start Cycle:** Once powered, the machine will typically start automatically or with a single button press (refer to specific unit for button functionality if present). The machine operates with a single standard cycle.
- 5. **Automatic Shut-off:** The machine is designed to automatically power off after approximately 20 minutes of operation.
- 6. **Drain Water:** After the cycle completes, unplug the power cable. Carefully lift the bucket and pour out the dirty water.
- 7. **Rinse (Optional):** For rinsing, refill the bucket with clean water and run another short cycle without detergent, then drain.
- 8. **Remove Laundry:** Take out the washed items.

7. MAINTENANCE

- **Cleaning:** After each use, rinse the bucket and pulsator with clean water. Wipe the exterior of the pulsator unit with a damp cloth. Do not use abrasive cleaners.
- **Drying:** Allow all components to air dry completely before folding and storing.
- **Storage:** Fold the bucket for compact storage. Store the machine in a cool, dry place away from direct sunlight.
- **Cable Care:** Do not bend or crimp the USB power cable excessively.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not start	No power or loose connection	Ensure USB cable is securely connected to both the pulsator and the power source. Verify the power source is active.
Pulsator not spinning effectively	Overloaded or pulsator not secured	Reduce laundry load. Ensure the suction cup firmly attaches the pulsator to the bucket bottom.
Water leaking	Bucket not fully expanded or damaged	Ensure the foldable bucket is fully expanded and stable. Inspect for any visible damage.
Unusual noise during operation	Foreign object or unstable placement	Check for any foreign objects in the bucket. Ensure the machine is on a flat, stable surface.

9. SPECIFICATIONS

Feature	Detail
Item Type	Folding Washing Machine
Brand	Septpenta
Model Number	Septpentar26iknx7sw

Feature	Detail
Material	ABS
Voltage	5V
Power	18W
Capacity	5KG / 11lbs (including water)
Auto Power Off	After 20 minutes of work
Item Weight	0.95 Kilograms / 2.09 pounds
Product Dimensions (Expanded)	12.6 x 12.6 x 9.84 inches (32 x 32 x 25 cm)
Special Feature	Foldable
Access Location	Top Load
Standard Cycles	1

10. WARRANTY AND SUPPORT

For any questions or concerns regarding your Septpenta Mini Portable Foldable Turbo Washing Machine, please contact Septpenta customer service. We aim to reply to all inquiries within 24 hours.
Please refer to your purchase documentation for specific warranty details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question