

Amkette 584

Amkette Pocket Mate Digital FM Radio with Bluetooth Speaker

Model: 584 | Brand: Amkette

INTRODUCTION

The Amkette Pocket Mate is a versatile digital FM radio and Bluetooth speaker designed for portable audio entertainment. It features multiple playback options including FM radio, Bluetooth connectivity, Micro SD card, and USB input. Equipped with a number pad for easy station and song selection, an LED display, and a built-in antenna, this device offers up to 8 hours of playtime on a single charge via its Type-C charging port.

WHAT'S IN THE BOX

- 1 x Amkette Pocket Mate Digital FM Radio with Bluetooth Speaker
- 1 x User Manual
- 1 x Charging Cable (Type-C)

PRODUCT OVERVIEW

Familiarize yourself with the components of your Amkette Pocket Mate.



Figure 1: Front view of the Amkette Pocket Mate Digital FM Radio with Bluetooth Speaker. It features a speaker grille on the left, an LED display, and a number pad on the right. An extendable antenna is visible at the top.



Figure 2: Close-up view highlighting the LED display and number pad for quick access to radio stations or songs.



Figure 3: The device in FM Radio Mode, showing the extended antenna for strong signal reception. The display shows a frequency of 104.8 MHz.




Figure 4: Illustration of multiple playback options including Bluetooth, FM Radio, USB, and Micro SD player. A USB drive is shown inserted into the device.



Figure 5: Diagram showing the dimensions of the Amkette Pocket Mate: 11.81 cm length, 6.4 cm width, and 2.79 cm height.

Key Components:

- **LED Display:** Shows current mode, frequency, or track information.
- **Number Pad:** For direct frequency input in FM mode or track selection.
- **Function Buttons:** Power, Play/Pause, Mode, Previous/Next Track.
- **Extendable Antenna:** For enhanced FM radio reception.
- **Speaker:** Built-in 5W speaker for audio output.
- **Micro SD Card Slot:** For playing audio files from a Micro SD card.
- **USB Input:** For playing audio files from a USB drive.
- **3.5mm Headphone Jack:** For private listening.
- **Type-C Charging Port:** For charging the internal battery.

SETUP

1. Charging the Device

1. Connect the provided Type-C charging cable to the charging port on the Amkette Pocket Mate.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer's USB port.
3. The LED display will indicate charging status. A full charge provides up to 8 hours of playback.

2. Powering On/Off

- To power on, press and hold the **Power button** (🔌) for a few seconds until the LED display lights up.
- To power off, press and hold the **Power button** again until the display turns off.

OPERATING INSTRUCTIONS

1. Mode Selection

Press the **Mode (M) button** to cycle through available modes: FM Radio, Bluetooth, Micro SD Card, and USB Input.

2. FM Radio Operation

1. Extend the antenna fully for optimal reception.
2. Press the **Mode (M) button** to select FM Radio mode.
3. **Auto Search and Save:** Press and hold the **Play/Pause button** to automatically scan and save all available FM stations.

- 4. **Manual Tuning:** Use the **Previous/Next Track buttons** to fine-tune the frequency.
- 5. **Direct Frequency Input:** Use the **number pad** to directly enter the desired FM frequency (e.g., 104.8).

3. Bluetooth Pairing

- 1. Press the **Mode (M) button** to select Bluetooth mode. The device will enter pairing mode, indicated by a flashing Bluetooth icon or specific audio prompt.
- 2. On your smartphone, tablet, or PC, enable Bluetooth and search for available devices.
- 3. Select "Amkette Pocket Mate" from the list of devices to pair.
- 4. Once paired, you can stream audio wirelessly to the speaker.

4. Micro SD Card / USB Playback

- 1. Insert a Micro SD card into the designated slot or a USB drive into the USB port.
- 2. The device should automatically switch to the corresponding playback mode. If not, press the **Mode (M) button** to select it.
- 3. Use the **Previous/Next Track buttons** to navigate through songs.
- 4. Press the **Play/Pause button** to play or pause audio.

5. Volume Control

Volume is typically controlled by long-pressing the **Previous/Next Track buttons** or directly from the connected Bluetooth device.

6. Headphone Use

Plug any standard 3.5mm headphones into the headphone jack for private listening. The speaker output will automatically mute.

MAINTENANCE

- Keep the device dry. Avoid exposure to water or excessive humidity.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the device in a cool, dry place when not in use.
- Avoid dropping or subjecting the device to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery or no charge.	Charge the device using the provided Type-C cable.
No sound from speaker.	Volume too low; device in headphone mode; incorrect mode selected.	Increase volume; remove headphones; ensure correct mode (FM, BT, SD, USB) is selected.
Poor FM radio reception.	Antenna not extended; weak signal area.	Fully extend the antenna; try moving to a location with better signal.

Problem	Possible Cause	Solution
Bluetooth device not pairing.	Device not in pairing mode; Bluetooth disabled on source device.	Ensure Amkette Pocket Mate is in Bluetooth pairing mode; enable Bluetooth on your source device and search again.
Micro SD/USB not playing.	Incorrect file format; card/drive not inserted correctly; corrupted files.	Ensure audio files are in a compatible format; reinsert card/drive; try a different card/drive.

SPECIFICATIONS

Brand	Amkette
Model Name	Pocket Mate FM
Model Number	584
Product Dimensions	3.9 x 7.5 x 16.3 cm; 320 g
Batteries	1 Lithium Ion battery (included)
Hardware Interface	MicroSD, USB
Tuner Technology	FM
Compatible Devices	All Bluetooth enabled devices, Android, iPhone, PC, Laptop
Special Features	Crisp and Bassy 5 W speaker, High Quality FM Speaker with Antenna, Multiple Playback Options (BT, FM, SD Card, USB), Number Pad for Easy FM and Song Selection and LED Display, Up to 8 Hours of Playback
Display Type	LED
Speakers Maximum Output Power	5 Watts
Speaker Connectivity	Bluetooth and Aux
Power Source	Battery Powered
Battery Cell Composition	Lithium Ion
Connector Type	Bluetooth
Radio Bands Supported	FM
Material	Plastic
Country of Origin	China
Item Weight	320 g

WARRANTY AND SUPPORT





The Amkette Pocket Mate Digital FM Radio with Bluetooth Speaker comes with a**1-Year Manufacturing Warranty**.

For any issues, technical assistance, or warranty claims, please contact Amkette customer support. Contact details can typically be found on the official Amkette website or through the retailer where the product was purchased.

Please retain your purchase receipt for warranty validation.

© 2023 Amkette. All rights reserved.

Related Documents

	<p>Amkette Pocket Blast Bluetooth Speaker User Guide</p> <p>User guide for the Amkette Pocket Blast Bluetooth Speaker. This document provides technical specifications, troubleshooting tips, warranty information, and detailed instructions for using Bluetooth pairing, FM radio, USB/SD card playback, and recording functions.</p>
	<p>Amkette Boomer MAXX 500 User Guide: Features, Pairing, and Troubleshooting</p> <p>Comprehensive user guide for the Amkette Boomer MAXX 500 Bluetooth speaker. Learn about setup, charging, TWS pairing, AUX and USB playback, voice assistant activation, troubleshooting, specifications, and warranty information.</p>
	<p>EvoFox Elite X2 Pro Wireless Gamepad Quick Start Guide</p> <p>This guide provides instructions for setting up and using the EvoFox Elite X2 Pro Wireless Gamepad, including charging, Bluetooth and USB connectivity, button functions, and advanced features like macros and vibration control.</p>
	<p>Amkette EvoFox One S Universal Wireless Gamepad Quick Start Guide</p> <p>A comprehensive guide to setting up and using the Amkette EvoFox One S Universal Wireless Gamepad, covering features like macros, turbo settings, vibration levels, and connectivity modes for various platforms including PC, PS3, PS4, Switch, Android, and iOS.</p>

Note: The list includes all companies that registered during this period irrespective of the current status of the company. As such you will be aware

Note: The list includes all companies that registered during this period irrespective of the current status of the company. As such you will be aware

Year	Entity	Entity type	Rate of negligence	Rate of negligence
1997	1997-01-01	1997-01-01	1997-01-01	1997-01-01
1998	1998-01-01	1998-01-01	1998-01-01	1998-01-01
1999	1999-01-01	1999-01-01	1999-01-01	1999-01-01
2000	2000-01-01	2000-01-01	2000-01-01	2000-01-01
2001	2001-01-01	2001-01-01	2001-01-01	2001-01-01
2002	2002-01-01	2002-01-01	2002-01-01	2002-01-01
2003	2003-01-01	2003-01-01	2003-01-01	2003-01-01
2004	2004-01-01	2004-01-01	2004-01-01	2004-01-01
2005	2005-01-01	2005-01-01	2005-01-01	2005-01-01
2006	2006-01-01	2006-01-01	2006-01-01	2006-01-01
2007	2007-01-01	2007-01-01	2007-01-01	2007-01-01
2008	2008-01-01	2008-01-01	2008-01-01	2008-01-01
2009	2009-01-01	2009-01-01	2009-01-01	2009-01-01
2010	2010-01-01	2010-01-01	2010-01-01	2010-01-01
2011	2011-01-01	2011-01-01	2011-01-01	2011-01-01
2012	2012-01-01	2012-01-01	2012-01-01	2012-01-01
2013	2013-01-01	2013-01-01	2013-01-01	2013-01-01
2014	2014-01-01	2014-01-01	2014-01-01	2014-01-01
2015	2015-01-01	2015-01-01	2015-01-01	2015-01-01
2016	2016-01-01	2016-01-01	2016-01-01	2016-01-01
2017	2017-01-01	2017-01-01	2017-01-01	2017-01-01
2018	2018-01-01	2018-01-01	2018-01-01	2018-01-01
2019	2019-01-01	2019-01-01	2019-01-01	2019-01-01
2020	2020-01-01	2020-01-01	2020-01-01	2020-01-01
2021	2021-01-01	2021-01-01	2021-01-01	2021-01-01
2022	2022-01-01	2022-01-01	2022-01-01	2022-01-01
2023	2023-01-01	2023-01-01	2023-01-01	2023-01-01
2024	2024-01-01	2024-01-01	2024-01-01	2024-01-01
2025	2025-01-01	2025-01-01	2025-01-01	2025-01-01
2026	2026-01-01	2026-01-01	2026-01-01	2026-01-01
2027	2027-01-01	2027-01-01	2027-01-01	2027-01-01
2028	2028-01-01	2028-01-01	2028-01-01	2028-01-01
2029	2029-01-01	2029-01-01	2029-01-01	2029-01-01
2030	2030-01-01	2030-01-01	2030-01-01	2030-01-01
2031	2031-01-01	2031-01-01	2031-01-01	2031-01-01
2032	2032-01-01	2032-01-01	2032-01-01	2032-01-01
2033	2033-01-01	2033-01-01	2033-01-01	2033-01-01
2034	2034-01-01	2034-01-01	2034-01-01	2034-01-01
2035	2035-01-01	2035-01-01	2035-01-01	2035-01-01
2036	2036-01-01	2036-01-01	2036-01-01	2036-01-01
2037	2037-01-01	2037-01-01	2037-01-01	2037-01-01
2038	2038-01-01	2038-01-01	2038-01-01	2038-01-01
2039	2039-01-01	2039-01-01	2039-01-01	2039-01-01
2040	2040-01-01	2040-01-01	2040-01-01	2040-01-01
2041	2041-01-01	2041-01-01	2041-01-01	2041-01-01
2042	2042-01-01	2042-01-01	2042-01-01	2042-01-01
2043	2043-01-01	2043-01-01	2043-01-01	2043-01-01
2044	2044-01-01	2044-01-01	2044-01-01	2044-01-01
2045	2045-01-01	2045-01-01	2045-01-01	2045-01-01
2046	2046-01-01	2046-01-01	2046-01-01	2046-01-01
2047	2047-01-01	2047-01-01	2047-01-01	2047-01-01
2048	2048-01-01	2048-01-01	2048-01-01	2048-01-01
2049	2049-01-01	2049-01-01	2049-01-01	2049-01-01
2050	2050-01-01	2050-01-01	2050-01-01	2050-01-01
2051	2051-01-01	2051-01-01	2051-01-01	2051-01-01
2052	2052-01-01	2052-01-01	2052-01-01	2052-01-01
2053	2053-01-01	2053-01-01	2053-01-01	2053-01-01
2054	2054-01-01	2054-01-01	2054-01-01	2054-01-01
2055	2055-01-01	2055-01-01	2055-01-01	2055-01-01
2056	2056-01-01	2056-01-01	2056-01-01	2056-01-01
2057	2057-01-01	2057-01-01	2057-01-01	2057-01-01
2058	2058-01-01	2058-01-01	2058-01-01	2058-01-01
2059	2059-01-01	2059-01-01	2059-01-01	2059-01-01
2060	2060-01-01	2060-01-01	2060-01-01	2060-01-01
2061	2061-01-01	2061-01-01	2061-01-01	2061-01-01
2062	2062-01-01	2062-01-01	2062-01-01	2062-01-01
2063	2063-01-01	2063-01-01	2063-01-01	2063-01-01
2064	2064-01-01	2064-01-01	2064-01-01	2064-01-01
2065	2065-01-01	2065-01-01	2065-01-01	2065-01-01
2066	2066-01-01	2066-01-01	2066-01-01	2066-01-01
2067	2067-01-01	2067-01-01	2067-01-01	2067-01-01
2068	2068-01-01	2068-01-01	2068-01-01	2068-01-01
2069	2069-01-01	2069-01-01	2069-01-01	2069-01-01
2070	2070-01-01	2070-01-01	2070-01-01	2070-01-01
2071	2071-01-01	2071-01-01	2071-01-01	2071-01-01
2072	2072-01-01	2072-01-01	2072-01-01	2072-01-01
2073	2073-01-01	2073-01-01	2073-01-01	2073-01-01
2074	2074-01-01	2074-01-01	2074-01-01	2074-01-01
2075	2075-01-01	2075-01-01	2075-01-01	2075-01-01
2076	2076-01-01	2076-01-01	2076-01-01	2076-01-01
2077	2077-01-01	2077-01-01	2077-01-01	2077-01-01
2078	2078-01-01	2078-01-01	2078-01-01	2078-01-01
2079	2079-01-01	2079-01-01	2079-01-01	2079-01-01
2080	2080-01-01	2080-01-01	2080-01-01	2080-01-01
2081	2081-01-01	2081-01-01	2081-01-01	2081-01-01
2082	2082-01-01	2082-01-01	2082-01-01	2082-01-01
2083	2083-01-01	2083-01-01	2083-01-01	2083-01-01
2084	2084-01-01	2084-01-01	2084-01-01	2084-01-01
2085	2085-01-01	2085-01-01	2085-01-01	2085-01-01
2086	2086-01-01	2086-01-01	2086-01-01	2086-01-01
2087	2087-01-01	2087-01-01	2087-01-01	2087-01-01
2088	2088-01-01	2088-01-01	2088-01-01	2088-01-01
2089	2089-01-01	2089-01-01	2089-01-01	2089-01-01
2090	2090-01-01	2090-01-01	2090-01-01	2090-01-01
2091	2091-01-01	2091-01-01	2091-01-01	2091-01-01
2092	2092-01-01	2092-01-01	2092-01-01	2092-01-01
2093	2093-01-01	2093-01-01	2093-01-01	2093-01-01
2094	2094-01-01	2094-01-01	2094-01-01	2094-01-01
2095	2095-01-01	2095-01-01	2095-01-01	2095-01-01
2096	2096-01-01	2096-01-01	2096-01-01	2096-01-01
2097	2097-01-01	2097-01-01	2097-01-01	2097-01-01
2098	2098-01-01	2098-01-01	2098-01-01	2098-01-01
2099	2099-01-01	2099-01-01	2099-01-01	2099-01-01
2100	2100-01-01	2100-01-01	2100-01-01	2100-01-01

Official compilation of companies and Limited Liability Partnerships (LLPs) registered in India during 1993. Includes registration details and a link to the Ministry of Corporate Affairs (MCA) for current company status information.

lang:i-klinton **score:9** filesize: 2.57 M page_count: 481 document date: 2014-08-01