Lapcare LBS-004

Lapcare Gobeat LBS-004 Bluetooth Portable Speaker

User Manual

Model: LBS-004 | Brand: Lapcare

Introduction

Thank you for purchasing the Lapcare Gobeat LBS-004 Bluetooth Portable Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully to ensure optimal performance and longevity of your device.



This image displays the Lapcare Gobeat LBS-004 portable Bluetooth speaker in black, highlighting its sleek design and the accessible control panel on top, including power, volume, and mode buttons. The speaker features a 10 Watt power output.

Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and other liquids. It is not waterproof.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for any repairs.
- Use only the provided charging cable or a certified equivalent.
- Listen at moderate volume levels to prevent hearing damage.

Package Contents

Please check the box for the following items:

- 1 x Lapcare Gobeat LBS-004 Bluetooth Portable Speaker
- 1 x Charging Cable
- 1 x Warranty Card
- 1 x Product Manual (this document)

Product Overview

Familiarize yourself with the speaker's controls and ports:

- **Power Button ( ):** Press and hold to power on/off. Short press to switch modes (Bluetooth, FM, Micro SD, USB).
- **Play/Pause/Call Button (▶▌▌ / ☎):** Short press to play/pause music. Short press to answer/end calls. Press and hold to reject an incoming call.
- **Volume Down / Previous Track (-):** Short press for volume down. Press and hold for previous track.
- **Volume Up / Next Track (+):** Short press for volume up. Press and hold for next track.
- **Microphone (MIC):** For hands-free calling.
- **USB Port:** For USB drive playback.
- **Micro SD Card Slot:** For Micro SD card playback.
- **Charging Port:** For charging the speaker.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. The estimated charge time is 2.3 hours.

1. Connect the provided charging cable to the speaker's charging port.
2. Connect the other end of the cable to a 5 Volt USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color once charging is complete.

2. Power On/Off

- To power on, press and hold the Power button ( ) for approximately 3 seconds. You will hear an audible prompt.
- To power off, press and hold the Power button ( ) for approximately 3 seconds. You will hear an audible prompt.

3. Bluetooth Pairing

Pair your speaker with a Bluetooth-enabled device to play audio wirelessly.

1. Ensure the speaker is powered on and in Bluetooth mode. If not, short press the Power button ( ) to cycle through modes until you hear the Bluetooth pairing prompt. The LED indicator will flash, indicating it's ready for pairing.
2. Enable Bluetooth on your mobile phone, tablet, or computer.
3. Search for available Bluetooth devices and select "LBS-004" from the list.
4. Once paired, the speaker will emit a confirmation sound, and the LED indicator will stop flashing and remain solid.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.



This image features the Lapcare Gobeat LBS-004 speaker positioned vertically next to a person using a smartphone, symbolizing its Bluetooth 5.0 connectivity and hands-free calling capability, powered by an 1800mAh battery.

4. FM Radio Operation

1. Power on the speaker and short press the Power button ( ) to switch to FM Radio mode.
2. Press the Play/Pause button (▶❚❚) once to automatically scan and save available FM stations.
3. Use the Volume Up (+) and Volume Down (-) buttons (press and hold) to navigate between saved stations.

5. Micro SD Card / USB Drive Playback

1. Insert a Micro SD card or USB drive into the corresponding slot/port.
2. The speaker will automatically detect the storage device and switch to the appropriate playback

mode.

3. Use the Play/Pause button (▶❚❚) to control playback.
4. Use the Volume Up (+) and Volume Down (-) buttons (press and hold) to skip tracks.

Operating

Basic Controls

- **Volume Adjustment:** Short press the Volume Up (+) or Volume Down (-) buttons to adjust the volume.
- **Track Navigation:** Press and hold the Volume Up (+) button for the next track. Press and hold the Volume Down (-) button for the previous track.
- **Play/Pause:** Short press the Play/Pause button (▶❚❚) to play or pause audio.
- **Mode Switching:** Short press the Power button ( ) to switch between Bluetooth, FM Radio, Micro SD, and USB modes.

Hands-free Calling

When connected via Bluetooth to your smartphone:

- **Answer Call:** Short press the Play/Pause/Call button (☎) to answer an incoming call.
- **End Call:** Short press the Play/Pause/Call button (☎) to end an ongoing call.
- **Reject Call:** Press and hold the Play/Pause/Call button (☎) to reject an incoming call.



The Lapcare Gobeat LBS-004 speaker is shown in a home setting, with text emphasizing 'Immersive Audio Experience' and 'Dual Drivers 45mm X 2', indicating its sound quality.

Maintenance


Cleaning

- Wipe the speaker with a soft, dry cloth.

- Do not use abrasive cleaners, alcohol, or chemical solvents.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its lifespan.



This image shows the Lapcare Gobeat LBS-004 speaker attached to a backpack, demonstrating its portability for outdoor activities. It is designed for music on the go.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source and try again.
No sound from the speaker.	Check the volume level on both the speaker and your connected device. Ensure the speaker is in the correct mode (Bluetooth, FM, Micro SD, USB).
Cannot pair with Bluetooth device.	Ensure the speaker is in Bluetooth pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move the speaker closer to your device. Clear previous pairings on your device.
FM radio reception is poor.	Move the speaker to an open area. Some environments may have weaker signals.

Specifications

Feature	Detail

Feature	Detail
Brand	Lapcare
Model Name	Lapcare Gobeat LBS-004
Model Number	LKAMBLSH7430
Speaker Maximum Output Power	10 Watts
Connectivity Technology	Bluetooth, USB
Wireless Technology Type	Bluetooth
Bluetooth Version	5.0 (Inferred from image, not explicit in specs list)
Audio Output Mode	Stereo
Speaker Type	Component
Woofer Driver Diameter	45 Millimetres
Frequency Response	18.5 KHz
Signal-to-Noise Ratio	70 dB
Impedance	4 Ohms
Battery Average Life	10 Hours
Battery Charge Time	2.3 Hours
Battery Capacity	1800 mAh (Inferred from image, not explicit in specs list)
Input Voltage	5 Volts
Total USB 2.0 Ports	1
Product Features	Built-in Microphone, Powerful Bass, Shockproof, Smart Design, USB Port
Enclosure Material	ABS, Plastic, Rubber, Silicone
Item Dimensions (D x W x H)	18.3D x 6W x 6H Centimeters
Item Weight	381 Grams
Color	Black
Water Resistance Level	Not Water Resistant

Warranty Information

The Lapcare Gobeat LBS-004 Bluetooth Portable Speaker comes with a **1 Year Manufacturer Warranty**. Please refer to the included warranty card for detailed terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For any queries, technical assistance, or warranty claims, please contact Lapcare customer support:

- **Manufacturer:** Rx Infotech Pvt Ltd.
- **Address:** Unit No -407, 4th Floor, Plot - 391, Diamond Plaza, Dr. D.b. Marg, Girgaon Mumbai – 400004
- Please visit the official Lapcare website for the most up-to-date contact information and support resources.