



Manuals.plus /

› FEONAL /

› FEONAL 10-inch Android Tablet (Model 2024) User Manual

FEONAL 2024 Latest Android Tablet

FEONAL 10-inch Android Tablet (Model 2024) User Manual

Model: 2024 Latest Android Tablet | Brand: FEONAL

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your FEONAL 10-inch Android Tablet (Model 2024). This tablet is designed for versatile use, featuring an Octa-Core T610 processor, 8GB RAM, 128GB internal storage (expandable up to 1TB via TF card), a 10.1-inch HD display, and dual cameras. It operates on the Android 12 system and supports 2.4G/5G dual-band WiFi and Bluetooth 5.0.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x FEONAL K110 Tablet
- 1 x Tablet Case
- 1 x Keyboard
- 1 x Mouse
- 1 x OTG Adapter
- 1 x Touch Pen
- 1 x Type-C Cable
- 1 x Charger
- 1 x TF Card Pin
- 1 x User Manual



Image: FEONAL Tablet shown with its accompanying keyboard, mouse, stylus, charger, and protective case.

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components of your tablet:

Light & Thin Metal Unibody Body

The best choice for gifts, meet the needs of every age group



Image: Detailed view of the tablet's side, highlighting the Type-C port, reset button, volume buttons, power button, 3.5mm headphone jack, Micro SD slot, and dual speakers.

- **Type-C Port:** For charging and data transfer.
- **Reset Button:** Used to restart the device if it becomes unresponsive.
- **Volume Buttons:** Adjust the audio output level.
- **Power Button:** Press and hold to power on/off or restart. Press briefly to turn the screen on/off.
- **3.5mm Headphone Jack:** Connect wired headphones.
- **Micro SD Slot:** Insert a TF (Micro SD) card for expandable storage up to 1TB.
- **Dual Speakers:** Provide stereo audio output.
- **Front Camera (8MP):** Located on the top bezel for video calls and selfies.
- **Rear Camera (13MP):** Located on the back for high-resolution photos and videos.

4. SETUP

4.1 Initial Power On

1. Press and hold the **Power Button** until the FEONAL logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and accept the terms and conditions.

4.2 Wi-Fi Connection

1. During initial setup or via **Settings > Network & internet > Wi-Fi**, select your desired Wi-Fi network.
2. Enter the Wi-Fi password if prompted and tap **Connect**. The tablet supports both 2.4G and 5G networks.

4.3 Google Account Setup

Sign in with your Google account to access Google Play Store, Gmail, and other Google services. If you don't have an account, you can create one during this step.

4.4 Connecting Accessories (Keyboard & Mouse)

The included keyboard and mouse connect wirelessly. The mouse requires its own batteries (not included) and connects via a USB dongle. The keyboard connects via Bluetooth.

1. **Mouse:** Insert batteries into the mouse. Locate the USB dongle for the mouse (often stored within the mouse itself) and plug it into the OTG adapter. Then, plug the OTG adapter into the tablet's Type-C port. The mouse should be recognized automatically.
2. **Keyboard:** Turn on the keyboard. Go to **Settings > Connected devices > Bluetooth** on your tablet. Enable Bluetooth and search for available devices. Select the keyboard from the list and follow any pairing instructions.

Your browser does not support the video tag.

Video: An official product video demonstrating the FEONAL 10.1-inch Android tablet, highlighting its features and accessories.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The tablet runs on Android 12, offering an intuitive touch interface. Swipe to navigate home screens, open the app drawer, and access notifications or quick settings.

5.2 App Management

Download applications from the Google Play Store. To install, open the Play Store, search for your desired app, and tap **Install**. To uninstall, long-press the app icon on the home screen or in the app drawer, then drag it to the uninstall option.

7000mAh

7000 mAh | Type-C

LONG LASTING BATTERY
Power for All Your Needs

The 7000mAh battery supports enough power for the whole family whether playing games, scrolling social media or streaming your favorite shows or movies.

Reference Duration:

- Video 8 Hours
- Browsing 12 Hours
- E-Book 15 Hours

Image: The tablet's screen showing a variety of installed applications, demonstrating its multi-functional capabilities.

5.3 Storage Management

The tablet comes with 128GB of internal storage. You can expand this by inserting a TF (Micro SD) card into the dedicated slot. To manage storage, go to **Settings > Storage**.



Processor
Octa-core | Vivid Screen
10.1 Inch

**FASTER PROCESSING SPEED
BIGGER STORAGE FOR ALL**

Get the power, storage & speed your family / friend needs with an upgraded chipset and plenty of room to keep files — 128GB of storage; a long-lasting battery lets you go unplugged for hours to keep the fun going.

Image: Visual representation of the tablet's storage capabilities, including 128GB ROM, 4GB RAM, and support for 1TB TF card expansion.

5.4 Camera Usage

The tablet features an 8MP front camera and a 13MP rear camera. Open the Camera app to take photos or record videos. Tap the screen to focus and use the on-screen buttons to switch between modes or cameras.



Image: The tablet displaying images taken with its 8MP front camera and 13MP rear camera, illustrating its photography features.

5.5 Battery Life

The tablet is equipped with a 7000mAh battery, providing extended usage. To optimize battery life, adjust screen brightness, close unused apps, and disable Wi-Fi or Bluetooth when not in use.




Image: The tablet showcasing its 7000mAh battery capacity and estimated usage times for video playback, browsing, and e-book

6. MAINTENANCE

6.1 Cleaning

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the device.

6.2 Software Updates

Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings > System > System update** to check for updates.

7. TROUBLESHOOTING

- **Tablet not turning on:** Ensure the tablet is charged. Connect it to the charger and wait a few minutes before attempting to power it on again.
- **Screen is unresponsive:** Try restarting the tablet by pressing and holding the power button for about 10-15 seconds. If that doesn't work, use a pin to press the reset button (if available, refer to Product Overview).
- **Wi-Fi connection issues:** Check if other devices can connect to the Wi-Fi network. Restart your router and the tablet. Ensure the Wi-Fi password is correct.
- **Keyboard/Mouse not connecting:** For the mouse, ensure batteries are installed and the USB dongle is properly connected via the OTG adapter. For the keyboard, ensure Bluetooth is enabled on the tablet and the keyboard is in pairing mode.
- **Slow performance:** Close unused applications, clear cache, and ensure you have sufficient storage space. Consider performing a factory reset if issues persist (back up your data first).

8. SPECIFICATIONS

Feature	Specification
Brand	FEONAL
Model Name	2024 Latest Android Tablet
Memory Storage Capacity	128 GB (Expandable up to 1TB via TF Card)
RAM Memory Installed	8 GB (4+4GB)
Screen Size	10.1 inches
Display Resolution Maximum	1280x800 Pixels
Operating System	Android 12
Processor	Octa-Core T610 (MediaTek)
Processor Speed	1.8 GHz
Rear Facing Camera Photo Sensor Resolution	13 MP
Front Photo Sensor Resolution	8 MP
Battery Capacity	7000 mAh
Battery Average Life	Up to 14 Hours (local video playback)
Wireless Technology	Bluetooth 5.0, Wi-Fi (2.4G/5G)
Connectivity Technology	USB Type C
Color	Gray
Item Dimensions (L x W x Thickness)	10.1"L x 6.5"W x 0.2"Th
GTIN / UPC	700721581917

9. WARRANTY AND SUPPORT

Your FEONAL Tablet comes with a **1-Year Limited Warranty**. For any issues or support inquiries, please contact FEONAL customer service. Refer to the contact information provided in your product packaging or on the official FEONAL website.