

[Manuals.plus](#) /

› [Anna Bella](#) /

› Anna Bella 10.1 Inch Smart WiFi Digital Photo Frame User Manual

Anna Bella B0BVQ1BV9V

Anna Bella 10.1 Inch Smart WiFi Digital Photo Frame User Manual

Model: B0BVQ1BV9V

Brand: Anna Bella

INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your Anna Bella 10.1 Inch Smart WiFi Digital Photo Frame. This device is designed to display digital photos and videos, offer video call functionality, and allow remote sharing of memories with family and friends.



Image: The Anna Bella Digital Photo Frame, showcasing its ability to display photos and facilitate video calls. A family is shown on the frame, while a smartphone displays a video call with older relatives.

SETUP

1. Power Connection

Connect the provided USB-C cable to the frame's power port and plug the adapter into a standard electrical outlet. The frame will power on automatically.

2. Initial Wi-Fi Setup

Upon first use, the frame will guide you through the Wi-Fi setup process. Select your home Wi-Fi network from the list and enter the password. Ensure a stable internet connection for optimal performance.

3. AiMOR APP Installation and Pairing

To share photos and videos remotely, download the "AiMOR" application from your device's app store (Google Play for Android or Apple App Store for iOS). Follow the in-app instructions to create an account and pair it with your digital photo frame. The frame will display a unique code for pairing.

4. Auto-Rotate Functionality

The frame features an auto-rotate function, allowing it to automatically adjust the photo orientation whether placed in portrait or landscape mode. This ensures images always fit the frame perfectly.

Auto-Rotate Photos



Video Call



Photos



Videos



Aimor App



Clock



Weather



Touchscreen



Light Sensor

Image: Illustration demonstrating the frame's auto-rotate capability, showing a photo automatically reorienting itself when the frame is turned from portrait to landscape.

OPERATING INSTRUCTIONS

1. Touch Screen Navigation

The 10.1-inch IPS HD touch screen allows for intuitive navigation. Swipe left or right to browse photos, tap to access settings, and use pinch-to-zoom gestures for closer inspection of images.

2. Sharing Photos and Videos via AiMOR APP

Once paired, use the AiMOR APP on your smartphone to wirelessly share photos and short videos (max 15 seconds) to the frame. You can share up to 9 photos or 1 short video at a time. The frame supports instant batch uploads when connected to the same Wi-Fi network.

Pop-up Design Camera

Protect Your Privacy



Image: The AiMOR app on a smartphone demonstrating the instant batch upload feature, allowing users to quickly send multiple photos to the digital frame.

3. Video Call Function

The frame features a newly upgraded pop-up camera, enabling video calls with friends and family who also have the AiMOR APP. Initiate calls directly from the frame or receive calls from connected contacts. The pop-up design allows you to easily block the camera lens for privacy.

Light Sensor

Automatically adjust screen brightness according to the environment light intensity.



Image: Demonstrates the instant video call feature, showing a family making a video call on the frame, and an older couple receiving the call on another frame, highlighting remote connection.

Instant Batch Upload With AiMOR

Supports transferring 50 photos while connected to the same WiFi



Image: Two frames illustrating the pop-up camera design, emphasizing the privacy feature where the camera can be retracted when not in use.

4. Slideshow and Display Settings

Customize your viewing experience with various settings available through the touch screen or AiMOR APP. Options include timer settings for photo transitions, zoom & crop functions, and sleep mode. The built-in light sensor automatically adjusts screen brightness based on ambient light conditions.

Happy Mother's Day 🎉



Image: Shows the light sensor in action, with the frame's screen brightness adapting to different lighting conditions, from a bright room to a dark bedroom.

MAINTENANCE

To ensure the longevity and optimal performance of your digital photo frame, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the touch screen. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Storage:** If storing the frame for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your digital photo frame, try the following common troubleshooting steps:

- **Frame Not Powering On:** Ensure the power cable is securely connected to both the frame and the power outlet. Try a different outlet if necessary.
- **No Wi-Fi Connection:** Check if your Wi-Fi router is working correctly. Re-enter the Wi-Fi password on the frame to ensure it's accurate. Move the frame closer to the router to improve signal strength.
- **Unable to Upload Photos/Videos:** Verify that the frame is connected to Wi-Fi and that your AiMOR APP is correctly paired. Ensure the files you are trying to upload are within the supported size and format limits (e.g., 15 seconds max for videos).
- **Screen Unresponsive:** Restart the frame by disconnecting and reconnecting the power. If the issue persists, perform a factory reset (refer to the on-screen settings for this option).
- **Images Not Displaying Correctly:** Check the resolution of your images. While the frame supports 1280*800 resolution, very low-resolution images may appear pixelated. Ensure images are in a compatible format.

SPECIFICATIONS

Feature	Detail
Screen Size	10.1 Inches
Resolution	1280*800 (WXGA)
Display Type	IPS HD Touch Screen
Internal Storage	16GB (stores 40,000+ photos at 300KBS each)
Connectivity	WiFi
Ports	USB port, SD card slot
Special Features	Video Call Function, Auto-Rotate, Light Sensor, Pop-up Camera for Privacy
Product Dimensions	10.1 x 7.1 x 0.99 inches
Item Weight	2.64 pounds
Compatible Devices	Smartphone (via AiMOR APP)

10.1 Inch Picture Display

Resolution
1280*800


IPS Display


Touchscreen




Image: Close-up of the digital photo frame's screen, emphasizing its 10.1-inch size, 1280x800 resolution, IPS display technology, and touchscreen capabilities.

WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not provided in the available product data. Please refer to the product packaging or the manufacturer's official website for the most up-to-date warranty terms and customer support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question