Oraimo OPC-TR10

Oraimo SmartTrimmer Multi Grooming Kit User Manual

Model: OPC-TR10 | Brand: Oraimo

1. Introduction

Thank you for choosing the Oraimo SmartTrimmer Multi Grooming Kit. This all-in-one cordless trimmer is designed for precise grooming of your beard, head, face, and body. Featuring a powerful motor, durable stainless steel blades, an intelligent LED indicator, and a convenient travel lock, the SmartTrimmer provides a smooth and efficient trimming experience. Please read this manual carefully before use to ensure proper operation and maintenance.

2. What's in the Box

Verify that all components are present in your package:

- 1 x Oraimo SmartTrimmer (OPC-TR10)
- 4 x Guide Combs (various lengths)
- 1 x Type-C Charging Cable
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle
- 1 x User Manual



Image: All components included in the Oraimo SmartTrimmer package.

3. Product Overview

The Oraimo SmartTrimmer is designed for versatility and performance across various grooming needs.

Multi-functional Usage

This all-in-one trimmer is suitable for beard styling, head hair cutting, and body grooming, providing precise results for different hair types and lengths.




Image: Demonstrating the trimmer's use for face, head, and body.

Powerful & Durable Motor

Equipped with a full metal motor reinforced with tempered steel and stainless steel blades, the SmartTrimmer delivers maximum power for a clean and smooth trim, ensuring long-lasting sharpness and performance.

Image: Illustration of the trimmer's powerful and durable motor.

LED Indicator & Long-lasting Battery

The built-in LED display indicates the current battery power, reminding you when to charge. The rechargeable Lithium-ion battery provides up to 90 minutes of continuous run time after approximately 1.5 hours of charging.



Image: The trimmer showing its LED indicator and charging port.

Travel Lock

A considerate travel lock feature prevents the trimmer from accidentally turning on while stored in luggage or during transport, conserving battery life and preventing unintended operation.



Image: Detail of the travel lock function on the trimmer.

4. Setup

Initial Charge

1. Before first use, fully charge the trimmer. Connect the Type-C charging cable to the trimmer's charging port and plug the other end into a compatible USB power adapter (not included).
2. The LED indicator will illuminate during charging. A full charge takes approximately 1.5 hours.
3. Once fully charged, the trimmer provides up to 90 minutes of cordless operation.

Attaching Guide Combs

1. Ensure the trimmer is turned off.
2. Select the desired guide comb for your preferred hair length.
3. Align the comb with the trimmer blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb away from the blade.

5. Operating Instructions

Turning On/Off

- Press the power button once to turn the trimmer on.
- Press the power button again to turn the trimmer off.

Using the Travel Lock

- **To activate Travel Lock:** With the trimmer turned off, long press the power button for approximately 4 seconds until the LED indicator flashes, indicating the lock is engaged.
- **To release Travel Lock:** Long press the power button for approximately 4 seconds until the LED indicator illuminates steadily, indicating the lock is disengaged and the trimmer is ready for use.

General Trimming Tips

- For best results, use the trimmer on clean, dry hair.
- Always start with a longer guide comb if you are unsure of the desired length.
- Move the trimmer against the direction of hair growth for an even cut.
- Use short, controlled strokes.
- For detailing or outlining, remove the guide comb and use the bare blade carefully.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your trimmer and ensure optimal performance.

Cleaning the Blades

1. Turn off the trimmer and disconnect it from the charging cable.
2. Remove any attached guide combs.
3. Use the provided cleaning brush to brush away hair clippings from the blades and the trimmer head.
4. For a more thorough clean, the blade head can be rinsed under running water. Ensure the trimmer body does not get wet. Allow the blade head to air dry completely before reattaching or storing.

Lubricating the Blades

1. After cleaning and drying, apply 1-2 drops of the provided lubricating oil to the blades.
2. Turn on the trimmer for a few seconds to allow the oil to distribute evenly.
3. Wipe off any excess oil with a soft cloth.

Storage

Store the trimmer in a cool, dry place, away from direct sunlight and moisture. Ensure the travel lock is activated if storing in luggage.

7. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted; Travel lock is engaged.	Charge the trimmer fully; Release the travel lock by long pressing the power button for 4 seconds.
Trimmer stops working shortly after charging.	Battery not holding charge; Improper charging.	Ensure the charging cable is securely connected; Try a different USB power adapter; If issue persists, contact customer service.
Trimmer pulls hair or cuts unevenly.	Blades are dull or clogged; Insufficient lubrication.	Clean the blades thoroughly; Apply lubricating oil to the blades.
Trimmer makes unusual noise.	Blades are clogged or misaligned; Needs lubrication.	Clean and lubricate the blades; Ensure the blade head is properly seated.

8. Specifications

Feature	Detail
Model Name	SmartTrimmer
Item Model Number	OPC-TR10
Power Source	Battery Powered
Blade Material	Stainless Steel
Battery Type	Lithium Polymer
Run Time	Up to 90 minutes
Charging Time	Approximately 1.5 hours
Product Dimensions (LxWxH)	20 x 16 x 4.6 cm
Item Weight	290 g
Included Components	Hair Trimmer, 4 Guide Combs, Type-C Cable, User Manual

9. Warranty and Support

Oraimo provides a **1-year warranty** for the SmartTrimmer Multi Grooming Kit. We are committed to resolving any issues you may encounter within 24 hours.
For customer service and support, please contact:
Customer Care: 1800 419 0525
Please retain your purchase receipt as proof of purchase for warranty claims.

© 2024 Oraimo. All rights reserved.