

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Corner Desk User Manual

vidaXL Corner Desk

vidaXL Corner Desk User Manual

Model: Adjustable Writing Desk with Storage

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your new vidaXL Corner Desk. Designed for versatility, this desk features a unique rotatable design, allowing it to function as both a straight desk and a corner desk, adapting to various room layouts. It also includes ample storage compartments for your office essentials.

Please read this manual thoroughly before assembly and use to ensure proper setup and to maximize the lifespan of your product.

SAFETY INFORMATION

Important Safety Warning: To prevent overturning, this product **must** be used with the wall attachment device provided. Ensure the desk is securely anchored to a stable wall surface before use. Failure to do so can result in serious injury.

- Keep all assembly hardware out of reach of children.
- Do not stand or sit on the desk.
- Ensure all connections are tight before use. Periodically check and re-tighten as necessary.
- Place the desk on a flat, stable surface.

PARTS LIST AND ASSEMBLY

Your vidaXL Corner Desk comes with a detailed assembly manual and all necessary parts and hardware included in the packaging. Please refer to the separate assembly manual for a complete list of components and step-by-step instructions.

Note: Assembly is required for this product. It is recommended to have two people for assembly to ensure stability and ease of construction.



Image: The vidaXL Corner Desk shown in its straight configuration, ready for assembly.

OPERATING INSTRUCTIONS

Adjusting the Desk Configuration

The vidaXL Corner Desk features a unique rotatable design, allowing you to easily switch between a straight desk and a corner desk setup. This adaptability makes it suitable for various room layouts and space requirements.

1. **Straight Desk Configuration:** To use the desk in a straight line, align the two main sections end-to-end. Ensure the connecting points are stable and the desk is fully extended.
2. **Corner Desk Configuration:** To transform the desk into a corner unit, gently rotate one section of the desk relative to the other until it forms an 'L' shape. The rotating mechanism is designed for smooth movement. Ensure the desk is stable in its new configuration before placing items on it.



Image: The desk configured as a straight unit, displaying its ample surface and storage shelves.



Image: The desk configured as a corner unit, demonstrating its space-saving L-shape and integrated storage.

Utilizing Storage

The desk features spacious open compartments designed for convenient storage of books, files, office supplies, and other useful items, keeping them within easy reach.

MAINTENANCE

Cleaning

The engineered wood material of this desk is easy to clean. Simply wipe the surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.

General Care

- Avoid exposing the desk to excessive moisture or direct sunlight for prolonged periods.
- Use coasters or mats under hot or wet items to protect the surface.
- Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary.



Image: A close-up view of the smoked oak engineered wood texture, highlighting the durable and easy-to-clean surface.

TROUBLESHOOTING

If you encounter any issues with your vidaXL Corner Desk, please review the assembly manual for common solutions. For problems not addressed in the manual, or if you require further assistance, please contact vidaXL customer support.

- **Desk feels wobbly:** Ensure all screws and fasteners are securely tightened. Verify the desk is placed on a level surface.
- **Difficulty rotating sections:** Check for any obstructions or debris in the rotating mechanism. Ensure the desk is not overloaded.

SPECIFICATIONS

Brand	vidaXL
-------	--------

Material	Engineered Wood
Color	Smoked Oak
Dimensions (Straight)	78.7" (L) x 19.7" (W) x 29.9" (H) / 200 cm (L) x 50 cm (W) x 76 cm (H)
Dimensions (Corner)	47.2" (L) x 47.2" (W) x 29.9" (H) / 120 cm (L) x 120 cm (W) x 76 cm (H)
Assembly Required	Yes
Room Type	Home Office, Study, Bedroom




Image: A technical diagram illustrating the dimensions of the vidaXL Corner Desk in its straight configuration.

WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain support for your vidaXL Corner Desk, please visit the official vidaXL website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

vidaXL Customer Service: Please refer to the contact information provided with your product packaging or on the official vidaXL website (www.vidaxl.com).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BVR589ZM>

More documents and user manuals: **<https://manuals.plus/>**