Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luqeeg Luqeeg2h65obewvz

Luqeeg 4G LTE USB Portable Router User Manual

Model: Luqeeg2h65obewvz

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your Luqeeg 4G LTE USB Portable Router. Please read this manual thoroughly before operating the device to ensure optimal performance and safety.
The Luqeeg 4G LTE USB Portable Router is designed to provide high-speed internet access on the go, functioning as both a portable Wi-Fi hotspot and a USB modem. It supports 3G and 4G networks and can share internet connectivity with up to 8 devices simultaneously.

2. Package Contents

- 1 x Luqeeg 4G Router
- 1 x User Manual

Note: A Micro SIM Card is not included and must be purchased separately.

3. Specifications

Feature	Description
Model	Luqeeg2h65obewvz
Material	ABS
Color	White
USB Port	Standard USB
SIM Card Slot	Micro SIM Card Slot
Max Rate	150Mbps
4G Speed	150Mbps Downlink

Feature	Description
4G LTE FDD Bands	1/3/5/7/8/20
LTE TDD Bands	38/40/41
WCDMA UMTS Bands	B1/B8
Wi-Fi Standard	IEEE802.11b/g/n
Wi-Fi Range	Approx. 5 to 10 meters (5.5 to 10.9 yards)
Supported Connections	Up to 8 Wi-Fi devices + 1 USB user
Compatible Devices	Tablet, Laptop, Phone
Operating System	ZyNOS (Internal OS)
Security Protocol	WPS
Item Weight	1.27 ounces
Package Dimensions	4.33 x 2.76 x 0.79 inches

4. Safety Information

Please observe the following safety precautions:

- Keep the device away from water and moisture.
- Do not expose the device to extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Store the product separately from children's toys and other items to avoid accidental ingestion or choking.



Figure 4.1: Multilingual warning label indicating to store the product away from children's toys to prevent accidental ingestion or choking.

5. Setup Guide

Follow these steps to set up your 4G LTE USB Portable Router:

1. **Open the Device:** Gently push down on the back cover of the router to remove it.





Figure 5.1: The router with its back cover removed, showing the internal Micro SIM card slot.

2. **Insert SIM Card:** Insert your Micro SIM card into the designated slot with the card core facing down. Ensure it is securely seated.



Figure 5.2: Inserting the Micro SIM card into the router.

3. **Connect to Power:** Plug the USB port of the router into a power supply. This can be a USB wall adapter, a power bank, or a computer's USB port.



Figure 5.3: The Luqeeg 4G LTE USB Portable Router, ready to be plugged into a USB power source.

4. **Power On:** The device will automatically power on once connected to a power source. The indicator lights will illuminate.

6. Operating Instructions

6.1. Connecting to Wi-Fi

1. Ensure the 4G Router is powered on.
2. On your device (tablet, laptop, phone), search for available Wi-Fi networks.
3. Select the Wi-Fi network name (SSID) broadcast by the router. The default SSID and password can usually be found on a label inside the device or in the accompanying documentation.
4. Enter the Wi-Fi password when prompted.
5. Once connected, you will be able to access the internet.



Figure 6.1: The router providing network access, capable of supporting up to 8 users simultaneously.

6.2. Accessing Router Settings

To customize your network settings, such as Wi-Fi name (SSID) and password, follow these steps:

1. Connect your device to the router's Wi-Fi network.
2. Open a web browser on your connected device.
3. Enter the router's default IP address (usually printed on the device or in the manual) into the browser's address bar and press Enter.

4. Log in using the default username and password (also typically found on the device or in the manual).
5. From the administration panel, you can modify settings such as Wi-Fi name, password, and APN (Access Point Name) settings if required by your SIM card provider.



Figure 6.2: The router highlighting its plug-and-play feature and Micro SIM card slot for easy setup.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight.
- **Software Updates:** Periodically check the manufacturer's website or the router's administration panel for any available firmware updates to ensure optimal performance and security.

8. Troubleshooting

Problem	Possible Cause	Solution
No internet connection	SIM card not inserted correctly or not activated. No data plan. Incorrect APN settings.	◦ Ensure SIM card is properly inserted and activated with a data plan. ◦ Verify APN settings in the router's administration panel match your carrier's requirements. ◦ Restart the router by unplugging and re-plugging it.
Cannot connect to Wi-Fi	Incorrect Wi-Fi password. Router not powered on. Wi-Fi signal too weak.	◦ Double-check the Wi-Fi password. ◦ Ensure the router is powered on and indicator lights are active. ◦ Move closer to the router to improve signal strength.
Slow internet speed	Weak 4G signal. Too many connected devices. Network congestion.	◦ Relocate the router to an area with better 4G signal reception. ◦ Disconnect unnecessary devices from the Wi-Fi network. ◦ Contact your mobile carrier to inquire about network status.
Cannot access router settings page	Incorrect IP address. Not connected to router's Wi-Fi. Browser issues.	◦ Verify the router's IP address. ◦ Ensure your device is connected to the router's Wi-Fi network. ◦ Try a different web browser or clear browser cache.

9. Warranty and Support

For warranty information and technical support, please refer to the documentation provided at the time of purchase or visit the official Luqeeg website. Keep your purchase receipt as proof of purchase for warranty claims.
You can also visit the Luqeeg Store on Amazon for more product information and support resources.

© 2023 Luqeeg. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVRFJFXB

More documents and user manuals: **https://manuals.plus/**