

DIZO DA2106

DIZO Earphones with HD Mic (Model DA2106) User Manual

Wired In-Ear Headset

INTRODUCTION

The DIZO Earphones with HD Mic (Model DA2106) are designed to provide a clear audio experience for music listening and calls. Featuring an 11.2mm dynamic driver for enhanced bass and a built-in HD microphone for clear communication, these wired in-ear earphones are equipped with a tangle-free cable and a 90-degree angle audio jack for durability and ease of use.

PACKAGE CONTENTS

Please verify that all items are present in the package:

- DIZO Earphones (Model DA2106)
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your DIZO Earphones.



Image 1: Overview of DIZO Earphones, illustrating the earbuds, in-line remote control, and 3.5mm audio jack.

- **Earbuds:** Designed for in-ear comfort and sound delivery.
- **In-line Remote Control:** Integrated into the cable for easy access to functions.
- **HD Microphone:** Located on the in-line remote for clear voice capture during calls.
- **Tangle-Free Cable:** Durable cable designed to resist tangling.
- **90-Degree Angle Audio Jack:** A 3.5mm connector designed for reduced strain and enhanced durability when plugged into devices.



Image 2: Detailed view of the in-line remote control and the 90-degree 3.5mm audio jack.

90° Angle Audio Jack




Image 3: Focus on the 90-degree angle audio jack, highlighting its design for durability.

SETUP

Connecting your DIZO Earphones is a straightforward process:

1. **Identify the Audio Port:** Locate the 3.5mm audio jack on your device (e.g., smartphone, laptop, tablet). This port is typically marked with a headphone icon.
2. **Insert the Jack:** Gently insert the 3.5mm audio jack of the DIZO Earphones into your device's audio port until it is fully seated. The 90-degree angle design helps reduce stress on the cable.
3. **Adjust Earphones:** Place the earbuds comfortably into your ears. Ensure a snug fit for optimal sound quality and bass response.
4. **Test Audio:** Play some audio from your device to confirm that the earphones are working correctly. Adjust the volume on your device as needed.

OPERATING INSTRUCTIONS

The in-line remote control allows for easy management of audio playback and calls.

Fashionable Design



Image 4: Various angles of the earphones, highlighting the in-line remote for control.

- **Play/Pause Music:** Press the multi-function button on the in-line remote once to play or pause the current audio track.
- **Next Track:** Press the multi-function button twice quickly to skip to the next track.
- **Previous Track:** Press the multi-function button three times quickly to go back to the previous track.
- **Answer/End Call:** Press the multi-function button once to answer an incoming call or end an active call.
- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds to reject an incoming call.
- **Activate Voice Assistant:** Press and hold the multi-function button for approximately 2 seconds (when not on a call) to activate your device's voice assistant (e.g., Google Assistant, Siri).

Note: Volume control is managed directly through your connected device.

MAINTENANCE

Proper care ensures the longevity and performance of your earphones.

- **Cleaning:**

- Gently wipe the earbuds and cable with a soft, dry, lint-free cloth.
 - For ear tips, remove them and clean with a mild soap solution if necessary, then rinse thoroughly and ensure they are completely dry before reattaching.
 - Do not use harsh chemicals, abrasive cleaners, or solvents.
- **Storage:**
 - Store the earphones in a clean, dry place when not in use.
 - Avoid extreme temperatures and direct sunlight.
 - Do not wrap the cable too tightly to prevent damage. The tangle-free design helps with neat storage.
 - **Handling:**
 - Avoid pulling the cable forcefully when disconnecting from a device; always grasp the 3.5mm jack.
 - Do not expose the earphones to water or excessive moisture. While they have some water repellency, they are not waterproof.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Solution
No sound from earphones.	• Ensure the 3.5mm jack is fully inserted into the device's audio port. • Check the volume level on your connected device. • Test the earphones with another device to rule out a device-specific issue. • Inspect the cable and jack for any visible damage.
Microphone not working during calls.	• Ensure the 3.5mm jack is fully inserted. • Verify that your device's microphone settings are configured to use the external headset microphone. • Test with another device or application to confirm microphone functionality.
Sound quality is poor or distorted.	• Ensure the earbuds are properly seated in your ears for a good seal. • Check the audio source for quality issues. • Clean the ear tips and speaker grilles to remove any debris. • Reduce the volume on your device if distortion occurs at high levels.

SPECIFICATIONS

Key technical specifications for the DIZO Earphones (Model DA2106):

Feature	Detail
Model Number	DA2106
Driver Size	11.2mm Dynamic Driver
Ear Placement	In Ear
Connectivity	Wired (3.5mm Jack)
Impedance	28 Ohms
Frequency Response	20000 KHz
Sensitivity	106 dB
Microphone	HD Microphone Included
Cable Features	Tangle Free
Audio Jack Angle	90-degree
Weight	14 Grams
Material	Plastic
Compatible Devices	Cellphones, Laptops, Telephones
Water Resistance Level	Water Repellent

11.2mm Dynamic Driver




Image 5: Illustration of the 11.2mm Dynamic Driver, responsible for audio output.

Excellent Bass Performance



Image 6: Visual representation of the earphones' capability for excellent bass performance.

Tangle Free Cable




Image 7: Detail of the tangle-free cable, designed for durability and ease of use.

WARRANTY AND SUPPORT

DIZO provides a limited warranty for this product.

- **Warranty Period:** 12 months from the date of purchase.
- **Warranty Service:** For warranty claims or technical support, please carry the product to an authorized service center.
- **Contact Information:**
 - Email: service.in@dizo.net
 - Toll-Free Number: [1800 843 3030](tel:18008433030)

Please retain your proof of purchase for warranty validation.