



[Manuals.plus](#) /

› [PHILIPS](#) /

› PHILIPS 55-Inch Class 4K 2160p Smart LED TV User Manual

PHILIPS 55PUL7552/F7

PHILIPS 55-Inch Class 4K 2160p Smart LED TV User Manual

Model: 55PUL7552/F7

1. INTRODUCTION

Welcome to your new PHILIPS 55-Inch Class 4K 2160p Smart LED TV. This television, model 55PUL7552/F7, is designed to provide an immersive entertainment experience with its 4K Ultra HD resolution and smart features. It integrates Google TV, allowing you to access movies, shows, live TV, and various applications seamlessly. With built-in Google Assistant, Chromecast, and Bluetooth connectivity, this TV offers a comprehensive and user-friendly platform for all your media needs.

Key features include:

- **4K Ultra HD (2160p resolution):** Experience stunning visuals with four times the resolution of Full HD, and enjoy upscaling of existing content to near-4K quality.
- **Smart TV with access to streaming services:** Instantly access popular apps like Netflix, Disney+, YouTube, and many more directly on your TV.
- **Google Assistant Built-in:** Use voice commands via the remote to change channels, control volume, search for content, and manage smart home devices.
- **Bluetooth connectivity:** Wirelessly connect compatible soundbars, headphones, or other stereo components.
- **Chromecast Built-in:** Easily cast movies, shows, photos, and more from your mobile device to your TV screen.



Figure 1.1: Front view of the Philips 55-inch Google TV with its smart interface.

This image shows the television powered on, displaying the Google TV home screen. The screen is filled with content recommendations and icons for popular streaming services such as YouTube, Disney+, Apple TV, HBO Max, Peacock, and Spotify. The Philips logo is visible on the bottom left bezel.

2. WHAT'S IN THE BOX

Upon opening the package, please ensure all the following components are present:

- PHILIPS 55-Inch 4K Smart LED TV (Model: 55PUL7552/F7)
- Remote Control
- TV Stand (2 pieces)
- Power Cord
- Quick Start Guide (not included in this manual)
- Screws for Stand Assembly

3. SETUP

3.1 Attaching the TV Stand

Carefully place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand pieces with the designated slots on the bottom of the TV. Secure them using the provided screws.



Figure 3.1: Philips TV with stand attached.

This image shows the television from an angled perspective, resting on its two black stand feet. The screen displays the Google TV interface, similar to Figure 1.1, highlighting the TV's readiness for use after stand assembly.


3.2 Connecting Power and Devices

After attaching the stand or mounting the TV, connect the power cord to the TV's power input and then to a wall outlet. Connect your external devices such as cable boxes, gaming consoles, or Blu-ray players to the appropriate ports.




Figure 3.2: Rear view of the TV with input ports.

This image displays the back panel of the Philips TV, highlighting the arrangement of its connectivity ports. Visible ports include multiple HDMI inputs, USB ports, digital audio out, and an Ethernet port, indicating various connection possibilities for external devices.



*Product features, functionality and design are subject to change without notice.

55PUL7552 Connectivity



- USB x1
- HDMI x3
- Digital Audio Out
- Headphone
- Audio / Video
- Antenna in
- LAN

Figure 3.3: TV Dimensions and Connectivity Diagram.

This graphic provides key dimensions of the 55-inch Philips TV, including width (49.2 inches), height (30.6 inches), and depth (11.0 inches with stand). It also features a detailed diagram of the connectivity panel, listing available ports: USB x1, HDMI x3, Digital Audio Out, Headphone, Audio/Video, Antenna in, and LAN.

Available ports include:

- USB x1
- HDMI x3
- Digital Audio Out
- Headphone
- Audio / Video
- Antenna in
- LAN (Ethernet)


3.3 Initial Setup and Network Connection

Upon first power-on, the TV will guide you through the initial setup process. This includes selecting your language, connecting to a Wi-Fi network (or using the LAN port), and signing in with your Google account to enable full Google TV functionality.

4. OPERATING YOUR TV

4.1 Remote Control Functions

The included remote control provides access to all TV functions. Familiarize yourself with the button layout for easy navigation.



Use your voice to find movies, stream apps, and control your TV. Just press the Google Assistant button on the remote.

Try saying,

- “Find action movies.”
- “Turn on the TV.”
- “Show me the front door camera.”




Figure 4.1: Philips TV Remote Control.

This image displays the Philips TV remote control, emphasizing its Google Assistant integration. The remote features a dedicated Google Assistant button, along with standard navigation, volume, channel, and input controls. Example voice commands like "Find action movies," "Turn on the TV," and "Show me the front door camera" are shown, illustrating the voice control capabilities.

4.2 Google TV Interface

The Google TV interface organizes content from all your streaming services into a personalized home screen. You can browse recommendations, access your installed apps, and manage your library.

- **Home Screen:** Displays personalized recommendations, trending content, and quick access to your favorite

apps.

- **Apps:** Navigate to the "Apps" tab to view and launch all installed applications. You can download more apps from the Google Play Store.
- **Library:** Access your purchased movies and TV shows from Google Play.

4.3 Using Google Assistant

Press the dedicated Google Assistant button on your remote control to activate voice commands. Speak clearly into the remote's microphone.

Examples of commands:

- "Find action movies."
- "Open Netflix."
- "Turn up the volume."
- "What's the weather like?"
- "Play music."

4.4 Chromecast Built-in

Chromecast allows you to cast content from your compatible mobile devices (smartphones, tablets) or computer (using Chrome browser) directly to your TV.

1. Ensure your mobile device and TV are connected to the same Wi-Fi network.
2. Open a Chromecast-enabled app (e.g., YouTube, Netflix, Google Photos) on your mobile device.
3. Tap the Cast icon (▶) within the app.
4. Select your PHILIPS TV from the list of available devices.
5. The content will begin playing on your TV.

4.5 Bluetooth Connectivity

You can connect Bluetooth-enabled devices such as headphones or soundbars to your TV for wireless audio.

1. Go to the TV's Settings menu.
2. Navigate to "Remotes & Accessories" or "Bluetooth Settings."
3. Enable Bluetooth on the TV and put your Bluetooth device into pairing mode.
4. Select your device from the list of available devices on the TV screen to pair.

5. MAINTENANCE

Proper care and maintenance will extend the life of your television.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasives, or alcohol-based cleaners.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked. Allow adequate space around the TV for proper airflow.
- **Power Off:** When not in use for extended periods, it is recommended to unplug the TV from the power outlet.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions before contacting support.

| Problem | Possible Cause / Solution |
|---|---|
| No Power | Ensure the power cord is securely plugged into the TV and the wall outlet. Check if the wall outlet is working by plugging in another device. Press the power button on the TV itself, not just the remote. |
| No Picture, But Sound is Present | Check the input source. Press the "Input" button on your remote to cycle through inputs. Ensure the connected device (cable box, DVD player) is powered on and functioning correctly. Try restarting the TV by unplugging it for a few minutes and plugging it back in. |
| No Sound, But Picture is Present | Check the volume level on the TV and any connected audio devices. Ensure the TV is not muted. Check audio cables for secure connection. If using external audio, ensure the correct audio output setting is selected on the TV. |
| Remote Control Not Working | Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor. If it's a Bluetooth remote, try re-pairing it with the TV (refer to section 4.1). |
| Wi-Fi Connection Issues | Ensure your Wi-Fi router is on and functioning. Restart your router and modem. Go to the TV's network settings and try reconnecting to your Wi-Fi network. Consider using a wired (LAN) connection if Wi-Fi remains unstable. |

7. SPECIFICATIONS

Detailed technical specifications for the PHILIPS 55PUL7552/F7 TV:

| Feature | Detail |
|---------------------------|--|
| Brand | PHILIPS |
| Model Number | 55PUL7552/F7 |
| Screen Size | 55 Inches (140 cm diagonal) |
| Display Technology | LED |
| Resolution | 4K Ultra HD (2160p) |
| Refresh Rate | 60 Hz |
| Aspect Ratio | 16:9 |
| Operating System | Google TV |
| Special Features | Chromecast Built-in, Google Assistant Built-in |

| Feature | Detail |
|--------------------------------|---|
| Connectivity Technology | Bluetooth, Wi-Fi, Ethernet |
| Input Ports | 3x HDMI, 1x USB, Digital Audio Out, Headphone, Audio/Video, Antenna in, LAN |
| Product Dimensions (D x W x H) | 3"D x 49.2"W x 28.5"H (without stand) / 11.0"D (with stand) |
| Item Weight | 31.7 pounds |
| Voltage | 120 Volts |
| Included Components | Remote, Stand, TV |

8. WARRANTY AND SUPPORT

This product is listed as "Renewed." Renewed products typically come with a specific warranty provided by the seller or the Amazon Renewed program.

- **Return Policy:** This product is eligible for a 90-day refund/replacement return policy from the date of purchase. Please refer to the Amazon Renewed program terms for full details.
- **Technical Support:** For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Philips customer support or the seller from whom you purchased this renewed product. Contact information can typically be found on the Philips official website or through your Amazon order details.