

[Manuals.plus](#) /

› [Funsicle](#) /

› Funsicle Oasis Designer 13' x 7' x 39.5" Rectangular Above Ground Swimming Pool Set Instruction Manual

Funsicle 325411880

Funsicle Oasis Designer 13' x 7' x 39.5" Rectangular Above Ground Swimming Pool Set Instruction Manual

Brand: Funsicle

Model: 325411880

PRODUCT OVERVIEW

The Funsicle Oasis Designer 13' x 7' x 39.5" Rectangular Above Ground Swimming Pool Set is designed for backyard aquatic recreation. It includes a 2-in-1 SkimmerPlus Filter Pump for water circulation and filtration, a sturdy frame with ultra-strong oval poles, and a durable 3-ply Toughmesh liner. Essential accessories like a SureStep ladder and a repair patch are provided for convenient setup and maintenance.



Image: Funsicle Oasis Designer 13' x 7' Rectangular Above Ground Swimming Pool Set, showcasing its dark herringbone gray pattern, included ladder, and integrated filter pump.




Image: The FunSicle Oasis Designer pool in a backyard setting, demonstrating its rectangular shape and capacity for multiple users.

SETUP INSTRUCTIONS

Proper setup is crucial for the longevity and safe operation of your pool. Please follow these steps carefully.

1. Site Preparation

Select a flat, firm, and level ground surface for pool installation. Ensure the area is free from any stones, sharp objects, or loose ground that could damage the liner. If using a filtration system, position the pool 10-21 feet away from the power outlet.

Installation Guide

QUICK AND SIMPLE DIY

STEP
01

PREPARE THE SITE

Choose a flat, firm, and level surface, avoiding sand or sharp objects. Position the pool 10-21 feet from the outlet for filtration systems.



STEP
02

ASSEMBLE THE POOL

Assemble the frame and T-fittings, then vertical legs and leg caps. Ensure the liner is securely connected to the frame.

STEP
03

ADD WATER

Fill the pool with one inch of water and smooth out the wrinkles to ensure a taut liner.



STEP
04

INSTALL THE FILTRATION SYSTEM

Install suction and return fittings, hoses, and the filtration system as per your pool's instructions. Check water levels and chemical balance for a safe swim. Enjoy!

Image: Step 1 of the installation guide, illustrating the importance of preparing a clean, level site for the pool.

Your browser does not support the video tag.

Video: FunSicle Oasis Pool Tutorial - Site Preparation. This segment demonstrates how to choose and prepare a firm, level ground, free of sharp objects, and the recommended distance from a power outlet for the filtration system.

2. Pool Assembly

Unfold the pool liner on the prepared site. If you have a ground cloth, lay it down first. Allow the liner to warm in the sun for approximately two hours to make it more pliable. Assemble the frame by inserting horizontal beams into T-fittings, ensuring pins snap securely into place. Push the assembled sets through the top liner sleeves. Connect the easy-link T-fitting with the last

horizontal beam. Insert foot pads onto the vertical legs and carefully slide the vertical legs through the liner belt, snapping them to each T-fitting. Ensure all frame pins are securely snapped.

FunSicle

Installation Guide

QUICK AND SIMPLE DIY

STEP
01

PREPARE THE SITE

Choose a flat, firm, and level surface, avoiding sand or sharp objects. Position the pool 10-21 feet from the outlet for filtration systems.



STEP
02

ASSEMBLE THE POOL

Assemble the frame and T-fittings, then vertical legs and leg caps. Ensure the liner is securely connected to the frame.

STEP
03

ADD WATER

Fill the pool with one inch of water and smooth out the wrinkles to ensure a taut liner.



STEP
04

INSTALL THE FILTRATION SYSTEM

Install suction and return fittings, hoses, and the filtration system as per your pool's instructions. Check water levels and chemical balance for a safe swim. Enjoy!

Image: Step 2 of the installation guide, illustrating the process of assembling the pool frame and attaching the liner.



Image: Detail of the SmartConnect snap-in frame, showing how the oval-shaped poles connect for swift setup.



Image: Diagram illustrating the durable 3-ply liner construction, featuring heavy gauge PVC and polyester mesh for resistance against punctures.

Your browser does not support the video tag.

Video: Funsicle Oasis Pool Tutorial - Pool Assembly. This segment provides a visual guide on laying out the liner, assembling the frame components, and securing the vertical legs to stand up the pool structure.

3. Adding Water

Fill the pool with approximately one inch of water. Stop the water flow and carefully push out any remaining floor wrinkles to ensure the liner is taut and smooth all around. This helps prevent stress on the liner as the pool fills completely. Continue filling the pool, checking occasionally to ensure it fills evenly and adjusting as needed. Do not overfill the pool; the water level should be approximately 6 inches below the top rim.

Installation Guide

QUICK AND SIMPLE DIY

STEP 01

PREPARE THE SITE

Choose a flat, firm, and level surface, avoiding sand or sharp objects. Position the pool 10-21 feet from the outlet for filtration systems.



STEP 02

ASSEMBLE THE POOL

Assemble the frame and T-fittings, then vertical legs and leg caps. Ensure the liner is securely connected to the frame.

STEP 03

ADD WATER

Fill the pool with one inch of water and smooth out the wrinkles to ensure a taut liner.



STEP 04

INSTALL THE FILTRATION SYSTEM

Install suction and return fittings, hoses, and the filtration system as per your pool's instructions. Check water levels and chemical balance for a safe swim. Enjoy!

Image: Step 3 of the installation guide, demonstrating the initial filling of the pool and smoothing out the liner.

Your browser does not support the video tag.

Video: FunSicle Oasis Pool Tutorial - Adding Water. This segment shows how to add the initial inch of water to smooth out wrinkles and then continue filling the pool to the recommended level.

4. Filtration System Installation

If your pool includes or is compatible with a filtration system, install it according to the specific user guide for your model. For the SFX600 SkimmerPlus Filter Pump, locate the inlet and outlet holes on your pool. Disassemble the skimmer seal ring and re-thread it onto the skimmer through the wall opening. Disassemble the return fitting assembly from the inside of the pool and insert it with

the fitting gasket. On the outside, place the thrust washer on the fitting, followed by the fitting nut (hand-tighten only). Install a hose clamp on each end of the hose. Attach one end of the hose to the skimmer and the other end to the return fitting, ensuring hose clamps are tightened directly over the O-rings.

FunSicle

Installation Guide

QUICK AND SIMPLE DIY

STEP
01

PREPARE THE SITE

Choose a flat, firm, and level surface, avoiding sand or sharp objects. Position the pool 10-21 feet from the outlet for filtration systems.



STEP
02

ASSEMBLE THE POOL

Assemble the frame and T-fittings, then vertical legs and leg caps. Ensure the liner is securely connected to the frame.

STEP
03

ADD WATER

Fill the pool with one inch of water and smooth out the wrinkles to ensure a taut liner.



STEP
04

INSTALL THE FILTRATION SYSTEM

Install suction and return fittings, hoses, and the filtration system as per your pool's instructions. Check water levels and chemical balance for a safe swim. Enjoy!

Image: Step 4 of the installation guide, detailing the components and process for installing the filtration system.

Includes our exclusive 2 in 1 side-mounted SkimmerPlus® filter pump



1. Skimmer basket picks up debris, leaves & insects



2. Filter cartridge captures small particles



Look for
Funicle filters
Type

D

Combines the functions of a skimmer & filter pump in one unit
Filter pump attaches to pool sidewall for easy maintenance
and efficient space

Image: Detailed diagram of the Funicle SkimmerPlus Filter Pump, explaining its two-stage filtration process: skimmer basket for debris and filter cartridge for small particles.



Image: Close-up view of the JetMaxx Aeration feature, which helps to provide cleaner, purer water by introducing air into the pool.

Your browser does not support the video tag.

Video: Funsicle Oasis Pool Tutorial - Filtration System Assembly. This segment details the installation of the SkimmerPlus Filter Pump, including connecting hoses and ensuring proper seals.

OPERATING THE POOL


Once the pool is filled and the filtration system (if applicable) is installed, you can begin enjoying your Funsicle Oasis pool. Ensure the water level is maintained at the recommended height (approximately 6 inches below the top rim) to allow the skimmer to function effectively.

Includes our exclusive 2 in 1 side-mounted SkimmerPlus® filter pump

Oasis Designer Lap Pool Set Features:

Durable puncture-resistant liner

3-layered: Polyester mesh
between heavy gauge
PVC materials



SureStep™ ladder

Convenient in &
out access

Combines the functions of a skimmer & filter pump in one unit

Filter pump attaches to pool sidewall for easy maintenance
and efficient space

Image: The Funsicle Oasis Designer pool featuring the SureStep ladder for easy access and the side-mounted SkimmerPlus filter pump.

Filter Pump Operation

The SFX600 SkimmerPlus Filter Pump is designed to provide continuous water circulation and filtration. If your pump is equipped with a GFCI power cord, it may have a daily timer function. If the pump does not turn on immediately after plugging in, do not worry. The pump's power is controlled by a daily timer that can be configured through the 'Set' button. Refer to your pump's user

guide for detailed instructions on setting the timer and troubleshooting power issues.

Your browser does not support the video tag.

Video: Funsicle Oasis Pool Tutorial - GFCI Power Cord and Timer. This segment explains the functionality of the GFCI power cord and how to use the timer settings for the filter pump.

MAINTENANCE

Regular maintenance is essential to keep your pool water clean and safe for use.

Water Chemistry

Use a pool test strip to regularly monitor and ensure the pH and chlorine levels are within a healthy range. Proper chemical balance prevents algae growth and keeps the water clear. Consult your pool chemical supplier for specific dosage recommendations based on your pool's volume and usage.

Your browser does not support the video tag.

Video: Funsicle Oasis Pool Tutorial - Water Chemistry. This segment highlights the importance of using a pool test strip to maintain balanced pH and chlorine levels for healthy pool water.

Cleaning

Regularly remove debris from the skimmer basket and clean or replace the filter cartridge as needed. Skim the surface of the pool daily to remove leaves and other floating debris. Vacuum the pool floor periodically to prevent buildup of dirt and sediment.

TROUBLESHOOTING

- Pump Not Operating:** If the filter pump does not turn on, check the GFCI power cord. It may have a built-in timer that needs to be reset or configured. Refer to your pump's user guide for specific instructions.
- Water Leaks:** Ensure all connections for the filtration system (if applicable) are securely tightened. Check the pool liner for any punctures or tears. A repair patch is included for minor damages.
- Uneven Pool Filling:** During the initial filling, ensure the liner is taut and smooth. Adjust the water distribution as the pool fills to prevent uneven pressure on the frame.

SPECIFICATIONS

Feature	Detail
Product Dimensions	156 x 84 x 39.5 inches (13' x 7' x 39.5")
Model Number	325411880
Brand	Funsicle
Liner Material	Durable 3-ply Toughmesh (PVC and polyester mesh)
Frame Material	Ultra-strong oval poles with matte finish
Filter Pump	SFX600 SkimmerPlus Filter Pump with JetMaxx Aeration
Included Accessories	Type D filter cartridge, SureStep ladder, repair patch



Image: The Funsicle Oasis Designer pool, highlighting its 40-inch height.

WARRANTY INFORMATION

The Funsicle Oasis Designer Pool Set comes with a **1-year manufacturer warranty** covering the pool, pump, and ladder. Please retain your proof of purchase for warranty claims.

SUPPORT AND CONTACT INFORMATION

For further assistance or inquiries regarding your Funsicle Oasis Designer Pool Set, please use the following contact methods:

- **Website Support:** Visit funsicle.com/support
- **Phone:** 888-670-4FUN (888-670-4386)
- **Email:** HelloFun@Funsicle.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question