

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Funsicle](#) /

› Funsicle 12' x 30" Round Metal Frame Above Ground Pool with SkimmerPlus Filter Pump Instruction Manual

## Funsicle 12ft x 30in SkimmerPlus Pump

# Funsicle 12' x 30" Round Metal Frame Above Ground Pool with SkimmerPlus Filter Pump

Instruction Manual

### IMPORTANT SAFETY INFORMATION

---

Read and understand all instructions before installing and using this product. Failure to follow these warnings and instructions can result in serious injury or death. This manual contains important information about the installation, operation, and maintenance of your Funsicle above ground pool. Keep this manual for future reference.

- Adult supervision is required at all times when children are in or near the pool.
- Never dive or jump into the pool. The pool depth is 30 inches, which is not suitable for diving.
- Ensure the pool is set up on a level surface to prevent structural failure and water spillage.
- Keep children away from the filter pump and electrical connections.
- Do not sit, stand, or climb on the pool frame.

### PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- Round Pool Liner (12 ft diameter, 30 inches tall)
- Metal Frame Poles and Connectors
- SkimmerPlus SFX330 Filter Pump (110-120V)
- Type I Filter Cartridge
- Hoses and Clamps for Pump Connection
- Drainage Plug

### SETUP INSTRUCTIONS

---

Follow these steps for proper pool assembly and installation:

1. **Site Preparation:** Choose a firm, level surface free of debris. Lay a ground cloth or tarp (not included) to protect the pool liner.
2. **Frame Assembly:** Assemble the metal frame poles by snapping them into place with the provided lock pins. Ensure all connections are secure.
3. **Liner Installation:** Carefully spread the durable 3-ply ToughMesh pool liner within the assembled frame. Ensure the drain


plug is securely closed.

4. **Partial Filling:** Begin filling the pool with water. As the water level rises, smooth out any wrinkles in the bottom of the liner.
5. **SkimmerPlus Filter Pump Installation:** Attach the SkimmerPlus SFX330 filter pump to the sidewall of the pool according to the pump's specific instructions. Ensure all hoses are securely connected and clamps are tightened.
6. **Complete Filling:** Continue filling the pool to the recommended water level, typically just below the top rail.

## Activity™ Pool Set Features:



**Strong & sturdy metal frame**  
Easy setup with lock pins



**Durable puncture-resistant liner**  
3-layered: Polyester mesh  
between heavy gauge  
PVC materials

Image: Overview of the FunSicle pool highlighting its strong metal frame and durable liner construction.

## Just as easy to disassemble

2-in-1 drainage plug for convenient  
lock and unlock, no tools required



Image: Detail of the snap-in-place metal frame poles for easy assembly.

## OPERATING THE SKIMMERPLUS FILTER PUMP

---

The SkimmerPlus SFX330 filter pump is designed to keep your pool water clean and clear. It combines a skimmer and a filter pump into one unit.

- The skimmer basket collects larger debris such as leaves and insects from the water surface.
- The Type I filter cartridge captures small particles as water passes through the pump.
- The pump features an automatic timer to operate for a set duration, ensuring consistent filtration without manual intervention.

## Includes our exclusive 2 in 1 side-mounted SkimmerPlus® filter pump



1. Skimmer basket picks up debris, leaves & insects



2. Filter cartridge captures small particles



Look for  
Funsicle filters  
Type



Combines the functions of a skimmer & filter pump in one unit  
Filter pump attaches to pool sidewall for easy maintenance  
and efficient space

Image: Internal view of the SkimmerPlus pump showing debris collection and filtration process.



Image: The SkimmerPlus filter pump and a Type I replacement filter cartridge.



Image: Clean, filtered water returning to the pool.

## MAINTENANCE

---

Regular maintenance is crucial for extending the life of your pool and ensuring clean water.

- **Filter Cartridge Cleaning/Replacement:** The Type I filter cartridge should be rinsed daily with a power hose to remove debris. Replace the cartridge every two weeks or sooner if heavily soiled.
- **Skimmer Basket Cleaning:** Periodically empty the skimmer basket to ensure optimal debris collection.
- **Water Chemistry:** Regularly test and adjust pool water chemistry (pH, chlorine levels) using appropriate pool chemicals (not included) to prevent algae growth and maintain water quality.
- **Draining the Pool:** When preparing to store the pool, use the 2-in-1 drainage plug located at the bottom of the pool liner. Unscrew the cap to allow water to drain easily.

# Value

## SureStep™ ladder

Easy pool access in and out

## CP2000 Cartridge Filter Pump

Effective cartridge filter pump keeps pool water sparkling clean



## Optional matching accessories

Maintenance kits, pool covers & more to elevate your experience



*Images are for reference only. Actual model may vary.*

Image: The 2-in-1 drainage plug for convenient water removal.

## TROUBLESHOOTING

If you encounter issues with your Funsicle pool, refer to the following common problems and solutions:

- **Weak Pump Flow:** Ensure the filter cartridge is clean and free of debris. Check for any blockages in the hoses or skimmer basket. Verify the pump is properly connected and receiving power.
- **Water Leaks:** Inspect the pool liner for any punctures or tears. Check all hose connections and the drainage plug for tightness. Ensure the pool is on a level surface, as uneven ground can stress the liner and frame, potentially causing leaks.
- **Cloudy Water:** This often indicates insufficient filtration or improper water chemistry. Clean or replace the filter cartridge, ensure the pump runs for adequate periods, and test/adjust water chemical levels.

## SPECIFICATIONS

Feature	Detail
Brand	Funsicle
Model	12ft x 30in SkimmerPlus Pump
Capacity	1718 Gallons
Product Dimensions	144"L x 30"W x 144"H (12' x 30")
Shape	Round
Material Type	Metal (Frame), 3-ply ToughMesh (Liner)
Included Components	Filter Pump, Skimmer, Filter Cartridge
UPC	195545003170

## WARRANTY AND SUPPORT

Your Funsicle pool, pump, and ladder are covered by a **1-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For customer service, technical support, or warranty inquiries, please contact Funsicle directly:

**Phone:** (888) 870-4388

**Website:** [support.funsicle.com](https://support.funsicle.com)



Image: Funsicle Customer Service contact details.