

Vivi Vivi Bike Lock (B0BVSY29HR)

Vivi Bike Lock User Manual

Model: Vivi Bike Lock (B0BVSY29HR)

1. INTRODUCTION

This user manual provides comprehensive instructions for the Vivi Bike Lock, a robust and resettable combination lock designed to secure your bicycle. Please read this manual carefully before using the product to ensure proper operation and longevity.



Figure 1: The Vivi Bike Lock in its coiled state, ready for use.

2. SAFETY INFORMATION

To ensure safe and effective use of your Vivi Bike Lock, please observe the following precautions:

- Always ensure the lock mechanism is fully engaged and the combination wheels are scrambled after locking your bicycle.
- Do not attempt to force the lock open if the combination is incorrect, as this may damage the internal mechanism.
- Keep the lock away from extreme temperatures and corrosive substances.
- This product is not a toy. Keep out of reach of children.

3. PRODUCT COMPONENTS

The Vivi Bike Lock package typically includes:

- 1 x Vivi Bike Lock Unit (Combination Cable Lock)
- 1 x Instruction Manual (this document)
- (Optional) 1 x Combination Reset Tool (if included, refer to packaging)



Figure 2: The lock head detached, showing the internal mechanism and combination wheels.

4. SETTING YOUR COMBINATION

Your Vivi Bike Lock comes with a factory preset combination, usually 00000. Follow these steps to set your personal combination:

1. **Open the Lock:** Align the factory preset combination (e.g., 00000) with the indicator marks on the lock head and pull the lock head out from the cable end.
2. **Locate the Reset Mechanism:** With the lock open, locate the reset dial or button. This is typically a small knob or lever on the side or end of the lock head.



Figure 3: Close-up view of the "SET" dial, used for resetting the combination.

3. **Engage Reset Mode:** Rotate the "SET" dial clockwise 90 degrees (or as indicated by an arrow) until it clicks into place, or push the reset button firmly.



Figure 4: The lock head showing the "SET" dial rotated to the reset position.

4. **Set New Combination:** While in reset mode, rotate the number wheels to your desired 5-digit combination. Choose a memorable combination.
5. **Disengage Reset Mode:** Rotate the "SET" dial back counter-clockwise 90 degrees (or as indicated) to its original position. This will lock in your new combination.
6. **Test New Combination:** Scramble the numbers on the wheels. Then, align your new combination and attempt to open the lock to verify it works correctly.

Important: Remember your new combination. There is no master key to open the lock if you forget it.

5. OPERATING THE LOCK

Using your Vivi Bike Lock is straightforward:

1. **To Open:** Align your personal 5-digit combination with the indicator marks on the lock head. Pull the lock head away from the cable end.



Figure 5: Detailed view of the combination wheels and the alignment indicators.

2. **To Lock:** Wrap the cable around your bicycle frame and a secure, immovable object (e.g., a bike rack, lamppost). Insert the cable end into the lock head until it clicks securely into place.
3. **Secure the Combination:** Once locked, scramble the numbers on the combination wheels to prevent unauthorized access.

6. MAINTENANCE

Proper maintenance will extend the life of your Vivi Bike Lock:

- **Cleaning:** Wipe the lock clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the internal mechanism and combination wheels to ensure smooth operation, especially if used in dusty or wet environments.
- **Storage:** Store the lock in a dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lock will not open.	Incorrect combination entered. Numbers not perfectly aligned.	Double-check your combination. Ensure each number is precisely aligned with the indicator marks. Try wiggling the wheels slightly.
Cannot set a new combination.	Reset mechanism not fully engaged. Lock not in open position.	Ensure the lock is open with the current combination. Confirm the "SET" dial is fully rotated or the reset button is fully pressed.

Problem	Possible Cause	Solution
Combination wheels are stiff.	Dirt or debris in mechanism. Lack of lubrication.	Clean the wheels and apply a small amount of silicone lubricant.

8. SPECIFICATIONS

Feature	Detail
Brand	Vivi
Model	Vivi Bike Lock (B0BVSY29HR)
Lock Type	Combination Lock
Special Feature	Anti Theft, Resettable
Material	Alloy Steel, Polyvinyl Chloride
Item Dimensions (L x W x H)	3.9 x 0.6 x 1 inches (Lock head dimensions)
Recommended Uses	Security (for bicycles)
Color	Maroon21 (as per product listing, though appears black/grey in images)
Number of Pieces	1
Finish Type	PVC

9. WARRANTY INFORMATION





Specific warranty details for the Vivi Bike Lock may vary. Please refer to the product packaging, the official Vivi website, or your point of purchase for the most accurate and up-to-date warranty information.

10. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Vivi Bike Lock, please contact Vivi customer support through their official website or the retailer from whom you purchased the product. Provide your product model (B0BVSY29HR) and a detailed description of your issue for faster assistance. For more information, visit the [Vivi Store on Amazon](#).



Related Documents

<p>E-bike User's Manual</p> 	<p>VIVI E-bike User's Manual: Installation, Operation, and Maintenance Guide</p> <p>Comprehensive user's manual for the VIVI E-bike, covering safety instructions, meter operation, battery care, charging procedures, and detailed installation steps for components like the handlebar, front wheel, pedals, seat post, and throttle.</p>
	<p>VIVI TT2020-Z3 Electric Bicycle User Manual</p> <p>Comprehensive user manual for the VIVI TT2020-Z3 electric bicycle, covering safety, assembly, operation, maintenance, troubleshooting, and specifications.</p>
	<p>Vivi Box Installation and Setup Guide</p> <p>Comprehensive guide to installing and setting up the Vivi Box wireless presentation system, covering network, display, and power connections, as well as boot-up and activation procedures. Includes FCC compliance information.</p>
	<p>VIVI 26SH Electric Bike User Manual: Operation and Installation Guide</p> <p>Comprehensive user manual for the VIVI 26SH Electric Bike, covering safety instructions, meter operation, battery care, charging, and step-by-step installation.</p>