

manuals.plus /

› [FRIZCOL](#) /

› [FRIZCOL 3-in-1 Camping Fan User Manual](#)

FRIZCOL FA-GY03

FRIZCOL 3-in-1 Camping Fan User Manual

Brand: FRIZCOL | Model: FA-GY03

INTRODUCTION

Thank you for choosing the FRIZCOL 3-in-1 Camping Fan. This versatile device combines a powerful fan, an LED light, and a portable power bank, making it an essential companion for your indoor and outdoor adventures. With its long-lasting 24000mAh battery and user-friendly features, you can enjoy comfort and convenience wherever you go. Please read this manual carefully to ensure proper use and maintenance of your fan.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Portable Rechargeable Fan
- 2 x 12000mAh Detachable Battery
- 1 x Remote Control
- 1 x User Manual (this document)
- 1 x USB-C Cable

Package Contents

- 12000mAh Detachable Battery * 2
- Portable Rechargeable Fan * 1
- Remote Control * 1
- User Manual * 1
- USB-C Cable * 1



Image: Contents of the FRIZCOL 3-in-1 Camping Fan package, including the fan, two detachable batteries, remote control, user manual, and USB-C cable.

SETUP

Battery Installation

1. Locate the battery compartment at the base of the fan.
2. Insert one or both 12000mAh detachable batteries into the designated slots, ensuring proper alignment with the charging ports. The batteries should click securely into place.

Remove the Battery

Press and push out with both hands to take out the battery



Image: Hands demonstrating how to press and push out the detachable battery from the fan's base.

Charging the Fan

Before first use, fully charge the fan's batteries. The fan is equipped with a USB-C charging port.

1. Connect the provided USB-C cable to the charging port on the fan.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a power source.
3. The charging indicator lights on the fan's base will illuminate to show charging status. A full charge typically takes 8-10 hours.

2*12000mAh Detachable Rechargeable Battery

Use for up to **140** hrs



8-10H
Fast Charging



140H
Long lasting

Note: Please note the interface needs to be aligned with the charging port.



Image: A close-up of the detachable 12000mAh battery being inserted into the fan base, highlighting its long-lasting and fast-charging capabilities.

OPERATING INSTRUCTIONS

Power On/Off

Press the power button located on the fan's base or on the remote control to turn the fan on or off.


Fan Speed Adjustment

The fan offers 4 speed settings. Press the fan speed button on the base or remote to cycle through the speeds (1, 2, 3, 4) and off. Each press increases the airflow.

4 Speed Airflow & Super Long Lasting


Ensure long-term uninterrupted use

1st gear

 2.0m/s


140Hrs

2nd gear

 2.4m/s

80Hrs

3rd gear

 3.2m/s

50Hrs

4th gear

 3.8m/s

20Hrs



Image: A person using the FRIZCOL fan at an outdoor table, illustrating the four fan speed settings and their corresponding battery life (e.g., 140 hours at 2.0m/s).

LED Light Operation

The fan includes an integrated LED light with 2 brightness levels. Press the light button on the base or remote to turn the light on and cycle through the brightness settings.

2 Level LED Ambient Light

Create a wonderful nighttime atmosphere



Image: Two people and a dog relaxing outdoors at night, illuminated by the fan's 2-level LED ambient light, creating a comfortable atmosphere.

Timer Function

Set the fan to automatically turn off after a specific duration using the timer function. Press the timer button on the remote control to select 1, 3, or 5 hours. This feature is ideal for peaceful sleep.

3 Timer Setting & Whisper Quiet

Set 1/3/5 Hr auto-off for peaceful sleep



Image: A person sleeping peacefully with the FRIZCOL fan operating quietly on a bedside table, demonstrating the timer function and low noise level (under 30 dB).

Remote Control Usage

The included remote control allows for convenient operation from a distance. Ensure the remote has working batteries and point it towards the fan for optimal response.

Versatile Camping Fan

Customize the comfortable airflow



Image: A child sitting near a tent, operating the FRIZCOL fan with a remote control, showcasing its versatility and adjustable airflow for comfortable outdoor use.

Power Bank Functionality

The 24000mAh battery can be used to charge your electronic devices. Locate the USB-A output port on the fan's base. Connect your device's charging cable to this port to use the fan as an emergency power bank.

2*12000mAh Detachable Big Power

Used as emergency power source



Image: The FRIZCOL fan's detachable 12000mAh battery being used to charge a smartphone, demonstrating its function as an emergency power source in an outdoor setting.

Hanging Function and Adjustable Tilt

The fan features a hidden hook at the bottom for easy hanging in tents or other elevated positions. The fan head is vertically adjustable, allowing you to direct the airflow as needed.

Function Hook & Adjustable Tilt

Customize your outdoor comfort



Image: A person sitting by a lake, with the FRIZCOL fan hanging inside a tent, illustrating its function hook and adjustable tilt for customized outdoor comfort.

MAINTENANCE

Cleaning

- Ensure the fan is turned off and unplugged before cleaning.
- Wipe the exterior of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For the fan blades, gently wipe away dust and debris. Do not immerse the fan in water.

Battery Care

- To prolong battery life, avoid fully discharging the batteries frequently.
- Store the fan and batteries in a cool, dry place when not in use for extended periods.
- Recharge the batteries every 3-6 months if stored, to maintain their capacity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted or not properly installed.	Charge the battery fully. Ensure batteries are securely inserted.
Weak airflow.	Fan speed is too low or fan blades are obstructed.	Increase fan speed. Clean any dust or debris from the fan blades.
LED light not working.	Light function not activated or battery low.	Press the light button. Charge the battery.

Problem	Possible Cause	Solution
Remote control not responding.	Remote batteries are dead or remote is out of range/not pointed correctly.	Replace remote batteries. Ensure remote is pointed at the fan within effective range.
Device not charging from fan (power bank function).	Fan battery is low or cable is faulty.	Charge the fan's battery. Try a different USB cable.

SPECIFICATIONS

Feature	Specification
Brand	FRIZCOL
Model Name	FA-GY03
Power Source	Battery Powered
Battery Capacity	24000mAh (2 x 12000mAh detachable)
Endurance	20-140 hours (depending on speed)
Fan Speeds	4 Levels
Noise Level	<30 dB
LED Light	2 Brightness Levels
Timer Settings	1, 3, 5 Hours
Control Method	Push Button, Remote Control
Product Dimensions	8.9"D x 3.3"W x 11.6"H
Item Weight	2.2 Pounds
Material	ABS Plastic
Connectivity	USB Type C (input), USB Type A (output)

Lightweight & Compact Design

Portable for indoor outdoor carrying



Image: The FRIZCOL fan with its dimensions (8.9 in D x 3.3 in W x 10.8 in H) and weight (1.8 lb) indicated, highlighting its lightweight and compact design for portability.

OFFICIAL PRODUCT VIDEOS

Your browser does not support the video tag.

Video: An official product video from FRIZCOL showcasing the 2nd generation camping fan with its detachable battery feature. This video provides a detailed look at the fan's components and how the detachable battery works.

Your browser does not support the video tag.

Video: An official product video from FRIZCOL demonstrating the 3-in-1 portable rechargeable fan for home and camping use. This video highlights the fan's various functionalities and its suitability for different environments.

WARRANTY AND SUPPORT

FRIZCOL products are designed for durability and performance. For any questions, technical support, or warranty claims, please contact FRIZCOL customer service through the retailer's platform or the official FRIZCOL website. Please retain your proof of purchase for warranty purposes.

© 2025 FRIZCOL. All rights reserved.