

magicplux IC2S

magicplux Induction Cooktop 2 Burners User Manual

Model: IC2S

1. INTRODUCTION

This user manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your magicplux 2-Burner Induction Cooktop. Please read this manual thoroughly before using the appliance and keep it for future reference.


2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, burns, or injury. This appliance is intended for household use only.

- Ensure the appliance is properly installed and grounded by a qualified technician.
- Do not touch hot surfaces. Use handles or knobs.
- Do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The cooktop is protected against overheating and will automatically shut off if the temperature is too high.
- The residual heat indicator "H" signals high temperatures on the cooktop surface.

3. PRODUCT OVERVIEW

The magicplux 2-Burner Induction Cooktop features a sleek black glass surface, touch controls, and a flexible cooking zone for versatile cooking. It offers precise temperature control and various safety features.






Figure 1: Top view of the magicplux 2-Burner Induction Cooktop, showcasing its black glass surface and touch controls.

4. SETUP AND INSTALLATION

4.1 Unpacking and Inspection

Carefully remove the cooktop from its packaging. Inspect the appliance for any signs of damage. Do not install if damaged. Keep all packaging materials until you are satisfied with the product's condition.

4.2 What's in the Box

- magicplux 2-Burner Induction Cooktop
- Mounting material
- User Guide (this manual)
- Sponge strip

4.3 Dimensions and Installation Requirements

The cooktop is designed for built-in installation. Ensure your countertop cutout meets the specified dimensions for proper fit and ventilation.

Design integrato

Elegante e salvaspazio



Figure 2: Diagram showing the integrated design and precise dimensions of the cooktop (520mm x 290mm x 63.5mm), essential for proper built-in installation.

- Product Dimensions: 52 x 29 x 6.35 cm (Length x Width x Height)
- Weight: 4.3 kg
- Ensure adequate ventilation space around and beneath the appliance.
- Connect to a suitable electrical supply as per local regulations.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button to turn the cooktop on or off. The display will illuminate when active.

5.2 Power Levels and Temperature Control

The cooktop features 9 power levels, allowing for precise temperature control for various cooking needs, from melting chocolate to searing steak.



Figure 3: Illustration of the 9 power level settings and the 99-minute timer function, demonstrating precise temperature control for different dishes.

5.3 Timer Function

Set the timer for 1 to 99 minutes. The cooktop will automatically shut off when the set time expires, enhancing cooking convenience.

5.4 Flexible Zone (Flex Zone)

The flexible zone allows for a larger heating surface, precisely heating the area covered by the cookware. This feature provides greater cooking possibilities, accommodating various pot and pan sizes.



Figure 4: Depiction of the flexible zone, illustrating how it adapts to different cookware sizes, including larger or elongated pots.

5.5 Stop/Work Function

The "stop/go" function allows you to pause and resume cooking at any time, providing flexibility during busy cooking sessions.

5.6 Cookware Compatibility

Induction cooktops require specific types of cookware. This cooktop works perfectly with cast iron, iron, or magnetic stainless steel pots and pans. If incompatible cookware is detected or no cookware is present, the cooktop will automatically stop heating and shut off after 2 minutes.

Compatibile con pentole magnetiche

Pentole adatte per una cottura migliore



Figure 5: Visual guide illustrating compatible cookware types (cast iron, enameled cast iron, magnetic stainless steel, magnetic wok) and incompatible types (copper, ceramic, aluminum, glass).

5.7 Child Lock Function

The control panel can be locked to prevent accidental operation, especially useful in households with children. Activate the child lock to secure the settings.

6. MAINTENANCE AND CLEANING

The cooktop features a smooth black crystal surface that is easy to clean and maintain. Always turn off the power supply before cleaning.

Manutenzione facile

Superficie liscia che può essere facilmente pulita con un panno umido



Figure 6: Image demonstrating the ease of cleaning the cooktop's smooth surface with a damp cloth and mild detergent.

- Use a soft cloth and mild detergent for daily cleaning.
- For stubborn stains, use a ceramic hob cleaner.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals that could scratch the surface.
- Wipe dry with a clean cloth to prevent water spots.

7. TROUBLESHOOTING

If you encounter issues with your magicplux Induction Cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; child lock activated.	Check power connection; deactivate child lock.
Cooktop beeps and stops heating.	Incompatible cookware; no cookware detected.	Use compatible magnetic cookware; place cookware on the zone.
Touch controls are unresponsive.	Wet surface; foreign object on controls; temporary malfunction.	Ensure controls are dry and clean; remove any objects; power cycle the unit by unplugging for a few minutes and plugging back in.
Cooktop overheats and shuts off.	Poor ventilation; prolonged high-power use.	Ensure proper ventilation around the unit; allow to cool down before resuming use.
"H" indicator remains on.	Residual heat on the surface.	This is normal. The "H" indicates the surface is still hot. Wait for it to cool down.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	magicplux
Model Number	IC2S
Product Dimensions	52 x 29 x 6.35 cm
Item Weight	4.3 kg
Burners	2
Color	Black
Power Source	Corded Electric
Fuel Type	Electric
Special Features	Hot surface indicator, Built-in, Timer, Safety lock, Digital display
Heater Surface Material	Ceramic Glass
Burner Type	Induction
Country of Origin	China

9. WARRANTY AND SUPPORT

The magicplux Induction Cooktop comes with a 1-year warranty. During this period, if you have any questions about magicplux products, please do not hesitate to contact customer service. You will receive a satisfactory response within 24 hours.

For returns or issues with defective/damaged products, please refer to the Amazon return policy or contact the seller directly.

For further assistance, please visit the [magicplux Store on Amazon](#).

© 2024 magicplux. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question