

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WiiM](#) /

› [WiiM Voice Remote User Manual](#)

WiiM WVR001

WiiM Voice Remote User Manual

Model: WVR001 | Brand: WiiM

INTRODUCTION

This manual provides detailed instructions for the WiiM Voice Remote, designed to enhance your control over WiiM Mini and Pro Audio Streamers. It features push-to-talk voice commands and four customizable music preset buttons for convenient access to your favorite audio content.

PRODUCT OVERVIEW

The WiiM Voice Remote offers intuitive control and a comfortable design. Below is an overview of the remote and its key features.





Figure 1: Front view of the WiiM Voice Remote, showcasing its sleek black design and button layout.






Figure 2: The WiiM Voice Remote with approximate dimensions of 1.5 inches width and 6.2 inches length, illustrating its compact size.

Upgrade your listening experience



Push-to-talk
voice



Easy to
control



Simple
setup



Four
presets



Figure 3: Visual representation of the remote's key features: Push-to-talk voice control, easy handling, simple setup, and four customizable presets.

Button Functions




Figure 4: A detailed diagram labeling each button on the WiiM Voice Remote and its corresponding function.

- **Power Button:** Controls standby mode for your connected WiiM device.
- **Voice Button (Microphone Icon):** Activates push-to-talk voice commands for searching and controlling via Alexa.
- **Volume Up (+):** Increases the audio volume.
- **Volume Down (-):** Decreases the audio volume.
- **Previous Track (◀◀):** Skips to the previous song or content.
- **Play/Pause (▶):** Toggles playback (play/pause).
- **Next Track (▶▶):** Skips to the next song or content.
- **Source Switch (Arrow Icon):** Changes the audio input source.
- **Mute/Unmute (Speaker Icon):** Toggles audio mute.
- **Preset Buttons (1, 2, 3, 4):** Customizable buttons for one-tap access to favorite music, playlists, or radio stations.

SETUP

Setting up your WiiM Voice Remote is a straightforward process through the WiiM Home app.

1. **Insert Batteries:** Ensure 2 AAA batteries (not included) are inserted into the remote.
2. **Open WiiM Home App:** Launch the WiiM Home application on your smartphone or tablet.
3. **Pairing:** Within the app, follow the on-screen instructions to easily pair the remote with your WiiM Mini or Pro

device. The app will guide you through the connection process.

4. **Voice Control Setup:** To use voice control with Alexa, ensure your WiiM device is connected to Alexa via the WiiM Home app. No additional built-in Alexa device is required for the remote's voice functionality.

WiiM Home App Guide

For a visual guide on setting up and utilizing the WiiM Home App, please watch the official video below:

Your browser does not support the video tag.

Video: Official WiiM Home App Guide. This video demonstrates the setup process, multi-room management, music streaming, smart presets, alarm/sleep timer functions, equalizer settings, and seamless device switching within the WiiM Home App.

OPERATING INSTRUCTIONS

Once paired, the WiiM Voice Remote provides convenient control over your audio experience.

- **Playback Control:** Use the central navigation buttons to play, pause, skip to the previous track, or skip to the next track.
- **Volume Control:** Adjust the volume using the '+' and '-' buttons. The mute button allows for instant audio silencing.
- **Voice Commands:** Press and hold the Voice button (microphone icon) to activate Alexa and issue voice commands for searching music, controlling playback, or other smart home functions. Release the button when finished speaking.
- **Customizable Presets:** The four numbered preset buttons (1, 2, 3, 4) can be customized via the WiiM Home app to instantly launch your favorite songs, playlists, radio stations, podcasts, or even control other devices.
- **Source Switching:** Use the Source Switch button to cycle through available audio input sources on your WiiM device.

MAINTENANCE

Battery Replacement

The WiiM Voice Remote requires 2 AAA batteries. When the remote's performance degrades or it stops responding, it's time to replace the batteries.

1. Locate the battery compartment cover on the back of the remote.
2. Slide the cover open.
3. Remove the old batteries and insert two new AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

If you encounter issues with your WiiM Voice Remote, try the following steps:

- **Remote Not Responding:**
 - Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary.
 - Ensure the remote is within range of your WiiM Mini or Pro device.
 - Re-pair the remote with your WiiM device via the WiiM Home app.

- **Voice Commands Not Working:**

- Verify that your WiiM device is properly connected to Alexa through the WiiM Home app.
- Ensure you are pressing and holding the Voice button while speaking.
- Check your internet connection for the WiiM device, as Alexa requires online access.

- **Preset Buttons Not Functioning:**

- Confirm that the preset buttons have been configured in the WiiM Home app.
- Check the availability of the content linked to the preset (e.g., if a streaming service is active).

For more detailed troubleshooting or specific issues, refer to the FAQ section within the WiiM Home app or visit the official WiiM support website.

SPECIFICATIONS

Feature	Detail
Brand	WiiM
Model Number	WVR001
Color	Black
Connectivity Technology	Bluetooth
Special Feature	Easy to Install
Compatible Devices	WiiM Mini, WiiM Pro Audio Streamers, Smartphone (for app control)
Maximum Supported Devices	1 (per remote)
Number of Buttons	4 (Preset) + Control Buttons
Controller Type	Remote Control
Maximum Range	10 Meters
Item Weight	77 Grams

WHAT'S IN THE BOX

- WiiM Voice Remote

Note: 2 AAA batteries are required and not included in the package.

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official WiiM website or contact WiiM customer service. You can also find an active user community and in-app feedback options within the WiiM Home application for rapid problem resolution.

Official WiiM Website: www.wiim.com

Related Documents - WVR001

	<p>WiiM Voice Remote Quick Start Guide for WiiM Mini and Pro</p> <p>Get started quickly with the WiiM Voice Remote. This guide explains how to use the remote with WiiM Mini and Pro devices, including button functions and pairing instructions for seamless control of your audio devices.</p>
<p>WiiM</p> <p>Quick Start Guide</p> <p>WiiM Voice Remote works with WiiM Mini and WiiM Pro. Use WiiM Voice Remote to control your favorite WiiM devices without your phone.</p>  <p>Voice button – Push to talk to use Alexa Preset shortcuts – Customize these presets within the WiiM Home App</p> <p>How to pair with WiiM devices To pair with WiiM Pro or Mini – Press “source switch” and “mute” buttons at the same time, then go to the WiiM Home App and select the Device tab in the device setting gear icon > Add or Delete a WVR Remote.</p> <p>FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction FCC ID: 2ANQG-WVR001</p>	<p>WiiM Voice Remote Quick Start Guide - Setup and Pairing</p> <p>Get started quickly with your WiiM Voice Remote. This guide covers setup, pairing with WiiM Mini and Pro, button functions, and FCC compliance information.</p>
 <p>WiiM Voice Remote Upgrade your listening experience</p>	<p>WiiM Voice Remote User Manual</p> <p>User manual for the WiiM Voice Remote, detailing its features, controls, pairing instructions, and safety information. Learn how to upgrade your listening experience with voice control and customizable presets.</p>

 <p>WiiM Mini Hi-Res Audio Streamer</p> <p>Model: WMR01</p>	<p>WiiM Mini Hi-Res Audio Streamer User Manual</p> <p>A comprehensive guide to the WiiM Mini Hi-Res Audio Streamer, covering setup, features, connectivity options like Wi-Fi, Bluetooth, Spotify Connect, and AirPlay 2, as well as voice control integration and troubleshooting.</p>
 <p>WiiM Ultra</p> <p>User Quick Guide</p> <p>QR code</p>	<p>WiiM Ultra User Quick Guide: Setup, Features, and Operation</p> <p>This guide provides essential information for setting up and using the WiiM Ultra digital audio streamer. Learn about connecting your device, using the WiiM Home app, configuring audio outputs, streaming music, utilizing the voice remote, and accessing support.</p>
<p>WiiM Pro</p> <p>USER QUICK GUIDE</p> <p>Audiophile grade music streamer</p>	<p>WiiM Pro User Manual: High-Resolution Audio Streamer</p> <p>Discover the WiiM Pro, a versatile Hi-Res audio streamer. This comprehensive guide covers setup, features, app integration, voice control, and troubleshooting for seamless music streaming with your existing audio system.</p>