

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Crivit](#) /

› [Silvercrest DAB+ Radio User Manual](#)

Crivit B0BVW5K8CV

Silvercrest DAB+ Radio User Manual

Model: B0BVW5K8CV | Brand: Crivit

INTRODUCTION

This user manual provides comprehensive instructions for the operation and maintenance of your Silvercrest DAB+ Radio. Please read this manual carefully before using the device to ensure proper functionality and to prevent damage. Keep this manual for future reference.

SAFETY INSTRUCTIONS

- Do not expose the device to rain, moisture, or extreme temperatures.
- Avoid placing the device near heat sources such as radiators or stoves.
- Do not open the device casing. Repairs should only be performed by qualified personnel.
- Ensure proper ventilation around the device.
- Disconnect the power plug during thunderstorms or when not in use for extended periods.
- Clean the device only with a dry, soft cloth. Do not use liquid cleaners.

PACKAGE CONTENTS

Please check that all items are present and in good condition:

- Silvercrest DAB+ Radio Unit
- Power Adapter
- User Manual (this document)

PRODUCT OVERVIEW



Figure 1: Front View. This image displays the front of the Silvercrest DAB+ Radio, highlighting its clear digital display which shows the current time and date. Above the display, several control buttons are visible, including a large 'SNOOZE' button.



Figure 2: Top and Rear View. This image provides a view of the top control panel with various buttons and the rear panel of the radio. The rear panel features a USB output port (OUT 5V/1A) for charging external devices, a DC input port (DC 5.3V/2A) for power, and an antenna (ANT) connection.

Controls and Connections:

- **Display:** Shows time, date, radio station information, and menu options.
- **Control Buttons (Top Panel):** For navigation, mode selection, volume, alarm settings, and snooze.
- **USB OUT (5V/1A):** USB port for charging compatible external devices.
- **DC IN (5.3V/2A):** Power input port for connecting the power adapter.
- **ANT:** Connection point for the external antenna.

SETUP

1. **Connect Antenna:** Connect the provided antenna cable to the ANT port on the rear of the radio. Extend the antenna fully for optimal reception.

- Connect Power:** Insert the power adapter cable into the DC IN (5.3V/2A) port on the rear of the radio. Plug the power adapter into a standard wall outlet.
- Initial Power On:** The radio will power on automatically or require a press of the power button. The display will light up.
- Automatic Time/Date Sync:** Upon first power-on, the radio will attempt to synchronize the time and date automatically via DAB+ signal. Ensure good reception for this feature.

OPERATING INSTRUCTIONS

Power On/Off

- Press the **Power** button to turn the radio on or off.

Mode Selection (DAB+/FM)

- Press the **Mode** button to switch between DAB+ and FM radio modes.

DAB+ Radio Operation

- First Time Scan:** When in DAB+ mode for the first time, the radio will automatically perform a full scan for available stations. This may take a few minutes.
- Manual Scan:** To perform a manual scan, navigate to the DAB+ menu and select "Full Scan" or "Auto Scan".
- Selecting Stations:** Use the **Tune>Select** knob or **Up/Down** buttons to browse through the list of available DAB+ stations. Press **Select** to confirm your choice.
- Saving Presets:** To save a station as a preset, tune to the desired station, then press and hold the **Preset** button. Use the **Tune>Select** knob or **Up/Down** buttons to choose a preset number (e.g., P1-P10), then press **Select** to confirm.
- Recalling Presets:** Briefly press the **Preset** button, then use the **Tune>Select** knob or **Up/Down** buttons to select the desired preset number, and press **Select**.

FM Radio Operation

- Auto Scan:** In FM mode, press and hold the **Scan** button to automatically scan and save strong FM stations.
- Manual Tuning:** Briefly press the **Tune>Select** knob or **Up/Down** buttons to fine-tune the frequency step by step. Press and hold to quickly scan for the next available station.
- Saving Presets:** Similar to DAB+, tune to the desired FM station, then press and hold the **Preset** button. Choose a preset number and press **Select**.
- Recalling Presets:** Briefly press the **Preset** button, then select the desired preset number and press **Select**.

Alarm Function

- Setting Alarm:** Press the **Alarm** button. Use the **Up/Down** buttons or **Tune>Select** knob to set the alarm time (hour and minute). Press **Select** to confirm each setting.
- Alarm Source:** Choose between Buzzer, DAB+, or FM as the alarm sound source.
- Alarm Volume:** Adjust the desired alarm volume.
- Activating/Deactivating Alarm:** After setting, ensure the alarm is activated (indicated by an alarm

icon on the display). Press the **Alarm** button repeatedly to toggle between Alarm 1, Alarm 2, or Off.

5. **Snooze:** When the alarm sounds, press the large **Snooze** button to temporarily silence it for a set period (e.g., 9 minutes).
6. **Stop Alarm:** To stop the alarm completely, press the **Power** button or the **Alarm** button.

Sleep Timer Function

- Press the **Sleep** button repeatedly to cycle through available sleep timer durations (e.g., 15, 30, 45, 60, 90 minutes, or Off). The radio will automatically turn off after the selected duration.

USB Charging Port

- The USB OUT (5V/1A) port on the rear of the radio can be used to charge small electronic devices such as smartphones or MP3 players. Connect your device's USB charging cable to this port.

MAINTENANCE

- Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior of the radio. Do not use abrasive cleaners, waxes, or solvents.
- Storage:** If storing the radio for an extended period, disconnect it from the power outlet and store it in a cool, dry place.
- Antenna Care:** Handle the antenna gently to avoid bending or breaking it.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty outlet.	Check power adapter connection. Try a different power outlet.
Poor radio reception (DAB+/FM)	Antenna not extended or poor signal area.	Fully extend the antenna. Reposition the radio for better signal. Perform a new scan.
No sound	Volume too low or muted.	Increase volume. Check if the radio is muted.
Alarm does not sound	Alarm not activated or set incorrectly.	Verify alarm time and activation status. Ensure alarm volume is audible.
Display is blank or frozen	Temporary software glitch.	Disconnect power for a few seconds, then reconnect to reset the device.

SPECIFICATIONS

Brand	Crivit
Model	B0BVW5K8CV
Tuner Technology	DAB+

Connectivity Technology	USB
Special Feature	Lightweight
Item Weight	330 Grams
Water Resistance Level	Waterproof
Hardware Interface	USB
Frequency	108 MHz (likely FM max frequency)
Compatible Devices	Headphones


WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

© 2024 Crivit. All rights reserved.


Related Documents - B0BVW5K8CV

 <p>IAN 369598 / Art. Nr. 9625821</p> <p>GOOF LASER ENTFERNUNGSMESSEUR GOOF LASER RANGEFINDER TELESTOOL GOOF LASER GOOF LASERDISTANTIMETR GOOF LASERDISTANTIMETR LADE & AUFSTANDSMESSEUR</p> <p>DEUTSCHENZÄHLUNG - 4 ENGLISCHENZÄHLUNG - 4 FRANZÖSISCHENZÄHLUNG - 4 MANUAL DE INSTRUCCIONES - 24 MANUAL DE INSTRUCCIONES - 27</p>	<p>CRIVIT Golf Laser Rangefinder Bedienungsanleitung</p> <p>Diese Bedienungsanleitung bietet detaillierte Informationen zum CRIVIT Golf Laser Rangefinder (IAN: 369598, Art. Nr.: 9625821). Sie deckt wichtige Sicherheitshinweise, technische Daten, Bedienung und Wartung ab.</p>
	<p>Crivit CEK 29 B5 Electric Cool Box User Manual</p> <p>Comprehensive user manual for the Crivit CEK 29 B5 electric cool box, covering operation, safety instructions, technical specifications, and maintenance. Includes information in multiple languages.</p>
 <p>CRIVIT</p> <p>KETTLEBELL</p> <p>10 KG</p> <p>KETTLEBELL Instruktion für use KETTLEBELL Gebrauchsanleitung</p> <p>IAN 466908_2407</p>	<p>CRIVIT Kettlebell: User Manual and Exercise Guide</p> <p>Comprehensive instructions for using the CRIVIT Kettlebell, including safety guidelines, exercise demonstrations, and maintenance tips. Learn how to perform various exercises for strength and conditioning.</p>
 <p>CRIVIT</p> <p>RESISTANCE BANDS</p> <p>EXERCISE BANDS Instruktion für use EXTENSIEUR Instruktion für use EXPANDER Gebrauchsanleitung</p> <p>IAN 463299_2407</p>	<p>CRIVIT Resistance Bands Instruction Manual (IAN 463299_2407)</p> <p>Comprehensive user manual for CRIVIT Resistance Bands (IAN 463299_2407), detailing safety instructions, intended use, exercise routines, storage, and care. Includes multi-language support.</p>



[CRIVIT Dumbbell Set - User Manual and Safety Instructions](#)

Comprehensive instructions for the CRIVIT Dumbbell Set, covering package contents, technical data, intended use, safety precautions, training guidelines, storage, disposal, and warranty information. Ensure safe and effective use of your fitness equipment.



[CRIVIT Bicycle Helmet with LED Rear Light SP-154 User Manual](#)

Comprehensive user manual for the CRIVIT Bicycle Helmet with LED Rear Light SP-154, covering safety information, usage instructions, cleaning, care, and warranty details.