

SEALY B0BVW8V48J

SEALY Electric Heated Throw Blanket User Manual

Model: B0BVW8V48J

INTRODUCTION

Thank you for choosing the SEALY Electric Heated Throw Blanket. This manual provides essential information for the safe and efficient use of your new heated blanket. Please read all instructions carefully before use and retain this manual for future reference.

This heated throw blanket features double-layered Sherpa material, 6 heating levels, a 2-10 hour auto-off timer, and built-in overheating protection for your comfort and safety.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of burns, electric shock, fire, or injury, this product must be used in accordance with the following instructions:

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use on areas of the body that are swollen, inflamed, or have open wounds.
- Do not use if the blanket is wet.
- Ensure the controller is always accessible and not covered.
- Do not use pins or other metallic objects with this blanket. They may damage electrical wiring.
- Do not use if the power cord or controller is damaged.
- Always unplug the blanket when not in use.
- This blanket is equipped with an overheating protection system and an automatic shut-off feature (2-10 hours).
- Keep pets away from the blanket to prevent damage to the wiring.
- Do not dry clean this product. Dry cleaning solvents may damage the insulation of the heating element.
- Do not iron the blanket.

This product is ETL and FCC certified, ensuring it meets safety standards.

SETUP INSTRUCTIONS

1. **Unpack the Blanket:** Carefully remove the heated throw blanket and its controller from the packaging.
2. **Connect the Controller:** Locate the connector on the blanket and the corresponding coupler on the controller cord.

Firmly push the coupler into the blanket connector until it clicks securely into place.



Description: A visual guide demonstrating the connection of the controller's coupler to the blanket's power port.

3. **Plug into Power:** Insert the power plug into a standard 120V AC electrical outlet. Ensure the outlet is easily accessible.



Description: An image illustrating the power cord being plugged into a wall socket.

4. **Position the Blanket:** Lay the blanket flat on your bed or sofa. Avoid bunching or folding the blanket while it is in use to ensure even heat distribution and prevent overheating.

Important: Not following this sequence (connect controller, then plug in power) may prevent the electric blanket from heating properly.


OPERATING INSTRUCTIONS

Your SEALY Electric Heated Throw Blanket features a user-friendly controller with heat level and timer settings.



WORKING AT HOME

never feel cold, and improve working efficiency



Description: A detailed view of the blanket's controller, showing the power button, heat setting button, time setting button, and digital display.


1. **Power On/Off:** Press the **Power button** () to turn the blanket on or off. The display will illuminate when powered on.
2. **Adjust Heat Level:** Press the **HEAT button** to cycle through the 6 available heat settings (95°F - 113°F). The current heat level will be displayed on the screen. Select your desired warmth level.
3. **Set Auto-Off Timer:** Press the **TIME button** to set the automatic shut-off timer. You can choose between 2 to 10 hours. The selected duration will be shown on the display. The blanket will automatically turn off after the set time.
4. **Pre-Heat Function:** The blanket features a pre-heat programmed function. You can turn it on a few minutes before use to warm up your bed or seating area.
5. **Setting Memory:** The controller retains your last used heat and timer settings for convenience.

For optimal performance, ensure the blanket is spread out evenly. The U-shaped coil structure is designed for even heat distribution.

MAINTENANCE AND CARE

Proper care will extend the life of your heated throw blanket. This blanket is machine washable.

1. **Disconnect Controller:** Before washing, always ensure the power cord is unplugged from the wall outlet and the controller cord is detached from the blanket.



Description: A person detaching the controller from the blanket, highlighting the importance of this step before washing.

2. **Machine Washing:** Machine wash the blanket on a gentle cycle with cold water. Do not use bleach.
3. **Drying:** We recommend air-drying the blanket. If using a dryer, tumble dry on a low temperature setting **Do not plug in or use the blanket until it is completely dry.**
4. **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal wiring.

Do NOT: Iron, dry clean, or use harsh chemicals on the blanket.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blanket does not heat.	Controller not properly connected; Power cord unplugged; Outlet malfunction; Overheating protection activated.	Ensure controller is securely connected to the blanket. Check if the power cord is firmly plugged into a working outlet. Unplug and re-plug the blanket. If overheating protection activated, allow blanket to cool down for 30 minutes before restarting.
Uneven heating.	Blanket is bunched or folded.	Spread the blanket out evenly. Avoid folding or bunching during use.
Controller display is off.	Blanket is off; Auto-off timer expired; Power interruption.	Press the Power button to turn on. If timer expired, restart the blanket. Check power connection.

PRODUCT SPECIFICATIONS

- Model:** B0BVW8V48J
- Brand:** SEALY
- Material:** Double-sided 240gsm Sherpa
- Color:** Charcoal
- Size:** Throw Size 50" x 60"
- Heat Settings:** 6 levels (95°F - 113°F)
- Auto-Off Timer:** 2-10 hours
- Safety Features:** Overheating protection, ETL & FCC certified
- Care Instructions:** Machine Washable (controller detachable)
- Power:** 120V AC (Standard US outlet)
- Included Components:** Electric throw blanket x 1, Controller x 1, User Manual x 1

WARRANTY AND CUSTOMER SUPPORT

SEALY products are engineered for high quality and long-lasting durability. This product is ETL certified for quality. If you have any questions or concerns about your SEALY Electric Heated Throw Blanket, please contact our customer service team. We provide 7x24-hour online customer service to assist you. For support, please refer to the contact information provided with your purchase or visit the official SEALY website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question