

[Manuals.plus](#) /

> [Ikea](#) /

> Ikea Barometer Ceiling Track Light (Model 90364642) User Manual

Ikea 90364642

Ikea Barometer Ceiling Track Light User Manual

Model: 90364642

1. PRODUCT OVERVIEW

The Ikea Barometer Ceiling Track Light is a modern lighting fixture designed for indoor use, featuring five individually adjustable spotlights. Its brass-coloured finish and versatile design allow for precise illumination, making it suitable for various spaces such as living rooms, corridors, and home offices. The fixture is constructed from durable metal, ensuring longevity and a sophisticated aesthetic.



Image 1.1: The Ikea Barometer Ceiling Track Light, showcasing its five adjustable brass-coloured spotlights on a linear track.

Key Features:

- **Versatile Design:** Modern brass-coloured ceiling track with 5 adjustable spotlight heads.
- **Premium Construction:** Durable metal construction with a sophisticated brass finish.
- **Adjustable Lighting:** Each spotlight can be independently aimed and rotated for customized directional lighting.
- **Ceiling-Mounted System:** Designed for ceiling installation, providing focused or distributed illumination.

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Always disconnect power at the main circuit breaker before installing, cleaning, or servicing the fixture.
- Installation should be performed by a qualified electrician if you are unsure about electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.

- Do not exceed the maximum wattage specified for the bulbs.
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Keep packaging materials out of reach of children.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Ikea Barometer Ceiling Track Light fixture (1 unit)
- Bulbs (quantity as specified, typically 5 LED bulbs)
- Mounting hardware (screws, wall anchors, wiring connectors)
- Instruction Manual (this document)

4. SETUP AND INSTALLATION

This section provides general guidelines for installing your ceiling track light. If you are not comfortable with electrical installations, please consult a qualified electrician.

Pre-Installation:

1. **Turn off Power:** Locate the circuit breaker controlling the light fixture's location and turn off the power. Verify power is off using a voltage tester.
2. **Prepare Mounting Area:** Ensure the ceiling surface is clean, dry, and structurally sound.
3. **Unpack Components:** Carefully remove all parts from the packaging and lay them out.

Mounting Steps:

1. **Attach Mounting Bracket:** Secure the fixture's mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached.
2. **Wire Connections:** Connect the fixture's wires to the household electrical wires. Typically, connect black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground). Use appropriate wire connectors and ensure secure connections.
3. **Secure Fixture:** Carefully lift the light fixture and align it with the mounting bracket. Secure the fixture to the bracket using the provided screws or fasteners.
4. **Install Bulbs:** Insert the recommended LED bulbs into each of the five spotlight sockets. Do not overtighten.
5. **Restore Power:** Once installation is complete and all connections are secure, turn the power back on at the circuit breaker.



Image 4.1: The Barometer track light installed on a ceiling, demonstrating its placement and illumination.

5. OPERATION

Operating the Ikea Barometer Ceiling Track Light is straightforward.

Turning On/Off:

The light fixture is controlled by a standard wall switch connected to your home's electrical system. Simply toggle the switch to turn the light on or off.

Adjusting Spotlights:

Each of the five spotlights can be individually adjusted to direct light precisely where needed. Gently grasp the spotlight head and rotate or pivot it to achieve the desired angle and direction of illumination. Avoid excessive force when adjusting.



Image 5.1: A close-up view of an adjustable spotlight, highlighting its pivot mechanism for directional lighting.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your track light.

Cleaning:

- Always turn off the power before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

Bulb Replacement:

- Ensure the power is off and the bulbs have cooled down before attempting to replace them.
- Gently unscrew the old bulb from its socket.
- Insert a new LED bulb of the same type and wattage. Refer to the specifications for recommended bulb types.

- Dispose of old bulbs according to local regulations.

7. TROUBLESHOOTING

If you encounter issues with your Ikea Barometer Ceiling Track Light, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the power switch is in the 'ON' position.
 - Verify that the circuit breaker has not tripped.
 - Ensure bulbs are correctly installed and not faulty.
 - Check electrical connections for looseness (with power off).
- **Light flickers:**
 - Ensure bulbs are fully screwed in.
 - Check for loose wiring connections (with power off).
 - Replace the bulb to rule out a faulty bulb.
- **One spotlight not working:**
 - Replace the specific bulb in the non-working spotlight.
 - Check the bulb's connection in its socket.

If these steps do not resolve the issue, please contact customer support.

8. SPECIFICATIONS

Brand	Ikea
Model Number	90364642
Colour	Brass
Material	Aluminium (Fixture), Alloy Steel (Shade)
Style	Modern
Product Dimensions (L x W x H)	90L x 15W x 15H Centimeters
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Installation Type	Hanging (Ceiling-mounted)
Special Feature	Adjustable Spot Light
Control Method	Push Button (via wall switch)
Light Source Type	LED

Finish Type	Brushed
Number of Light Sources	5
Light Colour	Warm White
Item Weight	250 Grams
Luminous Flux	50.0 (per bulb, typical for small LED spots)
Energy Efficiency	Energy Star compliant
Country of Origin	China

9. WARRANTY AND SUPPORT

Warranty Information:

This Ikea Barometer Ceiling Track Light is covered by a Limited Manufacturer Warranty. The specific terms and duration of the warranty may vary by region and purchase date. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty inquiries, or replacement parts, please contact Ikea customer service. You can find contact information on the official Ikea website or your purchase documentation.

When contacting support, please have your product model number (90364642) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BVWKJR84>

More documents and user manuals: <https://manuals.plus/>