
[Manuals.plus](#) /

› [Ikea](#) /

› Ikea LAGAN Plug-in Induction Hob 1 Zone/Black User Manual

Ikea IK.605.055.68

Ikea LAGAN Plug-in Induction Hob 1 Zone/Black User Manual

MODEL: IK.605.055.68

Introduction

This manual provides essential information for the safe and efficient use of your Ikea LAGAN Plug-in Induction Hob. Please read it thoroughly before installation and operation, and keep it for future reference.



The Ikea LAGAN Plug-in Induction Hob, a compact and efficient cooking solution, shown in a modern kitchen setting.


The Ikea LAGAN induction hob is designed for quick and precise cooking. Its induction zones transfer heat directly to the base of the pan, ensuring efficient cooking and rapid cooling when the pan is removed. This design provides superior temperature control and prevents food from burning onto the hob surface.

Setup and Installation


The Ikea LAGAN induction hob is designed for easy installation. Simply plug it into a suitable power socket to begin cooking.

Installation Requirements:

- Ensure the hob is placed on a stable, flat surface.
- Verify that the power outlet meets the voltage requirements (230 Volts).
- Allow adequate ventilation around the hob as per the dimension diagrams.




Detailed installation dimensions for the hob, illustrating required clearances for proper ventilation and placement within a kitchen counter setup. Dimensions include 38.0 cm length, 30.0 cm width, and 5.9 cm height, with minimum clearances of 5.5 cm from the side and 10.0 cm from the back.



A diagram indicating a 15 cm circular cutout, which may be relevant for specific countertop integration or ventilation requirements.

Operating Instructions

The LAGAN induction hob features an intuitive touch/press control panel for easy operation.



The control panel of the induction hob, featuring touch-sensitive symbols for power, timer, heat adjustment (+/-), pause, and lock functions.

Basic Operation:

- **Power On/Off:** Touch the power symbol to turn the hob on or off.
- **Heat Regulation:** Adjust the heat level easily and precisely by touching the + and - symbols.

Special Functions:

- **Pause Function:** If you need to interrupt cooking, touch the pause symbol. The cooking process will be suspended, and the cooking zone will automatically switch to the 'keep warm' setting. Touch the pause symbol again to resume cooking at the previous temperature.
- **Child Lock / Cleaning Lock:** To temporarily activate the child lock or cleaning function, hold the lock key for 3 seconds. This allows you to clean the surface without accidentally changing settings.



The induction hob efficiently boiling spaghetti, demonstrating its rapid heating capability.



The induction hob in operation, boiling potatoes, highlighting its versatility for various cooking tasks.

Maintenance and Cleaning

Maintaining your Ikea LAGAN induction hob is simple due to its smooth, easy-to-clean surface.

Cleaning Instructions:

- Ensure the hob is cool before cleaning.
- Wipe the surface with a damp cloth or sponge.
- For stubborn stains, use a mild detergent specifically designed for ceramic or induction hobs.
- Food or liquid spills do not burn onto the surface, making cleaning effortless.
- Avoid abrasive cleaners or scouring pads, as they can scratch the surface.

Troubleshooting

If you encounter any issues with your Ikea LAGAN induction hob, please refer to the following common troubleshooting tips. For more complex problems, contact customer support.

- **Hob not turning on:** Ensure the hob is properly plugged into a functioning power outlet. Check your household's circuit breaker.
- **No heat transfer:** Verify that you are using induction-compatible cookware. Induction hobs require pots and pans with a magnetic base.
- **Controls unresponsive:** Check if the child lock/cleaning function is activated. Hold the lock key for 3 seconds to deactivate it.
- **Unusual noises:** A slight buzzing or humming sound is normal during induction cooking, especially at higher power settings, and is due to the magnetic field.

Specifications

Feature	Detail
Brand	Ikea
Product Dimensions (L x W x H)	38 x 30 x 5.9 cm
Model Number	IK.605.055.68
Installation Type	Drop-In
Special Features	Heat Indicator, Programmable, Safety Lock
Hob Type	Induction
Number of Hobs	1
Color	Black
Voltage	230 Volts
Energy Type Used	Electric
Material	Ceramic Glass
Components Included	Hob only

Warranty Information

The Ikea LAGAN Plug-in Induction Hob comes with a**2-year warranty**. Please refer to the warranty brochure included with your purchase for detailed terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or spare parts inquiries, please contact Ikea customer service. Visit the official Ikea website for contact details and support resources in your region.

Note: Spare parts availability information is currently unavailable.

