

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA Alex 9-Drawer Unit (36x116 cm, White) Instruction Manual

IKEA IK.904.861.39

IKEA Alex 9-Drawer Unit Instruction Manual

Model: IK.904.861.39

PRODUCT OVERVIEW

The IKEA Alex 9-drawer unit is a versatile storage solution designed for various spaces, including offices and bedrooms. This unit features nine spacious drawers, providing ample storage for documents, supplies, or personal items. Each drawer is equipped with stops to prevent it from being pulled out too far, ensuring safe and convenient use.

Key Features:

- Nine functional drawers for organized storage.
- Integrated drawer stops for safety and ease of use.
- Durable construction suitable for daily use.





Image 1: The IKEA Alex 9-drawer unit in white, showcasing its tall, slender design with nine evenly spaced drawers.

SETUP AND ASSEMBLY

Assembly of the IKEA Alex 9-drawer unit is required. Please refer to the detailed assembly instructions included in the product packaging for step-by-step guidance. Ensure all components are present before beginning assembly. A second person may be helpful for certain steps.




Image 2: Technical drawing illustrating the dimensions of the IKEA Alex 9-drawer unit. The unit measures 36 cm (14 1/8") in width, 48 cm (18 7/8") in depth, and 116 cm (45 5/8") in height. Individual drawer heights are also indicated.

OPERATING INSTRUCTIONS

To use the drawers, simply pull the integrated handle on the front of each drawer. The drawers are designed with stops to prevent them from being accidentally pulled out completely, enhancing safety and preventing contents from spilling. Push the drawer back gently until it is fully closed.



Image 3: An open drawer of the IKEA Alex unit, revealing organized office supplies such as a stapler, notebooks, and a pen, demonstrating its practical storage capacity.



Image 4: A close-up view of the integrated handle design on the front of an IKEA Alex drawer, highlighting its minimalist and ergonomic shape.

MAINTENANCE

To maintain the appearance and longevity of your IKEA Alex drawer unit, clean it with a dry cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish. Regularly check all assembly fittings and re-tighten them as necessary to ensure stability.

TROUBLESHOOTING

- **Drawers sticking or not sliding smoothly:** Check if the drawer runners are correctly installed and free from obstructions. Ensure the unit is placed on a level surface.
- **Unit wobbles:** Verify that all screws and fittings are securely tightened. Ensure the unit is placed on a flat, stable surface.
- **Missing parts during assembly:** Contact IKEA customer service with your product model number and purchase details.

SPECIFICATIONS

Attribute	Value
Brand	IKEA
Model	IK.904.861.39
Product Dimensions (W x D x H)	36 x 48 x 116 cm (14 1/8 x 18 7/8 x 45 5/8 inches)
Material	Wood
Special Features	Soft closing, storage drawer
Number of Drawers	9
Finish Type	Lacquered
Furniture Finish	White
Assembly Required	Yes
Product Weight	40.39 Kilograms

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question