

## IKEA IK.901.245.34

# IKEA SKORVA Galvanized Midbeam Instruction Manual

Model: IK.901.245.34

## 1. INTRODUCTION

---

The IKEA SKORVA galvanized midbeam is a crucial component designed to provide robust central support for IKEA bed frames. This midbeam ensures stability and durability for your bed base and mattress, distributing weight evenly and preventing sagging. It is made from galvanized metal, offering resistance to corrosion and a long lifespan. This manual provides essential information for the safe and correct assembly, use, and maintenance of your SKORVA midbeam.

## 2. SAFETY INFORMATION

---

- Always follow the assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Ensure all fittings are securely tightened before use. Periodically check and re-tighten if necessary.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Handle metal parts with care to avoid cuts or pinches. Consider wearing protective gloves during assembly.
- Do not exceed the maximum load capacity of 600 kg for the midbeam.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. The package should contain:

- 1 x IKEA SKORVA Galvanized Midbeam (Model: IK.901.245.34)
- Necessary fasteners and brackets (refer to the specific assembly diagram included with your product for exact quantities and types).



An image showing the IKEA SKORVA galvanized midbeam, a long, silver-colored metal beam designed to provide central support for bed frames. It features a U-shaped profile with flared ends for attachment.

## 4. SETUP AND ASSEMBLY

---

The SKORVA midbeam is designed for easy integration with compatible IKEA bed frames. Follow these general steps, referring to your bed frame's specific assembly instructions for detailed diagrams:

1. **Prepare the Bed Frame:** Ensure your bed frame's side rails are assembled and ready to receive the midbeam.
2. **Position the Midbeam:** Place the SKORVA midbeam centrally between the two side rails of the bed frame. The ends of the midbeam are designed to fit into pre-drilled holes or slots on the side rails.
3. **Secure the Midbeam:** Use the provided screws or fasteners to secure each end of the midbeam to the bed frame's side rails. Ensure the connection is firm and stable.
4. **Check Stability:** Once attached, gently push and pull on the midbeam to confirm it is securely fastened and does not wobble.
5. **Install Bed Base:** After the midbeam is securely in place, you can proceed with installing your bed base (e.g., slatted bed base) on top of the midbeam and side rails.

*Note:* The exact method of attachment may vary slightly depending on the specific IKEA bed frame model. Always consult the assembly guide provided with your bed frame.

## 5. USAGE

---

Once properly installed, the IKEA SKORVA midbeam provides essential central support for your bed. It works in conjunction with your bed frame's side rails to evenly distribute the weight of your mattress and any occupants, preventing the bed base from sagging and ensuring a stable sleeping surface. This contributes to the longevity of your mattress and overall bed structure.

## 6. MAINTENANCE

---

- **Cleaning:** Wipe the midbeam with a damp cloth and a mild cleaner if necessary. Dry thoroughly. Avoid abrasive cleaners or harsh chemicals that could damage the galvanized finish.
- **Inspection:** Periodically inspect the midbeam and its connections to the bed frame for any signs of wear, damage, or loosening.
- **Tightening:** Re-tighten any screws or fasteners that may have become loose over time to maintain stability.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Midbeam feels loose or unstable.	Fittings are not fully tightened.	Check and securely tighten all screws and fasteners connecting the midbeam to the bed frame.
Midbeam does not fit the bed frame.	Incompatible bed frame model or incorrect orientation.	Ensure your bed frame is compatible with the SKORVA midbeam. Verify the midbeam's orientation and ensure it aligns with the designated attachment points on the bed frame.
Squeaking noises from the bed.	Loose connections or friction between metal parts.	Tighten all fasteners. If squeaking persists, apply a small amount of silicone spray or wax to contact points between the midbeam and bed frame (avoiding areas where fasteners need grip).

## 8. SPECIFICATIONS

---

**Model Number:** IK.901.245.34

**Brand:** IKEA

**Material:** Galvanized Metal

**Color:** Silver

**Product Dimensions (L x W x H):** 139 cm x 7 cm x 6 cm (54.7 in x 2.8 in x 2.4 in)

**Load Capacity:** 600 kg (1322 lbs)

## 9. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, returns, or additional product support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for any warranty claims.

**IKEA Official Website:** [www.ikea.com](http://www.ikea.com)