

## IKEA IK.394.813.57

# IKEA LURÖY Slatted Bed Base

Model: IK.394.813.57

## 1. INTRODUCTION

Thank you for choosing the IKEA LURÖY Slatted Bed Base. This product is designed to provide optimal support for your mattress, adapting to your body weight and increasing the flexibility of your sleeping surface. This manual contains important information regarding assembly, maintenance, and safe use of your new bed base. Please read it thoroughly before beginning assembly and retain it for future reference.

## 2. SAFETY INFORMATION

- Always follow the assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand or jump on the slatted bed base. It is designed to support a mattress and body weight evenly distributed.
- Keep small parts out of reach of children during assembly to prevent choking hazards.
- Use the bed base only with a compatible bed frame.

## 3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact IKEA customer service.

- LURÖY Slatted Bed Base (160 x 200 cm) - Consisting of multiple wooden slats and connecting straps/holders.
- Assembly hardware (screws, brackets, etc., if applicable for your specific model variant).




Image 1: Overview of the IKEA LURÖY Slatted Bed Base components, showing the arrangement of the wooden slats.

## 4. SETUP AND ASSEMBLY

Assembly of the LURÖY slatted bed base is typically straightforward. Refer to the specific assembly instructions included in your product packaging for detailed diagrams and steps. The general steps are as follows:

1. **Prepare the Bed Frame:** Ensure your bed frame is stable and ready to receive the slatted base. Some bed frames may have specific ledges or supports for the slats.
2. **Unroll the Slats:** The LURÖY slats often come pre-assembled in sections, connected by fabric straps. Carefully unroll or unfold these sections within the bed frame.
3. **Position the Slats:** Ensure the slats are evenly spaced and properly seated on the support ledges of your bed frame. The curved side of the slats should typically face upwards, providing spring action.
4. **Secure (if applicable):** Some bed frames or LURÖY variants may require securing the slatted base to the frame using screws or clips. Follow the specific instructions for your model.



Image 2: Detail view of the LURÖY slats, highlighting the wood material and the connecting strap.

## 5. OPERATING (USAGE)

---

The IKEA LURÖY Slatted Bed Base is designed to work in conjunction with a suitable mattress and bed frame. Once assembled and placed correctly, it provides a flexible and supportive foundation for your mattress.

- **Mattress Placement:** Place your mattress directly on top of the slatted base. Ensure the mattress is centered and covers the entire surface of the slats.
- **Weight Distribution:** The 17 glued slats are designed to adapt to your body weight, distributing it evenly across the sleeping surface. This helps to reduce pressure points and enhance mattress longevity.
- **Ventilation:** The open design of the slatted base allows for good air circulation around your mattress, which helps to keep it fresh and extend its lifespan.

## 6. MAINTENANCE AND CARE

---

To ensure the longevity and optimal performance of your LURÖY slatted bed base, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the wooden slats with a damp cloth. Use a mild cleaner if necessary, then wipe dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Regular Inspection:** Periodically check the slats and their connections for any signs of wear, damage, or loosening.
- **Tighten Fasteners:** If your bed base uses screws or other fasteners to attach to the bed frame, check them periodically and re-tighten if they have become loose.
- **Avoid Excessive Moisture:** Keep the bed base dry to prevent warping or damage to the wood.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Squeaking noises	Loose connections between slats and frame, or between bed frame components.	Check and tighten all screws and fasteners on both the slatted base (if applicable) and the bed frame. Ensure slats are properly seated.
Slats falling out of place	Incorrect positioning, or bed frame supports are not adequate.	Ensure slats are fully seated on the bed frame's support ledges. Verify the bed frame is compatible and provides sufficient support.
Slats appear warped or damaged	Excessive weight, moisture exposure, or manufacturing defect.	Reduce concentrated weight. Ensure the environment is not excessively humid. If damage is significant and not due to misuse, contact IKEA customer service.

## 8. SPECIFICATIONS

---

- **Model Number:** IK.394.813.57
- **Dimensions:** 160 x 200 cm (Length x Width)

- **Material:** Wood (typically birch veneer)
- **Number of Slats:** 17 glued slats
- **Assembly Required:** Yes
- **Care Instructions:** Wipe with a damp cloth

## 9. WARRANTY AND SUPPORT

---

IKEA products typically come with a limited warranty. For specific warranty terms and conditions applicable to your LURÖY slatted bed base, please refer to the warranty information provided with your purchase or visit the official IKEA website for your region.

For customer support, spare parts, or further assistance, please contact IKEA customer service through their official channels:

- **IKEA Official Website:** [www.ikea.com](http://www.ikea.com)
- **Customer Service Phone:** Refer to your local IKEA store's contact information.