

MPM 144326

MPM Automatic Microchip Pet Feeder User Manual

Model: 144326

1. INTRODUCTION

The MPM Automatic Microchip Pet Feeder is designed to provide controlled access to food for your pets, particularly beneficial in multi-pet households, for pets on special diets, or for managing pet weight. Utilizing RFID tag technology, the feeder grants access only to designated pets, preventing unauthorized consumption.

This innovative feeder allows you to schedule up to four meals per day, ensuring your pet receives their food at precise times. Its sealed food bowl design helps maintain food freshness and deters insects. The feeder is constructed from food-grade ABS materials, with a PP bowl and PC lid, ensuring safety for your beloved pets.



Image 1.1: Front-top view of the MPM Automatic Microchip Pet Feeder.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- MPM Automatic Microchip Pet Feeder Unit
- Removable Food Bowl
- RFID Collar Tags (2 included)
- USB Power Cable
- Instruction Manual



Image 2.1: All components included in the MPM Automatic Microchip Pet Feeder package.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your pet feeder:

- **Main Unit:** Houses the electronics, motor, and RFID sensor.
- **Food Bowl:** Removable for easy cleaning, suitable for wet or dry food.
- **Lid:** Automatically opens for authorized pets and seals to keep food fresh.
- **LCD Display:** Shows current time, feeding schedule, and menu options.
- **Control Buttons:** For navigating the menu and setting parameters.
- **RFID Sensor:** Detects registered RFID collar tags.
- **Power Port:** For connecting the USB power cable.
- **Battery Compartment:** (If applicable) For backup power using batteries.



Image 3.1: The feeder with the lid open, showing the food bowl.

4. SETUP

Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Power Connection:** Connect the USB power cable to the feeder's power port and plug it into a suitable power adapter (not included) or a USB power source. Alternatively, install batteries (not included) into the battery compartment for backup power.
3. **Install Food Bowl:** Place the removable food bowl securely into the main unit.
4. **Fill Food Bowl:** Add your pet's wet or dry food to the bowl. Do not overfill.
5. **Attach RFID Tag:** Securely attach one of the provided RFID collar tags to your designated pet's collar. Ensure it is not easily lost or damaged.

5. OPERATING INSTRUCTIONS

5.1. Initial Power On and Time Setting

1. Once powered, the LCD display will illuminate.
2. Use the control buttons (usually 'M' for Menu, 'SET' for Set, and arrow buttons for navigation) to set the current time. Refer to the specific button functions indicated on your feeder.

5.2. Registering RFID Tags

The feeder needs to learn your pet's RFID tag to grant access:

1. Access the 'RFID Registration' or 'Pet ID' menu option on the LCD display.
2. Follow the on-screen prompts to initiate the registration process.
3. Hold the pet's collar (with the attached RFID tag) near the feeder's sensor area (typically near the front of the lid). The feeder will emit a sound or display a confirmation message when the tag is successfully registered.
4. Repeat for any additional pets requiring access, using a unique RFID tag for each.

5.3. Programming Feeding Times

You can schedule up to 4 meals per day:

1. Navigate to the 'Meal Schedule' or 'Feeding Times' menu.
2. Select a meal slot (e.g., Meal 1, Meal 2).
3. Set the desired feeding time for that slot using the control buttons.
4. Confirm the setting. Repeat for up to four daily meals.
5. The feeder will automatically open its lid at the scheduled times when a registered pet approaches.

5.4. Manual Feeding

To open the feeder manually for immediate access:

- Locate the 'Manual Feed' or 'Open' button/option on the feeder's control panel or menu.
- Press or select this option to temporarily open the lid. The lid will close automatically after a short period or when the pet moves away.

5.5. Factory Reset

If you need to clear all settings, including registered RFID tags and feeding schedules, use the factory reset function:

1. Navigate to the 'System Settings' or 'Reset' menu option.
2. Select 'Factory Reset' and confirm your choice. All custom settings will be erased.

6. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and hygiene for your pet:

1. **Cleaning the Food Bowl:** The removable food bowl can be easily detached for separate cleaning. Wash it with warm, soapy water and rinse thoroughly. Ensure it is completely dry before placing it back into the feeder.
2. **Cleaning the Main Unit:** Wipe the exterior of the feeder with a damp cloth. Do not submerge the main unit in water. Avoid using abrasive cleaners.
3. **Lid and Sensor Area:** Periodically check and clean the lid mechanism and the RFID sensor area to ensure smooth operation and accurate tag detection. Remove any food debris or pet hair.
4. **Food Freshness:** The sealed design helps keep food fresh. For wet food, it is recommended to clean the bowl and refill more frequently to prevent spoilage.
5. **Battery Check:** If using batteries, check their charge periodically and replace them when low to ensure continuous operation during power outages.

7. TROUBLESHOOTING

If you encounter issues with your MPM Automatic Microchip Pet Feeder, refer to the following common problems and solutions:

- **Feeder not opening for registered pet:**
 - Ensure the RFID tag is securely attached to the pet's collar and is not damaged.
 - Verify the RFID tag is properly registered with the feeder (refer to Section 5.2).
 - Check for any obstructions around the sensor area or the lid mechanism.
 - Confirm the feeder has adequate power (AC adapter connected or fresh batteries).
- **Unauthorized pet accessing food:**
 - Ensure only designated pets have registered RFID tags.
 - Verify the feeder is not in a manual open mode.
 - Check if the feeder's sensor is obstructed, preventing it from closing properly.
 - Some clever pets may attempt to manipulate the lid. Ensure the feeder is placed in a stable location.
- **Power issues (feeder not turning on/display off):**
 - Check the USB power cable connection to both the feeder and the power source.
 - If using batteries, ensure they are correctly installed and have sufficient charge. Replace if necessary.
- **Food not dispensing/lid not opening at scheduled time:**
 - Verify the feeding schedule is correctly programmed (refer to Section 5.3).
 - Ensure the food bowl is not empty.
 - Check for any food jams or obstructions preventing the lid from opening.
- **LCD display not working or showing errors:**
 - Try performing a factory reset (refer to Section 5.5).
 - Disconnect and reconnect power to restart the device.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	144326
Dimensions (L x W x H)	40.64 x 25.4 x 7.62 cm
Weight	1.36 kg
Material	Acrylonitrile Butadiene Styrene (ABS), Polypropylene (PP), Polycarbonate (PC)
Target Species	Dog, Cat (Multi-Pet)
Recommended Uses	Dry Food, Wet Food, Multiple Pets
Special Feature	RFID Sensor, Automatic Feeding, LCD Display
Scheduled Meals	Up to 4 per day

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided with your purchase documentation or visit the official MPM website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact MPM customer service directly. Please have your model number (144326) and a description of the issue ready.

© 2023 MPM. All rights reserved.

Related Documents - 144326

 ІНСТРУКЦІЯ З ЕКСПЛУАТАЦІЇ  Холодильник/морозильна камера TOTAL NO Frost MPM-216-CF-26, MPM-216-CF-27, MPM-216-CF-28 ПЕЛІД ПОРІВНЯВІ ВІДПОВІДАЄ ДОКУМЕНТІВІ ІНСТРУКЦІЇ ІНСТРУКЦІЇ	MPM MPM-216-CF Series Refrigerator/Freezer User Manual This manual provides instructions for the MPM-216-CF-26, MPM-216-CF-27, and MPM-216-CF-28 refrigerator/freezer, covering safety information, daily use, installation, troubleshooting, and maintenance.
 ІНСТРУКЦІЯ ОБСЛУГИ  РОБОТ КУХОННИЙ MRK-17 Кухонный робот/Фуд просессор/Кузовний комбайн/Кузовний комбайн/Кухонный робот/ Robot cuisine multi-fonction/Cuicommachine ПРОД ПЕРЕКОНАЄ ВІДПОВІДАЄ ДОКУМЕНТІВІ ІНСТРУКЦІЇ ІНСТРУКЦІЇ	MPM MRK-17 Robot Kuchenny Instrukcja Obsługi Kompletna instrukcja obsługi robota kuchennego MPM MRK-17, zawierająca informacje o funkcjach, bezpieczeństwie, montażu i konserwacji urządzenia.
 ІНСТРУКЦІЯ ОБСЛУГИ  ПЛИТА ІНДУКЦІЙНА MPM-60-IM-15 ПРОД ПЕРЕКОНАЄ ВІДПОВІДАЄ ДОКУМЕНТІВІ ІНСТРУКЦІЇ ІНСТРУКЦІЇ	Instrukcja Obsługi Płyty Indukcyjnej MPM-60-IM-15 Instrukcja obsługi dla płyty indukcyjnej MPM model MPM-60-IM-15, zawierająca informacje o montażu, użytkowaniu, bezpieczeństwie, konserwacji, rozwiązywaniu problemów, danych technicznych oraz warunkach gwarancji.
 ІНСТРУКЦІЯ ОБСЛУГИ  Chłodziarko-zamrażarka model MPM-285-KB-31/E, MPM-285-KB-37/E, MPM-286-KB-34/E ПРОД ПЕРЕКОНАЄ ВІДПОВІДАЄ ДОКУМЕНТІВІ ІНСТРУКЦІЇ ІНСТРУКЦІЇ	MPM Chłodziarko-zamrażarka MPM-285-KB-31/E, MPM-285-KB-37/E, MPM-286-KB-34/E - Instrukcja Obsługi Kompleksowa instrukcja obsługi dla chłodziarko-zamrażarek MPM modeli MPM-285-KB-31/E, MPM-285-KB-37/E, MPM-286-KB-34/E. Zawiera informacje o bezpieczeństwie, instalacji, codziennym użytkowaniu, pielęgnacji, czyszczeniu, rozwiązywaniu problemów i danych technicznych.



NÁVOD K OBSLUZE



MIKROVLNNÁ TROUBA
MPM-20-KMT-04

PŘED PRVNÍM POUŽITÍM SI PŘEČTĚTE NÁVOD K OBSLUZE

[MPM-20-KMT-04 Mikrovlnná trouba: Návod k obsluze a bezpečnostní pokyny](#)

Kompletní návod k obsluze pro mikrovlnnou troubu MPM-20-KMT-04. Obsahuje důležité bezpečnostní pokyny, informace o instalaci, čištění, provozu a údržbě.



NÁVOD K OBSLUZE



MIKROVLNNÁ TROUBA
MPM-20-KMT-05

PŘED PRVNÍM POUŽITÍM SI PŘEČTĚTE NÁVOD K OBSLUZE

[Návod k obsluze: Mikrovlnná trouba MPM-20-KMT-05](#)

Kompletní uživatelská příručka pro mikrovlnnou troubu MPM-20-KMT-05 od výrobce MPM. Obsahuje podrobné pokyny k bezpečnému používání, instalaci, čištění a funkcím spotřebiče.