Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HP 4200

HP Color LaserJet Pro 4201dw Wireless Color Laser Printer

Model: 4200

Brand: HP

Introduction

The HP Color LaserJet Pro 4201dw is a versatile wireless color laser printer designed for small teams and busy offices. It delivers exceptional performance with brilliant 600 DPI print resolution and rapid printing capabilities. This single-function printer supports various media types and offers hassle-free wireless connectivity with intelligent Wi-Fi, ensuring a stable connection. Advanced security features and automatic double-sided printing enhance productivity and reduce waste.



Figure 1: Front view of the HP Color LaserJet Pro 4201dw printer.

Setup Guide

1. Unpacking and Initial Placement

Carefully remove the printer from its packaging. Ensure all packing materials and protective tapes are removed. Place the printer on a stable, flat surface with adequate space for ventilation and access to power and network connections.




Figure 2: Included components: Printer, toner cartridges (black and introductory cyan, magenta, yellow), documentation, and power cord.

2. Power Connection

Connect the power cord to the printer and then to a grounded electrical outlet. The printer will power on automatically or can be turned on using the power button.

3. Toner Cartridge Installation

The printer comes with preinstalled Original HP 210A Toner Cartridges. Ensure they are properly seated before first use.

4. Paper Loading

Load paper into the 250-sheet paper tray or the 50-sheet multipurpose tray. Adjust the paper guides to fit the paper size.



Figure 3: Paper trays and LCD panel.

5. Network Connection

Connect the printer to your network via Wi-Fi or Ethernet. The intelligent Wi-Fi feature helps maintain a stable connection. For wired connection, use the Ethernet port. A USB port is also available for direct connection.




Figure 4: Connectivity ports on the rear of the printer.

6. Driver Installation

Install the necessary drivers on your computer or mobile device. The printer supports wireless printing from any mobile device, PC, or tablet, and works with Microsoft, Mac, AirPrint, Android, Chromebook, and more.

Operating Instructions

Printing Documents

This printer offers blazing fast color printing at up to 35 pages per minute (PPM) for both color and monochrome documents, with sharp details and incredible color accuracy. It is ideal for high-volume office documents, presentations, and marketing materials, supporting 750-4,000 pages/month.




Figure 5: Key features of the HP Color LaserJet Pro 4201dw.

Automatic Two-Sided Printing

Utilize the automatic double-sided printing functionality to reduce paper waste and boost productivity. This feature is enabled by default in many print settings.

Wireless Printing

Connect your devices wirelessly using intelligent Wi-Fi, Ethernet, or Bluetooth. The printer is designed to find and maintain the most stable connection for seamless printing from various operating systems and devices.

Your browser does not support the video tag.

Video 1: Product Overview. This video demonstrates the HP Color LaserJet Pro 4201dw printer's features, including automatic two-sided printing, intelligent Wi-Fi connectivity, fast color printing at up to 35 PPM, and HP Wolf Pro Security. It also shows how to load paper into the tray.

Maintenance

Toner Cartridge Replacement

When toner levels are low, the printer's display will indicate which cartridge needs replacement. Use Original HP 210A Toner Cartridges for optimal performance and print quality. Follow the instructions provided with the new cartridges for proper installation.

Cleaning the Printer

Regularly clean the exterior of the printer with a soft, damp cloth. Avoid using abrasive cleaners. For internal cleaning, refer to the detailed instructions in the full user manual available on the HP support website.

Firmware Updates

Periodic firmware updates are released by HP to maintain the effectiveness of security measures and improve printer functionality. Ensure your printer is connected to the internet to receive these updates automatically or check for them manually through the printer's settings or HP's support website.

Troubleshooting

Connectivity Issues

- Ensure the printer is within range of your Wi-Fi router.
- Check that the Ethernet cable is securely connected if using a wired connection.
- Restart your printer, router, and computer/device.
- Verify that the printer's IP address is correct and accessible on your network.

Paper Jams

The HP Color LaserJet Pro 4201dw features auto paper jam recovery. If a jam occurs, follow the instructions displayed on the printer's control panel to clear the paper path. Always remove jammed paper carefully to avoid tearing.

Print Quality Problems

- Check toner levels and replace cartridges if necessary.
- Ensure you are using appropriate paper for your print job.
- Clean the print heads or internal components as per the full manual.

Security Concerns

The printer includes HP Wolf Pro Security with customizable settings to protect your data and network. Ensure these settings are configured according to your IT policies to maintain security.



Figure 6: HP Wolf Pro Security features.

Specifications

Feature	Detail
Product Dimensions	16.6"D x 11.3"W x 16.8"H
Printing Technology	Laser
Printer Output	Color
Maximum Print Speed (Color)	33 PPM
Max Printspeed Monochrome	35 PPM
Maximum Color Print Resolution	603 x 600 Dots Per Inch

Feature	Detail
Maximum Black and White Print Resolution	600 dpi
Dual-sided printing	Yes (Automatic)
Connectivity Technology	Bluetooth, USB, Ethernet
Max Input Sheet Capacity	300 sheets
Print media	Envelopes, Paper (plain), Glossy photo paper
Power Consumption	580 Watts (On-mode)
Memory Storage Capacity	512 MB
Item Weight	36 Pounds



Figure 7: Printer dimensions.

Warranty and Support

This HP Color LaserJet Pro 4201dw printer comes with a Limited Warranty. For detailed warranty information, terms, and conditions, please refer to the documentation included with your product or visit the official HP support website.
For technical support, driver downloads, and additional resources, please visit the official HP support website: www.hp.com/support

© 2023 HP Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVXMBJGH

More documents and user manuals: **https://manuals.plus/**