



[Manuals.plus](#) /

› [Hilitand](#) /

› Hilitand Diversion Book Safe User Manual

Hilitand Hilitandb6zfms9h82

Hilitand Diversion Book Safe User Manual

Model: Hilitandb6zfms9h82

INTRODUCTION

Thank you for choosing the Hilitand Diversion Book Safe. This product is designed to provide a discreet and secure storage solution for your valuables. Appearing as a regular book, it seamlessly blends into your bookshelf, offering a hidden compartment for cash, credit cards, important documents, jewelry, and other small items you wish to keep out of sight.

Its robust iron construction ensures durability, while the realistic fabric cover and spine enhance its concealment. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your new diversion safe.

PRODUCT OVERVIEW




Figure 1: The Hilitand Diversion Book Safe, appearing as a book, shown with its two accompanying keys.



Figure 2: The book safe opened, revealing the internal metal lock box with its keyhole.



Figure 3: The book safe with its metal compartment lid open, ready for storing valuables like jewelry.

SETUP

1. **Unpack the Safe:** Carefully remove the diversion book safe and its keys from the packaging. Ensure both keys are present.
2. **Inspect for Damage:** Before use, visually inspect the safe for any signs of damage during transit.
3. **Familiarize with Keys:** Identify the two keys provided. These are unique to your safe. It is recommended to keep one key in a secure, memorable location and the other for regular access.
4. **Placement:** For optimal concealment, place the diversion safe on a bookshelf or bookcase, ideally in between other books. It can also be placed on a coffee table or nightstand.

OPERATING INSTRUCTIONS

Opening the Safe:

1. Locate the keyhole on the metal compartment inside the book.
2. Insert one of the provided keys into the keyhole.
3. Turn the key clockwise to unlock the compartment.
4. Lift the metal lid to access the storage space.

Storing Valuables:

- Place your desired items (cash, jewelry, documents, etc.) into the compartment.
- Ensure items fit without forcing the lid closed, as this could damage the lock mechanism or the items themselves.

Closing and Locking the Safe:

1. Gently lower the metal lid until it is flush with the book's interior.
2. Turn the key counter-clockwise to lock the compartment.
3. Remove the key.
4. Close the book cover to complete the concealment.



Figure 4: A top-down view of the open book safe, showing the internal metal compartment ready for use.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the book safe with a soft, dry cloth to remove dust. For the metal interior, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or harsh chemicals.

- **Key Care:** Keep the keys clean and dry. Do not force the key if it feels stiff; a small amount of graphite lubricant (not oil) can be applied to the key and inserted into the lock if necessary.
- **Storage Environment:** Store the safe in a dry environment, away from extreme temperatures and humidity, to prevent damage to the materials.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Key does not turn in lock.	Incorrect key; debris in keyhole; stiff mechanism.	Ensure you are using the correct key. Check for and remove any visible debris. Apply a small amount of graphite lubricant to the key and gently insert it.
Lid does not close properly.	Items inside are too bulky; lid misaligned.	Remove some items if the compartment is overfilled. Gently adjust the lid to ensure it aligns correctly before closing.
Book appearance is not convincing.	Isolated placement.	Place the diversion safe between other books on a shelf to enhance its camouflage.

SPECIFICATIONS

Feature	Detail
Brand	Hilitand
Model Number	Hilitandb6zfms9h82
Lock Type	Key Lock
Material	Iron (internal safe), Paper/Fabric (external book cover)
Special Features	Durable, Portable, Concealed Storage
Mounting Type	Freestanding, Tabletop
Included Components	Diversion Book Safe, Keys (x2)
Water Resistance Level	Not Water Resistant
Approximate Dimensions (External)	8.7 x 5.9 x 1.7 inches (22.1 x 15 x 4.3 cm)
Approximate Chamber Depth	1 inch (2.54 cm)
Item Weight	0.004 ounces (approx. 0.11 grams) - <i>Note: This weight seems unusually low based on the product description of iron material. Please refer to product packaging for accurate weight.</i>

Feature	Detail
---------	--------

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Hilitand Diversion Book Safe, please refer to the retailer's return policy or contact Hilitand directly through their official channels. Information regarding specific warranty terms may be available on the product packaging or the Hilitand brand store.

Visit the official Hilitand Store for more information: [Hilitand Store on Amazon](#)

