

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NEEWER](#) /

› [NEEWER MS60B LED Video Light Instruction Manual](#)

## NEEWER MS60B

# NEEWER MS60B LED Video Light Instruction Manual

Comprehensive guide for setup, operation, and maintenance of your NEEWER MS60B Bi-Color LED Video Light.

## INTRODUCTION

---

Thank you for choosing the NEEWER MS60B LED Video Light. This compact and powerful bi-color COB light offers versatile lighting solutions for photography and videography. Featuring adjustable color temperature, multiple special effects, and flexible control options, the MS60B is designed to enhance your creative output. This manual provides detailed instructions for safe and effective use of your new equipment.

## WHAT'S IN THE BOX

---

Verify that all components are present before setup.

- 1 x MS60B LED Video Light
- 1 x Power Adapter
- 1 x Battery Plate
- 1 x Battery Cable
- 1 x V Mount Battery Adapter Plate
- 1 x Reflector
- 1 x Handle
- 1 x Bowens Mount Adapter
- 1 x Power Cord
- 1 x V Mount Hanging Belt

# PRODUCT DETAIL

MS60B BI COLOR VIDEO LIGHT WITH APP CONTROL

All Aluminum Alloy Body

Product Material



1 x LED Bi Color Light



1 x Reflector



1 x Handle



1 x Bowens Mount Adapter



1 x Power Adapter



1 x Battery Box



1 x Battery Box Power Cord



1 x Power Cord



1 x V Mount Hanging Belt

Image: All components included in the NEEWER MS60B standard package, neatly arranged in their protective foam casing.

## SETUP GUIDE

### 1. Attaching the Handle

Align the handle with the mounting point on the MS60B LED Video Light. Securely fasten the handle by tightening the screw mechanism. The handle can be angled up to 180° for flexible positioning.



Image: The MS60B light with its detachable handle, illustrating its 180-degree rotational adjustment for versatile use.

### 2. Powering the Light

The MS60B supports multiple power options:

- **AC Power Adapter:** For continuous operation, connect the included AC power adapter to the light and a wall socket.
- **NP-F Batteries:** Attach the battery box to the light. Insert one or two NP-F750/NP-F970 batteries (sold separately) into the battery box. Use the provided battery cable to connect the battery box to the light.
- **V-Mount Battery:** For maximum power output, use a V-mount battery (14.4V, sold separately) with the V-mount battery adapter plate and a D-Tap cable (sold separately).

**Note: Batteries cannot be charged while being used. Simultaneous use of charging and battery power is not supported.**




Image: Visual representation of the three power options: dual NP-F battery box, V-mount battery setup, and direct AC power connection.

### 3. Attaching Light Modifiers (Bowens Mount)

The MS60B features a proprietary NEEWER mount. To use Bowens mount accessories (softboxes, photography umbrellas, beauty dishes), attach the included Bowens mount adapter to the light. Then, mount your desired modifier onto the adapter.



Image: Detailed view of the NEEWER mount with the Bowens mount adapter and umbrella hole, ready for light modifiers.

## OPERATING INSTRUCTIONS

The NEEWER MS60B offers three methods of control:

### 1. Onboard Control Panel

Use the control knobs and buttons located on the back of the light for direct adjustments.

- **ON/OFF Button:** Press to power the light on or off.
- **INT+ / INT- Knob:** Rotate to adjust brightness from 1% to 100%. Press to confirm selection.
- **SET / B Knob:** Rotate to adjust color temperature (2700K-6500K) or cycle through special effects. Press to confirm selection or enter menu.
- **2.4G/BT Button:** Press to activate 2.4G wireless control or Bluetooth for app control.



Image: The control panel of the MS60B, showing the display, adjustment knobs, and control buttons.

## 2. NEEWER App Control (Bluetooth)

Download the NEEWER APP from your smartphone's app store. Enable Bluetooth on your device and pair it with the MS60B. The app allows you to control brightness, color temperature, and access 12 special effects remotely. It also supports OTA firmware upgrades.

## 3. 2.4G Wireless Control

The inbuilt 2.4G system supports group control of multiple NEEWER LED lights (different models) within 49ft (15m). Set all lights to the same channel (00-99) to control them simultaneously from one unit.



Image: Two MS60B lights demonstrating 2.4G wireless control, allowing multiple units to be controlled from a single source.

## Special Effects

The MS60B includes 12 special effects to enhance creative shooting scenarios. These effects can be accessed and adjusted via the onboard controls or the NEEWER App.




Image: A graphic displaying the 12 distinct special effects, such as Lightning, Paparazzi, and Fireworks, available on the MS60B.

## MAINTENANCE

- Keep the device dry. Do not touch with wet hands.
- Clean the light with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Ensure proper ventilation. The silent cooling fan helps dissipate heat, prolonging the light's lifespan. Do not block the fan vents.
- Store the light in a cool, dry place when not in use, preferably in its original protective casing.



Image: An internal view of the MS60B's silent cooling fan, emphasizing its role in heat dissipation and thermal protection.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power supply or low battery.	Check power adapter connection or replace/charge batteries.
App control not working.	Bluetooth not enabled or light not paired.	Ensure Bluetooth is on and pair the device via the NEEWER App.

Problem	Possible Cause	Solution
Light output is dim.	Brightness set too low or using NP-F batteries for maximum output.	Increase brightness. For maximum output, use AC power or a V-mount battery.
Fan noise is noticeable.	Fan operating at higher speed due to heat.	Ensure vents are clear. The fan is designed for silent operation under normal conditions.

## SPECIFICATIONS

**Model:** MS60B

**Power Output:** 65W

**Color Temperature:** 2700K-6500K

**CRI:** 97+

**TLCI:** 98+

**Maximum Illuminance:** 40000lux@1m, 110000lux@0.5m

**Dimming:** 1%-100% (PWM Technology)

**Special Effects:** 12 built-in effects

**Control Methods:** Onboard, NEEWER App (Bluetooth), 2.4G Wireless

**Mount Type:** NEEWER Mount (with included Bowens Mount Adapter)

**Dimensions:** 5.9" x 3.7" x 3.6" / 150 x 95 x 92mm

**Weight:** 1.5lb / 700g

**Material:** Metal Aluminum Housing



Image: Key specifications and performance metrics of the MS60B, highlighting its compact size and high output.

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official NEEWER website. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** NEEWER

**Brand:** NEEWER

**Website:** [Visit the NEEWER Store](#)

## SAFETY INFORMATION

---

- Do not disassemble or modify the product.
- Keep the light away from water and flammable liquids.
- Avoid direct eye exposure to the light source.
- Use only the specified power adapter and batteries.
- Ensure the light is securely mounted before operation.

© 2026 NEEWER. All rights reserved.