

[Manuals.plus](#) /

› [iWALK](#) /

› iWALK MAG-X Magnetic Wireless Power Bank with iWatch Charger User Manual

iWALK MXB001

iWALK MAG-X Magnetic Wireless Power Bank with iWatch Charger User Manual

Model: MXB001

INTRODUCTION

The iWALK MAG-X Magnetic Wireless Power Bank is a versatile portable charger designed for Apple devices. It features strong magnetic alignment for secure wireless charging of iPhones and a dedicated charging spot for Apple Watches. With its 10000mAh capacity and USB-C fast charging output, it provides reliable power on the go for multiple devices simultaneously.



Figure 1: iWALK MAG-X Power Bank simultaneously charging an iPhone and Apple Watch.

PACKAGE CONTENTS

- iWALK 10,000mAh Magnetic Wireless Power Bank x 1
- USB-C to USB-C cable x 1
- User Manual x 1




Figure 2: The package includes the power bank, a USB-C cable, and the user manual.

PRODUCT OVERVIEW

The iWALK MAG-X features a sleek design with multiple charging interfaces. It includes a magnetic wireless charging pad for iPhones, a dedicated Apple Watch charging area, and a USB-C port for wired charging or recharging the power bank itself.



Figure 3: Key components of the iWALK MAG-X Power Bank, including the LED display and power switch.

Key Features:

- **Magnetic Wireless Charging:** Strong magnets ensure perfect alignment for iPhone 12/13/14/15 series and MagSafe compatible cases.
- **Integrated Apple Watch Charger:** Conveniently charge your Apple Watch Series 2-8/Ultra/SE.
- **USB-C Port:** Supports both input (for recharging the power bank) and output (for charging other devices like iPads or AirPods).
- **Digital LED Display:** Shows remaining battery percentage.
- **Compact and Portable:** Designed for easy carrying and travel.
- **Phone Stand Function:** Can be used to prop up your phone for viewing.

SETUP

Initial Charging:

1. Before first use, fully charge the iWALK MAG-X Power Bank.
2. Connect the provided USB-C to USB-C cable to the power bank's USB-C port.
3. Connect the other end of the cable to a compatible USB-C power adapter (not included).
4. The digital LED display will show the charging progress. Charge until it reaches 100%.

Your browser does not support the video tag.

Video 1: Official iWALK video demonstrating the charging process of the power bank itself, showing the digital display indicating battery percentage.

OPERATING INSTRUCTIONS

Charging an iPhone (Magnetic Wireless):

1. Ensure your iPhone is a 12 series or newer, or has a MagSafe compatible case.
2. Align the back of your iPhone with the magnetic charging area on the power bank. The magnets will snap into place.
3. Press the power button on the side of the power bank once to initiate wireless charging.



Wireless Charging Your Apple Watch and iPhone at Once

Figure 4: The power bank supports simultaneous wireless charging for both iPhone and Apple Watch.

Charging an Apple Watch:

1. Place your Apple Watch onto the dedicated circular charging pad on the power bank.
2. Press the power button on the side of the power bank once to initiate wireless charging.

Widely Compatible with Apple Watches

38/40/42/44mm & Series 2-8/Ultra/SE



Apple Watch
Series 8



Apple Watch
Ultra



Apple Watch
SE



Apple Watch
Series 7/6/5/4/3/2



Apple Watch
Nike



Apple Watch
Hermès

Figure 5: The power bank is compatible with various Apple Watch models for convenient charging.

Charging Other Devices (USB-C):

1. Connect your device (e.g., iPad, AirPods with wireless charging case, Nintendo Switch) to the power bank's USB-C port using a compatible cable.
2. The power bank will automatically begin charging the connected device.

Pass-Through Charging

Type-C Fast Charging-18W Input and Output



Figure 6: The USB-C port allows for pass-through charging, enabling the power bank to charge itself while also charging another device.

Low-Power Mode for AirPods:

- For optimal charging of low-power devices like AirPods, press and hold the power button for three seconds to enter low-current discharge mode.

Turning Off:

- Double-click the side button to stop charging and turn off the power bank.

Your browser does not support the video tag.

Video 2: Official iWALK video demonstrating the power bank's features, including magnetic attachment and simultaneous charging.

- Keep the power bank dry and away from moisture.
- Avoid extreme temperatures.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use.
- Avoid dropping or subjecting the device to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging wirelessly.	Incorrect alignment, power bank off, non-MagSafe case.	Ensure proper magnetic alignment. Press power button once. Use a MagSafe compatible case or remove case.
Power bank not recharging.	Faulty cable/adaptor, power bank fully discharged.	Try a different USB-C cable and power adapter. Allow more time for charging if fully depleted.
Slow charging.	Using non-fast charging adapter, device not optimized for fast charging.	Use a PD (Power Delivery) compatible USB-C adapter for faster recharging. Ensure device supports fast charging.
Power bank automatically turns off.	Low battery, overheating, device fully charged.	Recharge the power bank. Allow it to cool down. This is normal if the connected device is fully charged.

SPECIFICATIONS

- **Model:** MXB001
- **Battery Capacity:** 10000mAh
- **Product Dimensions:** 0.39 x 0.39 x 0.39 inches
- **Item Weight:** 12 ounces
- **Connectivity:** Magnetic Wireless, USB-C
- **Compatibility:** Apple Watch Series 2-8/Ultra/SE, iPhone 12/13/14/15/16 Series, MagSafe Cases, AirPods 2/3/Pro/Pro2 (via low-power mode or USB-C).

Multiple-charging with 10000mAh



Figure 7: Approximate charging capacities for different Apple devices using the 10000mAh power bank.



Powerful Magnetic Attachment

Magnet is strong and snaps in place easily

Figure 8: The compact dimensions of the power bank make it ideal for travel and portability.

WARRANTY INFORMATION

The iWALK MAG-X Magnetic Wireless Power Bank comes with an 18-month warranty service for any issues. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance or technical support, please visit the official iWALK website or contact customer service through the details provided in your product packaging.

Manufacturer: U2O GLOBAL CO., LTD
iWALK Store: [Visit iWALK Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

