

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw ID208BT Charger Stand User Manual

Lamshaw ID207-DOCK

Lamshaw ID208BT Charger Stand User Manual

Model: ID207-DOCK

PRODUCT OVERVIEW

The Lamshaw ID208BT Charger Stand is designed to provide a convenient and stable charging solution for your compatible smartwatches. This stand integrates the charging cable, offering a neat and organized charging experience for your desk, table, or nightstand.



Desktop Partner

An excellent addition to your desk



Image: The Lamshaw ID208BT Charger Stand neatly charging a smartwatch on a desk, illustrating its compact and functional design.

Key Features:

- **Compatibility:** Specifically designed for ID208/ID208BT series smartwatches (including SKG V7 Pro, Konitee ID208BT, DECEWIN ID208BT, ENOMIR ID208BT, aeac ID208BT, FACOI ID208BT) and ID207 series smartwatches (SKG V7, VRPEFIT ID207, TOZO S2, OCTANDRA ID207, aeac ID207, Boean ID207, GGZZ ID207, Dirrelo ID207,

FVYAO ID207).

- **Integrated Charging:** Functions as both a charger and a stand, eliminating the need for separate charging cables.
- **Stable Design:** Features a high-quality silicone base to prevent shaking and slipping, ensuring your watch remains securely in place during charging.
- **Ergonomic Angle:** Designed with a 45-degree angle for optimal viewing and interaction while charging.
- **Cable Management:** Helps organize the charging cable, contributing to a tidy desktop environment.

SETUP GUIDE

Follow these steps to set up your Lamshaw ID208BT Charger Stand:

1. **Unpack the Stand:** Carefully remove the charger stand from its packaging. Ensure all components, including the integrated USB charging cable, are present.
2. **Connect to Power:** Insert the USB-A end of the integrated charging cable into a compatible USB power adapter (not included), a computer's USB port, or a power bank.



Image: A side view of the charger stand, highlighting the integrated USB cable extending from its base, ready for connection to a power source.

3. **Prepare the Charging Surface:** The stand features a magnetic charging surface with two contact pins. Ensure this surface is clean and free of debris.



Image: A rear view of the charger stand, clearly showing the two metallic charging pins and the magnetic surface where the smartwatch will connect.

4. **Place Your Smartwatch:** Gently place your compatible smartwatch onto the charging surface of the stand. The magnetic connection will help align the watch with the charging pins. Ensure the watch's charging contacts align correctly with the pins on the stand.



Image: A smartwatch positioned on the Lamshaw ID208BT Charger Stand, demonstrating the correct alignment for charging. The USB cable is visible, ready for connection.

5. **Verify Charging:** Once properly placed, your smartwatch should indicate that it is charging (e.g., a charging icon or battery percentage increase).

OPERATING INSTRUCTIONS

Using your Lamshaw ID208BT Charger Stand is straightforward:

- **Daily Charging:** For optimal battery health, it is recommended to charge your smartwatch daily or as needed. Simply place your watch on the stand when not in use.
- **Secure Placement:** Always ensure your smartwatch is securely seated on the charging surface. The strong magnetic connection will help prevent accidental dislodgement.
- **Charging Speed:** This charger stand is designed for efficient charging. Charging times may vary depending on your smartwatch model and its current battery level.
- **Viewing Angle:** The 45-degree tilt of the stand allows for easy viewing of your smartwatch display while it charges,

making it convenient for checking notifications or the time.

MAINTENANCE

To ensure the longevity and optimal performance of your charger stand, follow these maintenance guidelines:

- **Cleaning:**
 - Wipe the stand regularly with a soft, dry, lint-free cloth to remove dust and fingerprints.
 - If the silicone base or charging surface becomes dirty, gently wipe it with a slightly damp cloth. Ensure the stand is completely dry before reconnecting it to power.
- **Protective Film:** The bottom of the stand may have a transparent protective film. This film can be fixed in a certain position by tearing it off. If dust accumulates on the bottom, it can be washed with water and reused after drying.



- 1: There is a transparent film at the bottom, which can be fixed in a certain position by tearing
- 2: If there is dust on the bottom, it can be washed with water and can be used again

Image: The underside of the charger stand, illustrating the transparent protective film that can be removed or cleaned to maintain grip and stability.

- **Storage:** When not in use for extended periods, store the charger stand in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not drop the stand or expose it to excessive force, as this may damage the internal components or the charging pins.

TROUBLESHOOTING

If you encounter issues with your Lamshaw ID208BT Charger Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Smartwatch is not charging.	Incorrect alignment of watch on stand.	Ensure the smartwatch is perfectly aligned with the charging pins. The magnetic connection should feel secure.
	Loose USB connection.	Check that the USB cable is firmly plugged into both the stand and the power adapter/USB port.
	Faulty power source.	Try a different USB power adapter or USB port.
	Charging pins or watch contacts are dirty.	Clean the charging pins on the stand and the contacts on your smartwatch with a dry, soft cloth.
	Incompatibility with watch model.	Verify your smartwatch model is listed as compatible.
	<i>Potential issue: Magnetic polarity reversed (as reported by some users).</i>	<i>If your watch appears to charge only when placed "upside down" or in an unusual orientation, this indicates a potential manufacturing defect with the magnetic polarity. Please contact customer support for assistance.</i>
Stand is unstable or slips.	Protective film on bottom not removed or dirty. Uneven surface.	Ensure the transparent protective film on the bottom is properly adhered or removed if it's causing issues. Clean the bottom silicone pad if it's dusty. Place the stand on a flat, stable surface.
Slow charging.	Low power output from USB source. Dirty contacts.	Use a USB power adapter with sufficient output (e.g., 5V/1A or higher). Clean the charging pins on the stand and the contacts on your smartwatch.

If the problem persists after trying these solutions, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Lamshaw
Model Number	ID207-DOCK
Compatible Devices	Smartwatches (SKG V7 Pro, Konitee ID208BT, DECWIN ID208BT, ENOMIR ID208BT, aeac ID208BT, FACOI ID208BT, SKG V7, VRPEFIT ID207, TOZO S2, OCTANDRA ID207, Boean ID207, GGZZ ID207, Dirrelo ID207, FVYAO ID207)
Connector Type	USB-A
Output Voltage	5 Volts
Wattage	5 watts
Total USB Ports	1 (integrated cable)
Item Weight	1.13 ounces (approx. 32 grams)

Feature	Detail
Package Dimensions	2.44 x 2.36 x 1.57 inches (approx. 6.2 x 6.0 x 4.0 cm)



Image: Technical drawing showing the dimensions of the charger stand: 36mm width, 36mm depth, and 60mm height.

Warranty Information:

Lamshaw provides a 90-day warranty from the date of purchase for quality-related issues. During this period, we will address any defects with a replacement or refund.

Customer Support:

If you encounter any issues with your Lamshaw ID208BT Charger Stand, or if you have questions not covered in this manual, please contact our customer support team. When contacting support, please provide your purchase details and a clear description of the issue to facilitate a quick resolution.

For defective items, please contact us immediately. We are committed to ensuring your satisfaction with our products.

© 2025 Lamshaw. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BVZJMX37>

More documents and user manuals: <https://manuals.plus/>