

Cuifati CUIFATlrqxb3hpse

Cuifati Replacement Charging Case for True Earbuds

User Manual

1. INTRODUCTION

Thank you for choosing the Cuifati Replacement Charging Case. This manual provides essential information for the proper setup, operation, and maintenance of your charging case. Please read it thoroughly to ensure optimal performance and longevity of your product.

This charging case is designed as a replacement for lost or damaged original charging cases, specifically compatible with for Buds Live (model SM R180). It features a built-in LED indicator and a high-capacity battery for convenient charging of your earbuds.

2. PRODUCT OVERVIEW

The Cuifati Replacement Charging Case is engineered to provide reliable power to your compatible true wireless earbuds. It includes a charging port for the case itself and dedicated slots for each earbud.

Key Features:

- **Charging Indicator:** An LED indicator displays the charging status of your earbuds and the power level of the case.
- **High Capacity Battery:** When fully charged, the case can recharge your earbuds up to 4 times.
- **Durable Material:** Constructed from PC material and soft ABS plastic for a comfortable and sturdy feel.
- **Safety Protection:** Integrated chip protects against short circuit, over-voltage, over-current, and over-charge.
- **Compatibility:** Specifically designed for Buds Live (SM R180). Includes a 3.3ft Type-C charging cable.



Figure 2.1: Top view of the open Cuifati Replacement Charging Case, showing the earbud slots and charging pins.



Figure 2.2: The Cuifati Replacement Charging Case shown with its included USB-C charging cable.

3. SETUP

3.1 Initial Charging of the Case

1. Connect the provided Type-C charging cable to the charging port on the back of the case.
2. Plug the other end of the cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The external LED indicator on the case will illuminate to show charging status. Allow the case to fully charge before first use.

3.2 Inserting Earbuds

1. Open the lid of the charging case.
2. Carefully place your for Buds Live earbuds into their respective slots. Ensure the 'L' (left) earbud goes into the left slot and the 'R' (right) earbud into the right slot.
3. Confirm that the earbuds are seated correctly and making proper contact with the charging pins. Incorrect placement may prevent charging.



Figure 3.1: Close-up view of the charging case interior, highlighting the 'L' and 'R' markings for correct earbud placement.

4. OPERATION

4.1 Charging Earbuds

1. Place the earbuds into the charging case as described in Section 3.2.
2. Close the lid of the charging case. The earbuds will begin charging automatically.
3. The internal LED indicator (if visible) or external LED will show the charging status of the earbuds.

4.2 Understanding the LED Indicator

The external LED indicator on the charging case provides information about the case's power level:

- **Red Light:** Indicates approximately 30% power remaining in the charging case.
- **Orange Light:** Indicates approximately 60% power remaining in the charging case.
- **Green Light:** Indicates the charging case is fully charged or has a high power level.

When earbuds are placed inside, the LED may also indicate their charging status. Refer to the specific behavior of your earbuds for detailed charging indications.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, dry, lint-free cloth to clean the exterior of the charging case.
- For the interior and charging pins, use a dry cotton swab or a soft brush to gently remove any dust or debris.
- Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the case.

5.2 Storage

- Store the charging case in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing the product with children's toys or other small items to prevent accidental ingestion or choking.
- If storing for an extended period, ensure the case has some charge to maintain battery health.

1 | Warning

Store the product separately from children's toys and other items to avoid accidental ingestion or choking.

2 | Warnung

Bitte bewahren Sie das Produkt getrennt von Kinderspielzeug und anderen Gegenständen auf, um versehentliches Verschlucken oder Erstickten zu vermeiden.

3 | Avertissement

Conservez le produit à l'écart des jouets d'enfants et d'autres articles afin d'éviter toute ingestion accidentelle ou tout étouffement par les enfants.

4 | Advertencia

Guarde el producto separado de los juguetes de los niños y de otros objetos para evitar que los niños lo ingieran accidentalmente o se atraganten.

5 | Ostrzeżenie

Przechowuj produkt osobno od zabawek dziecięcych i innych przedmiotów, aby uniknąć przypadkowego połknięcia lub zadławienia.

6 | Waarschuwing

Bewaar het product apart van kinderspeelgoed en andere voorwerpen om te voorkomen dat kinderen het per ongeluk inslikken of stikken.

7 | Varning

Förvara produkten åtskild från leksaker och andra föremål för att undvika att barn råkar svälja eller kväva den.

8 | Attenzione

Conservare il prodotto separatamente dai giocattoli dei bambini e da altri oggetti per evitare ingestione accidentale o soffocamento.

9 | Uyarı

Çocukların kazara yutmasını veya boğulmasını önlemek için ürünü çocuk oyuncaklarından ve diğer eşyalardan ayrı bir yerde saklayın.



Figure 5.1: Important safety warning regarding product storage.

6. TROUBLESHOOTING

- **Earbuds not charging:**

- Ensure the earbuds are correctly seated in their respective slots (L for left, R for right) and making firm contact with the charging pins.
- Check if the charging case itself has sufficient power (refer to LED indicator). Recharge the case if necessary.
- Clean the charging pins on both the earbuds and the case to ensure good contact.

- **Charging case not charging:**

- Verify that the USB-C cable is securely connected to both the case and the power source.
- Try using a different USB-C cable or power adapter to rule out faulty accessories.
- Ensure the power source is active and providing power.

- **LED indicator not working:**

- If the case is completely depleted, the LED may not light up immediately when plugged in. Allow a few minutes for it to register.
- If the issue persists, contact customer support.

- **Earbuds not fitting correctly:**

- This case is specifically designed for Buds Live (SM R180). It is not compatible with for Buds, for Buds+ Plus, or other earbud models. Ensure your earbuds are the correct model.

7. SPECIFICATIONS



Figure 7.1: Bottom of the charging case displaying model and electrical information.

Feature	Detail
Brand	Cuifati
Model Number	CUIFATlrqxb3hpse
Compatible Devices	for Buds Live SM R180
Color	Black
Form Factor	Case
Shell Type	Hybrid
Special Features	Wireless Charging Compatible
Item Weight	2.65 ounces
Package Dimensions	3.82 x 3.19 x 1.26 inches

8. WARRANTY AND SUPPORT

This Cuifati product is covered by a 90-day warranty from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For warranty claims, technical support, or any questions regarding your Cuifati Replacement Charging Case, please contact your retailer or visit the official Cuifati store page on Amazon for further assistance. Please have your purchase details and product model number ready when contacting support.

Online Support: [Cuifati Amazon Store](#)