

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aureday](#) /

› [Aureday 67-inch Phone and Camera Tripod Stand \(Model TBC001\) - Instruction Manual](#)

## Aureday TBC001

# Aureday 67-inch Phone and Camera Tripod Stand

Model: TBC001

## INTRODUCTION

Thank you for choosing the Aureday 67-inch Phone and Camera Tripod Stand. This versatile and durable tripod is designed to enhance your photography and videography experience, offering stability and flexibility for various devices. Please read this manual carefully to ensure proper setup and operation.

## WHAT'S IN THE BOX

- Aureday 67-inch Tripod Stand
- Phone Holder
- Wireless Remote
- GoPro Adapter



Image: Components included with the Aureday tripod stand.

## SETUP

## 1. Unfolding the Tripod Legs

1. Place the tripod on a flat, stable surface.
2. Gently pull the legs outwards until they are fully extended and form a stable base. Ensure all three legs are evenly spread for maximum stability.

## 2. Adjusting Height

1. Locate the quick-release clips on each section of the tripod shaft.
2. Flip open the clips to release the sections.
3. Extend the shaft to your desired height. The tripod can extend up to 67 inches.
4. Securely close all quick-release clips to lock the shaft sections in place.

# PRODUCT DIMENSION

## 5 Sections Highly Adjustable




Image: The tripod demonstrating its adjustable height settings, ranging from 18 inches to 67 inches.

## 3. Attaching the Phone Holder/Gooseneck

1. The tripod comes with a flexible gooseneck attachment. Screw the gooseneck onto the 1/4" universal screw at the top of the tripod shaft.

2. Attach the universal phone holder to the gooseneck. The phone holder can be adjusted to fit phones from 2.3" to 3.6" wide.
3. Alternatively, you can directly attach a GoPro camera, mini DSLR camera, or ring light using the 1/4" universal screw or the provided GoPro adapter.

## Flexible Head for Free Rotation



Image: The flexible gooseneck and phone holder allowing for versatile camera angles, including 360-degree pan and 180-degree tilt.

### 4. Pairing the Wireless Remote

1. Turn on the wireless remote by pressing and holding the power button. A blue indicator light will flash.
2. On your smartphone, go to Bluetooth settings and search for available devices.
3. Select 'AB Shutter3' (or similar name) to pair. The indicator light will stop flashing once paired.
4. The remote is compatible with most iOS (6.0+) and Android (4.2.2+) smartphones.

Pair with your phone fast and stable



Compatible with all **2.2-5.5 inch** cellphones




Image: Instructions for pairing the wireless remote with iOS and Android smartphones, showing the remote and phone holder.

## OPERATING INSTRUCTIONS

### 1. Adjusting Camera Angles

- The flexible gooseneck allows for 360° pan motion and 180° tilt motion, enabling you to capture photos and videos from various perspectives.
- Rotate the phone holder to switch between vertical and horizontal shooting modes as needed.

### 2. Using the Wireless Remote

- Once paired, use the remote to trigger your phone's camera shutter for photos or to start/stop video recording.
- This allows for hands-free operation, ideal for group photos, selfies, or stable video recording.

### 3. Device Compatibility

- The universal 1/4" screw and phone holder ensure wide compatibility with most smartphones, GoPro cameras, and mini DSLR cameras weighing under 2 KG.

# Ultra-wide Compatibility

Equipped with the 1/4" standard screw, suit for all kinds of devices



Cellphone



GoPro



Camera



Image: The tripod demonstrating its compatibility with various devices including cellphones, GoPro cameras, and traditional cameras.

## MAINTENANCE

### 1. Cleaning

- Wipe the tripod with a soft, dry cloth to remove dust and dirt.
- Avoid using harsh chemicals or abrasive materials that could damage the finish.

### 2. Storage

- When not in use, collapse the tripod to its minimum height (20 inches) and fold the legs.
- Store it in the provided carry bag to protect it from dust and damage.

# Compact and Easy to Carry

Super portable for your trip, just grab and go.



Image: The tripod in its compact, folded state, easily fitting into a backpack for travel.

## 3. Remote Battery Replacement

- The wireless remote uses 1 CR2032 battery (included).
- If the remote stops working, replace the battery by opening the battery compartment on the back of the remote.

## TROUBLESHOOTING

- **Tripod Instability:** Ensure all leg sections are fully extended and their quick-release clips are securely closed. The legs should be spread evenly to form a wide, stable base.
- **Remote Not Connecting:** Check if the remote's battery is charged. Ensure Bluetooth is enabled on your phone and the remote is in pairing mode. Try re-pairing the remote as described in the Setup section.
- **Phone Not Holding Securely:** Verify that your phone's width is within the holder's adjustable range (2.3" to 3.6"). Ensure the phone is centered and firmly gripped by the holder.
- **Gooseneck Sagging:** While the gooseneck is flexible, ensure your device's weight does not exceed the

tripod's maximum weight limit of 2 KG. Adjust the gooseneck to a position that provides optimal balance for your device.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	0.38 x 20.2 x 67 inches
Item Weight	1.2 pounds (544.31 Grams)
Model Number	TBC001
Batteries	1 CR2032 battery required (included)
Material	Aluminum
Maximum Height	67 Inches
Minimum Height	20 Inches
Weight Limit	2000 Grams (4.4 pounds)
Compatible Devices	Cell Phones (2.3" to 3.6" wide), GoPro Cameras, Mini DSLR Cameras, Ring Lights

## WARRANTY & SUPPORT

### Warranty Information

This product is covered by a 30-day return policy for refund or replacement when purchased from Amazon. For specific warranty details beyond this period, please refer to the manufacturer's official website or contact their customer service.

### Customer Support

For further assistance, product inquiries, or technical support, please visit the official Aureday Store on Amazon or contact Aureday customer service directly. You can find more information and contact options at the [Aureday Store](#).