

[Manuals.plus](#) /

› [OmniBreeze](#) /

› OmniBreeze Digital Electric Tower Fan User Manual

OmniBreeze DC2219/2220

OmniBreeze Digital Electric Tower Fan User Manual

Model: DC2219/2220

Brand: OmniBreeze

INTRODUCTION

This user manual provides detailed instructions for the safe and efficient operation of your OmniBreeze Digital Electric Tower Fan. Please read this manual thoroughly before use and retain it for future reference.






Figure 1: OmniBreeze Digital Electric Tower Fan with remote control.

SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Always unplug the fan before cleaning or performing maintenance.
- Do not insert fingers or foreign objects into any openings of the fan.
- Do not operate the fan with a damaged cord or plug.
- Ensure the fan is placed on a stable, level surface to prevent tipping.
- Keep the fan away from water and excessive humidity.
- This appliance is for indoor use only.

Stylish Bladeless Design



ETL listed



Fused
Safety Plug



Safety Grid



Figure 2: Safety features including ETL listing, fused safety plug, and safety grid.

PACKAGE CONTENTS

Please check the package for the following items:

- OmniBreeze Digital Electric Tower Fan Main Body
- Fan Base (two parts)
- Lock Nut
- Remote Control
- User Manual (this document)

SETUP

The OmniBreeze Tower Fan is designed for easy assembly. Follow these steps to set up your fan:

1. Carefully remove the main fan body, the two parts of the base, and the lock nut from the packaging.
2. Align the two parts of the fan base and snap them together.
3. Place the main fan body onto the assembled base, ensuring it is securely seated.
4. From the underside of the base, loosen the lock nut and then firmly tighten it to secure the fan body to the base.
5. Place the assembled fan on a flat, stable surface.
6. Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

Your OmniBreeze Tower Fan can be controlled using the touch panel on the top of the unit or the included remote control.

Control Panel and Remote Control Overview

Large Led Display With SmartTouch Control



Figure 3: Top control panel and remote control layout.

- **Power Button:** Turns the fan On or Off.
- **Speed Button:** Cycles through 4 fan speed options: Ultra-quiet, Low, Medium, and High.
- **Mode Button:** Selects from 4 fan modes:

- *Normal Mode*: Constant airflow at selected speed.
 - *Natural Mode*: Simulates a natural outdoor breeze with varying wind speeds.
 - *Sleep Mode*: Gradually decreases wind speed for comfortable nighttime operation.
 - *Auto Mode*: Automatically adjusts fan speed based on room temperature for optimized settings and energy savings.
- **Oscillation Button**: Activates or deactivates the wide-angle oscillation feature (90 degrees).
 - **Timer Button**: Sets the operating timer for up to 12 hours.
 - **Mute/Display Off Button**: Allows for silent operation and turns off the LED display, ideal for use in bedrooms or with sleeping individuals.

Fan Modes and Speeds

The fan offers versatile settings to suit various cooling needs:

- **4 Fan Modes**: Normal, Natural, Sleep, Auto.
- **4 Fan Speeds**: Ultra-quiet, Low, Medium, High.

Silent Operation

Max **52**dB



Figure 4: The fan operates with a maximum noise level of 52dB, suitable for quiet environments.

Wide Angle Oscillation



Figure 5: The fan's 90-degree oscillation feature distributes cool air widely.

Wind Speed Up To 26ft/s Enjoy The Chill In Summer




Figure 6: The fan delivers powerful airflow up to 26 feet per second.

Humanized design

Mute / Timer OFF / Display OFF



Figure 7: Humanized design features like mute, timer off, and display off for enhanced user comfort.

Regular cleaning will help maintain the fan's performance and extend its lifespan.

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- To clean the air intake and outlet grilles, use a vacuum cleaner with a brush attachment or a soft brush to remove dust and debris.
- Ensure all parts are completely dry before plugging the fan back in.

TROUBLESHOOTING

If you encounter issues with your OmniBreeze Tower Fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Weak airflow.	Air intake/outlet blocked; fan speed set too low.	Clean any dust or obstructions from the grilles. Increase the fan speed setting.
Fan makes unusual noise.	Fan not on a level surface; internal obstruction.	Place the fan on a flat, stable surface. Unplug and check for any foreign objects inside the grilles.
Remote control not working.	Batteries dead or incorrectly inserted; remote too far from fan.	Replace batteries. Ensure correct polarity. Operate remote within 20ft of the fan.

If the problem persists after attempting these solutions, please contact OmniBreeze customer support.

SPECIFICATIONS

Feature	Detail
Brand	OmniBreeze
Model Name	DC2220 (Item model number: DC2219/2220)
Color	Black
Electric Fan Design	Floor Fan
Power Source	Corded Electric
Product Dimensions	11.42"D x 11.42"W x 36"H
Room Type	Living Room, Bedroom
Special Feature	Oscillation
Recommended Uses	Cooling
Noise Level	52 dB

Feature	Detail
Wattage	50 watts
Air Flow Capacity	540 Cubic Meters per Minute
Voltage	120 Volts
Included Components	Remote
Indoor/Outdoor Usage	Indoor
Specification Met	ETL
Control Method	Remote, Touch
Blade Material	Plastic
Item Weight	9.38 pounds
UPC	819079023496
Date First Available	February 17, 2023

WARRANTY AND SUPPORT

For warranty information or technical support, please contact OmniBreeze customer service through their official website or the contact details provided with your purchase. Please have your model number (DC2219/2220) and purchase date available when contacting support.

OFFICIAL PRODUCT VIDEOS

No official seller videos are available for this product at this time.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW31K26H>

More documents and user manuals: <https://manuals.plus/>