

- Manuals.plus /
- › Bellemave /
- › Bellemave LED TV Stand (Model: Table) Instruction Manual

Bellemave Table

Bellemave LED TV Stand Instruction Manual

Model: Table

		Introduction	Safety Information	Package		
Contents	Assembly	Operation	Maintenance	Troubleshooting	Specifications	Warranty & Support

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bellemave LED TV Stand. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and safe operation. Keep this manual for future reference.



Image 1.1: Front view of the Bellemave LED TV Stand.

2. SAFETY INFORMATION

Observe the following safety precautions during assembly and use:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 319 lbs (144.7 kg) for the TV stand. Overloading can cause instability and damage.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened securely before use. Improper assembly can lead to structural failure.
- **Placement:** Place the TV stand on a flat, level, and stable surface to prevent tipping.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- **Electrical Safety:** When connecting the LED lighting, ensure the power source is appropriate and connections are secure. Avoid exposing electrical components to moisture.
- **Moving:** If moving the assembled unit, lift it carefully with assistance. Do not drag, as this may damage the unit or flooring.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Main MDF board panels (top, bottom, side panels)
- Cabinet doors (2 units)
- Tempered glass shelves (2 units)
- LED strip light with remote control
- Assembly hardware (screws, dowels, hinges, shelf pins, etc.)
- Assembly instructions sheet



Image 3.1: View of the TV stand with cabinet doors open, showing internal compartments.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have a power drill for easier assembly. Follow the steps below carefully.

4.1. Tools Required

- Phillips head screwdriver
- Power drill (recommended)
- Hammer (for dowels)

4.2. Step-by-Step Assembly

1. **Unpack and Identify Parts:** Carefully unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each piece.
2. **Assemble Base Structure:** Connect the bottom and side panels using the provided dowels and screws. Ensure all connections are tight and flush.
3. **Install Shelves:** Insert shelf pins into the pre-drilled holes for the tempered glass shelves. Carefully place the glass shelves onto the pins.
4. **Attach Cabinet Doors:** Secure the hinges to the cabinet doors and then attach the doors to the main structure. Adjust hinges as needed for proper alignment.
5. **Install LED Lighting:** Adhere the LED strip light to the designated area, typically along the underside of the top panel or within the open shelf area. Connect the power adapter and remote receiver.
6. **Final Check:** Verify that all screws are tightened, and the stand is stable.



Image 4.1: Detail of the tempered glass shelves.

5. OPERATING INSTRUCTIONS (LED LIGHTING)

Your Bellemave LED TV Stand features a 16-color LED strip light to enhance your entertainment experience.

5.1. Connecting the LED Lights

1. Ensure the LED strip is securely attached to the TV stand.
2. Connect the LED strip to the receiver box.
3. Plug the power adapter into the receiver box and then into a standard electrical outlet.

5.2. Using the Remote Control

Use the provided remote control to operate the LED lights:

- **Power Button:** Turn the LED lights On or Off.
- **Color Selection:** Press the color buttons to choose from 16 different static colors.
- **Brightness Adjustment:** Use the brightness up/down buttons to adjust the intensity of the light.
- **Mode Selection:** Cycle through various dynamic modes (e.g., flash, strobe, fade, smooth) for different lighting effects.



Image 5.1: The TV stand illuminated with blue LED lighting.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your TV stand.

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the UV high gloss finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or damage to the wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **LED Lights:** If the LED strip or remote control malfunctions, refer to the troubleshooting section or contact customer support.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

7.1. LED Lights Not Working

- **Check Power Connection:** Ensure the power adapter is securely plugged into both the receiver box and a working electrical outlet.
- **Remote Control Battery:** Replace the battery in the remote control if the lights do not respond.
- **Receiver Line of Sight:** Ensure there are no obstructions between the remote control and the LED receiver.
- **LED Strip Connection:** Verify that the LED strip is properly connected to the receiver box.

7.2. Stand is Unstable

- **Level Surface:** Ensure the TV stand is placed on a completely flat and level surface.
- **Tighten Fasteners:** Recheck and tighten all assembly screws and connections.
- **Weight Distribution:** Ensure weight is evenly distributed on the stand and not exceeding the maximum capacity.

8. SPECIFICATIONS

Product Type	TV Stand
Shape	Rectangle
Color	Black
Product Material	MDF board, Tempered Glass
Finish Application	Veneer (UV High Gloss)
Overall Product Dimensions	70.8"L x 14.9"W x 14.9"H (179.8cm L x 37.8cm W x 37.8cm H)
Weight Capacity	319 lbs (144.7 kg)
Number of Shelves	2 (Tempered Glass)
Number of Cabinets	2
Built-In Lighting	Yes (16-color LED strip)
Clearance - Floor to Bottom	0.78 inch (2 cm)
Assembly Required	Yes
Country of Origin	China



9. WARRANTY & SUPPORT

9.1. Warranty Information

Specific warranty details for this product may vary. Please refer to your purchase documentation or contact the seller/manufacturer directly for information regarding warranty coverage, terms, and conditions.

9.2. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support through the retailer where the product was purchased or visit the official Bellemave website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW3XSS95>

More documents and user manuals: <https://manuals.plus/>