

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Stainless Steel Smartwatch Band Instruction Manual for EIGIIS K55 and Compatible Models

## Lamshaw Stainless Steel Smartwatch Band

# Lamshaw Stainless Steel Smartwatch Band Instruction Manual

For EIGIIS K55, PUREROYI C21/C20 Pro, VALYV K22, Bassizo K55, TAOPON NX3, LENUMB NX3, Moowhsh HM09 Smartwatches

## 1. PRODUCT OVERVIEW

---

This manual provides detailed instructions for the installation, adjustment, and maintenance of your Lamshaw Stainless Steel Smartwatch Band. This band is designed as a replacement strap for various smartwatches, offering durability and a refined aesthetic.

### Compatible Smartwatch Models:

- EIGIIS K55
- PUREROYI 1.32" C21/C20 Pro
- VALYV K22
- EIGIIS K22
- Bassizo K55
- TAOPON NX3 1.85
- LENUMB NX3 1.85
- Moowhsh HM09



Figure 1: Lamshaw Stainless Steel Smartwatch Band on a compatible smartwatch.

## 2. SETUP AND INSTALLATION

### 2.1 Package Contents

Your package should include the following items:

- Lamshaw Stainless Steel Smartwatch Band
- Spring bars (pins) for attachment
- Link removal tool



Figure 2: Package contents including the watch band, spring bars, and link removal tool.

## 2.2 Attaching the Band to Your Smartwatch

1. Locate the spring bar holes on your smartwatch and on the ends of the band.
2. Insert one end of a spring bar into a lug hole on the smartwatch.
3. Using the spring bar tool (or your fingernail), compress the other end of the spring bar and guide it into the corresponding lug hole on the smartwatch.
4. Gently pull on the band to ensure it is securely attached. Repeat for the other side of the band.

## 2.3 Adjusting Band Length (Link Removal)

The band can be adjusted to fit wrist sizes from 5.71" to 8.19" (145mm-208mm) by removing or adding links. A link removal tool is provided for this purpose.

# AVAILABLE LENGTH

Fit 145-265mm(5.70"-10.43") wrist with adjustable magnetic clasp




Figure 3: Wrist size compatibility for the adjustable band (5.71"-8.19" or 145mm-208mm). Note: This band adjusts by removing links, not with a magnetic clasp as depicted in the generic diagram text.

## Instructions for Link Removal:

1. Place the band into the link removal tool with the arrow on the band pointing downwards, aligning the pin with the tool's pusher.
2. Slowly turn the screw on the tool to push the pin out from the link.
3. Once the pin is partially out, you can pull it completely with your fingers or pliers.
4. Remove the desired number of links. Ensure an even number of links are removed from each side of the clasp for balanced wear.
5. To reassemble, align the links and insert the pin back into the holes. Use the tool to gently push the pin back in until it is flush with the band.

# Link Removal Tool Instructions


① Push from the side of the depression



② Screwed out the pin gradually



③ Repeat step ① and ② to remove more links



④ Slowly screw the pin until it goes in to the band completely



Figure 4: Detailed steps for using the link removal tool.

## 3. OPERATING THE CLASP

The Lamshaw Stainless Steel Smartwatch Band features a double-button folding clasp for secure and convenient wear.



Figure 5: Double-button folding clasp mechanism.

**To open the clasp:** Press the two side buttons simultaneously. The clasp will release, allowing you to put on or take off the smartwatch.

**To close the clasp:** Fold the clasp mechanism until it clicks securely into place. Ensure both sides are fully engaged to prevent accidental opening.

## 4. MAINTENANCE AND CARE

---

- **Cleaning:** Wipe the band regularly with a soft, damp cloth to remove dirt, sweat, and oils. For stubborn grime, a mild soap solution can be used, followed by thorough rinsing and drying.
- **Avoid Chemicals:** Do not expose the band to harsh chemicals, solvents, or strong detergents, as these can damage the finish.
- **Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the spring bars and clasp for any signs of wear or damage. Ensure all pins are securely in place.

## 5. TROUBLESHOOTING

- **Band does not attach securely:** Ensure the spring bars are correctly seated in the lug holes of your smartwatch. Verify that the spring bars are not bent or damaged.
- **Clasp is difficult to open/close:** Check for any debris or foreign objects obstructing the clasp mechanism. Ensure the buttons are pressed simultaneously and fully.
- **Band is too loose or too tight:** Refer to Section 2.3 for instructions on adjusting the band length by adding or removing links.
- **Pins are difficult to remove/insert during adjustment:** Ensure the link removal tool is properly aligned with the pin. Apply steady, even pressure. If a pin is bent, it may need replacement.

## 6. SPECIFICATIONS

| Feature                        | Specification                           |
|--------------------------------|-----------------------------------------|
| Product Name                   | Lamshaw Stainless Steel Smartwatch Band |
| Material                       | Stainless Steel                         |
| Clasp Type                     | Double Button Folding Clasp             |
| Adjustable Wrist Size          | 5.71" - 8.19" (145mm - 208mm)           |
| Color (as per current variant) | Black                                   |
| ASIN (Parent)                  | B0BW4324GK                              |
| Date First Available           | February 17, 2023                       |

## 7. WARRANTY AND SUPPORT

For 30 days after the date of purchase, Lamshaw addresses all quality-related issues with a replacement or refund. If you encounter any defective items or require assistance, please contact the seller directly.

**Contact Information:** Please refer to your purchase documentation or the seller's information on the platform where the product was purchased for direct contact details.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0BW4324GK>

More documents and user manuals: <https://manuals.plus/>