

[Manuals.plus](#) /

> [Philips](#) /

> Philips Airfryer 5000 Series XXL User Manual

## Philips HD9285/90

# Philips Airfryer 5000 Series XXL User Manual

Model: HD9285/90

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Philips Airfryer 5000 Series XXL. Please read it thoroughly before first use and keep it for future reference.

The Philips Airfryer 5000 Series XXL is designed to offer a versatile cooking experience with 16-in-1 functions, including frying, baking, roasting, grilling, defrosting, and more, utilizing Rapid Air Technology for healthier meals with up to 90% less fat.

## SAFETY INFORMATION

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance in water or any other liquid.
- Keep the appliance and its cord out of reach of children.
- Do not block the air inlet and outlet openings.
- Unplug the appliance when not in use and before cleaning.
- Only use accessories recommended by Philips.

## PRODUCT OVERVIEW



Image: Front view of the Philips Airfryer 5000 Series XXL, showcasing its digital display and control panel.

The Philips Airfryer 5000 Series XXL features a large 7.2L pan and a 1.4kg basket, suitable for preparing meals for up to 6 persons. It is equipped with a touchscreen display for easy operation and offers Wi-Fi connectivity for remote control via the HomeID app.



Image: The Philips Airfryer 5000 Series XXL with a Wi-Fi symbol indicating its connectivity feature.

## SETUP AND FIRST USE

### Unboxing and Initial Cleaning

1. Remove all packaging materials and stickers from the appliance.
2. Clean the basket and pan thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a moist cloth.
4. Ensure all parts are completely dry before use.

### Connecting to Wi-Fi and HomeID App

Your Airfryer can be connected to the HomeID app for remote control and access to personalized recipes.

1. Download the HomeID app from your smartphone's app store.
2. Follow the in-app instructions to pair your Philips Airfryer with your Wi-Fi network.
3. Once connected, you can monitor cooking progress and select recipes remotely.



Image: A user interacting with the HomeID app on a smartphone, demonstrating remote control capabilities for the Airfryer.

## OPERATING INSTRUCTIONS

### Basic Operation

1. Place the appliance on a stable, level, and heat-resistant surface.
2. Pull the pan out of the Airfryer.
3. Place ingredients into the basket. Do not exceed the MAX indication.
4. Slide the pan back into the Airfryer.
5. Plug the main plug into a wall socket.
6. Select a preset cooking program or manually set the temperature and time using the touchscreen display.

7. Press the start/pause button to begin cooking.



Image: The Airfryer with its cooking basket extended, filled with a variety of cooked items, demonstrating its capacity.

## 16-in-1 Cooking Functions

Your Airfryer offers a wide range of cooking possibilities:

- **Frying:** For crispy results with minimal oil.
- **Baking:** Ideal for cakes, muffins, and pastries.
- **Roasting:** Perfect for meats and vegetables.
- **Grilling:** Achieve grilled textures and flavors.
- **Defrosting:** Safely thaw frozen foods.
- **Fermenting:** For preparing dough or yogurt.
- And many more, accessible via the touchscreen or HomeID app.



Image: The Airfryer with a graphic emphasizing its 16-in-1 cooking versatility.

### **Rapid Air Technology**

The unique 'starfish' design of the Rapid Air Technology ensures optimal hot air circulation, resulting in food that is crispy on the outside and tender on the inside, with significantly less fat.



Image: An internal view of the Airfryer illustrating the hot air flow generated by Rapid Air Technology for even cooking.

## CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your Airfryer.

### Cleaning the Basket and Pan

- Unplug the Airfryer and allow it to cool down completely before cleaning.
- The QuickClean basket with non-stick coating and the pan are dishwasher-safe.
- Alternatively, clean them with hot water, dishwashing liquid, and a non-abrasive sponge.
- For stubborn residue, soak the pan and basket in hot water with some dishwashing liquid for approximately 10 minutes.



## Makkelijk schoon te maken

Alle verwijderbare onderdelen zijn vaatwasmachinebestendig

Image: The removable basket and pan of the Airfryer positioned in a dishwasher, highlighting their dishwasher-safe feature.

### Cleaning the Interior and Exterior

- Wipe the exterior of the appliance with a moist cloth.
- Clean the interior with hot water and a non-abrasive sponge.
- Remove any food residue from the heating element using a cleaning brush.

### TROUBLESHOOTING

Problem	Possible Cause	Solution
The Airfryer does not work.	The appliance is not plugged in.	Plug the main plug into an earthed wall socket.
Food is not cooked evenly.	Too much food in the basket; temperature or time settings incorrect.	Reduce food quantity; adjust temperature/time; shake basket during cooking.

Problem	Possible Cause	Solution
White smoke comes out of the appliance.	Fat residues from previous use; too much oil used.	Clean the pan and basket thoroughly; use less oil.
Appliance not connecting to Wi-Fi.	Incorrect Wi-Fi password; out of range; router issues.	Verify password; move appliance closer to router; restart router.
Appliance takes too long to heat up.	Incorrect temperature setting; preheating not done.	Ensure correct temperature is set; allow for preheating time.

## SPECIFICATIONS

**Brand:** Philips

**Model Number:** HD9285/90

**Color:** Black

**Product Dimensions:** 41 x 30 x 33 cm (D x W x H)

**Capacity:** 7.2 Liters (1.4 kg)

**Power/Wattage:** 2000 Watts

**Voltage:** 220 VAC

**Material:** Metal

**Special Features:** Rapid Air Technology, 16-in-1 Airfryer, Wi-Fi Connected

## WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or visit the official Philips website. For technical support, troubleshooting assistance, or to inquire about spare parts, please contact Philips customer service. You can find contact details for Philips customer support on their official website or in the documentation provided with your appliance.

### Online Resources:

- Philips Official Website: [www.philips.com](http://www.philips.com)
- HomeID App Support: Refer to the app's help section for specific guidance.