Garmin Alpha 300

Garmin Alpha 300 Handheld User Manual

Advanced Tracking and Training Handheld

1. Introduction

The Garmin Alpha 300 is a robust handheld device designed for advanced dog tracking and training. It enables users to monitor and train up to 20 dogs simultaneously, offering a range of up to 9 miles with a rapid 2.5-second update rate. The device features a vivid 3.5-inch capacitive touchscreen display and intuitive button controls for efficient operation. Integrated navigation capabilities include preloaded TopoActive maps, satellite imagery, a 3-axis compass, and a barometric altimeter. The Alpha 300 is equipped with a user-replaceable battery providing up to 55 hours of operation.





Figure 1.1: Garmin Alpha 300 Handheld with map display.

2. Setup

2.1 What's in the Box

- Alpha 300 handheld device
- Rechargeable lithium-ion battery pack (pre-installed)
- Belt clip
- AC adapter
- Type-A to Type-C USB cable
- Documentation (this manual and other guides)

2.2 Charging the Device

1. Connect the small end of the USB cable to the USB-C port on the Alpha 300 handheld.
2. Connect the large end of the USB cable to the AC adapter.
3. Plug the AC adapter into a standard wall outlet.
4. Allow the device to charge completely before first use. The battery indicator on the screen will show charging status.

2.3 Powering On/Off

- To power on: Press and hold the power button located on the side of the device until the screen illuminates.
- To power off: Press and hold the power button, then select 'Power Off' on the screen.

2.4 Initial Device Pairing with Dog Collars

The Alpha 300 is compatible with various Garmin dog collars, including existing T and TT series collars. Refer to your dog collar's specific manual for pairing instructions. Generally, ensure both devices are powered on and in pairing mode, then follow the on-screen prompts on the Alpha 300 to add a new dog.

3. Operating Instructions

3.1 Basic Navigation and Interface

The Alpha 300 features a 3.5-inch capacitive touchscreen and physical buttons for navigation. Use the touchscreen for menu selection and map interaction. Physical buttons provide quick access to frequently used functions, even when wearing gloves.

3.2 Dog Tracking

Monitor the location and status of up to 20 dogs from a distance of up to 9 miles. The device provides location updates every 2.5 seconds, ensuring near real-time tracking.





Figure 3.1: Compass view showing dog directions and distances.

- **Dog List and Group Management:** Organize and manage your dogs. Non-paired dog information can be stored for easier setup in the future.
- **Channel View:** Monitor collar concentration in the area to select less congested channels, minimizing interference.
- **Hunt Metrics:** Access data on each dog's daily hunting patterns and behaviors, allowing for informed adjustments to ensure their safety and health.




Figure 3.2: Dog list management screen.

3.3 Dog Training

When paired with a compatible training-enabled collar, the Alpha 300 provides 18 levels of momentary and continuous stimulation. It also supports audible tone or vibration commands.



Figure 3.3: Training control interface.

3.4 Navigation Features

The Alpha 300 includes advanced navigation tools to assist in the field:

- **Preloaded TopoActive Maps:** Detailed topographic maps for North America.
- **Satellite Imagery:** Downloadable satellite imagery provides a clear view of terrain features.
- **3-Axis Compass:** A tilt-compensated electronic compass provides accurate heading information whether you are moving or stationary.
- **Barometric Altimeter:** Accurately monitors ascent and descent, providing precise elevation data.



Features a vivid sunlight-readable 3.5″ capacitive touchscreen display and a button-operated, dog-focused design for quick adjustments.

Figure 3.4: Map screen with satellite imagery.

3.5 Garmin Explore App Integration

Pair the Alpha 300 with the Garmin Explore website and smartphone app to manage tracks, routes, and waypoints. Review statistics from the field and back up your device settings for comprehensive data management.

4. Maintenance

4.1 Battery Care

The Alpha 300 uses a user-replaceable lithium-ion battery, offering up to 55 hours of life. To maximize battery lifespan:

- Avoid extreme temperatures.
- Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- If storing the device for a long time, charge it to about 50% and store in a cool, dry place.

4.2 Cleaning the Device

Wipe the device with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the

screen or casing.

4.3 Software Updates

Keep your device's software up to date to ensure optimal performance and access to the latest features. Updates can often be delivered wirelessly when connected to a Wi-Fi network, especially with an Outdoor Maps+ subscription.

5. Troubleshooting

5.1 Device Not Powering On

- Ensure the battery is fully charged. Connect the device to the AC adapter and allow it to charge for at least 30 minutes.
- Verify the battery is properly seated in the device.

5.2 Unable to Connect to Dog Collar

- Ensure both the Alpha 300 and the dog collar are powered on and within range.
- Check that the dog collar's battery is charged.
- Confirm that the collar is not already paired with another handheld device.
- Perform a factory reset on both devices if connection issues persist, then attempt pairing again. Ensure both devices have the latest firmware.
- Minimize interference by attempting to pair away from other wireless devices or strong Wi-Fi signals.

5.3 GPS Signal Issues

- Ensure the device has a clear view of the sky. GPS signals can be obstructed by dense foliage, buildings, or deep canyons.
- Allow the device sufficient time to acquire satellites, especially after being off for an extended period or moved a significant distance.

For further troubleshooting or technical support, please visit the official Garmin support website or contact their customer service.

6. Specifications

Feature	Specification
Model Name	Alpha 300
Item Model Number	010-02807-50
Product Dimensions	2.7 x 6.4 x 1.3 inches
Item Weight	9.9 ounces
Screen Size	3.5 Inches
Display Resolution	320 x 480 pixels

Feature	Specification
Human Interface Input	Buttons, Touchscreen
Operating System	Proprietary Garmin OS
Connectivity Technologies	Bluetooth
Battery Type	1 Lithium Ion battery (included, user-replaceable)
Battery Life	Up to 55 Hours
Map Type	North America (TopoActive)

7. Warranty and Support

For detailed warranty information, please refer to the official Garmin website or the warranty card included with your product. Garmin provides customer support and resources for product registration, software updates, and troubleshooting.

Garmin Support: www.garmin.com/support

© 2023 Garmin Ltd. or its subsidiaries. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question