



Manuals.plus /

› Five /

› 5Five Blackacia Single Laundry Basket User Manual

Five Blackacia Single Laundry Basket

5Five Blackacia Single Laundry Basket User Manual

INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of your 5Five Blackacia Single Laundry Basket. Please read these instructions carefully before use and retain them for future reference.



Figure 1: Assembled 5Five Blackacia Single Laundry Basket.

PRODUCT COMPONENTS

The 5Five Blackacia Single Laundry Basket includes the following components:

- Wooden frame (disassembled)

- Fabric laundry liner (black, polyester)
- Assembly hardware (screws, Allen key if required)



Figure 2: Product packaging indicating removable and washable liner.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all listed components are present.
2. **Assemble Wooden Frame:** Follow the included diagram (if any) to connect the wooden frame pieces using the provided hardware. Ensure all screws are tightened securely for stability.
3. **Insert Fabric Liner:** Place the black polyester fabric liner into the assembled wooden frame. The liner should fit snugly within the frame.
4. **Position Basket:** Place the assembled laundry basket in your desired location.

OPERATING INSTRUCTIONS

The 5Five Blackacia Single Laundry Basket is designed for collecting and storing dirty laundry. Its portable design allows for easy transport.

- **Loading Laundry:** Place dirty clothes directly into the fabric liner. Do not overload the basket beyond its 50-liter capacity to prevent damage to the frame or liner.
- **Transporting Laundry:** The basket is portable. When full, lift the basket by its wooden frame to transport laundry to your washing machine. Avoid dragging the basket.

MAINTENANCE

Regular maintenance will extend the life of your laundry basket.

- **Fabric Liner:** The fabric liner is removable and washable. It can be machine washed at 30°C. Allow to air dry completely before reinserting into the frame. Do not bleach or tumble dry.
- **Wooden Frame:** Wipe the wooden frame with a damp cloth as needed. Avoid using harsh chemical cleaners that may damage the wood finish. Ensure the frame is dry after cleaning.
- **General Care:** Periodically check all screws and connections on the wooden frame to ensure they remain tight. Tighten if necessary.

TROUBLESHOOTING

- **Basket feels unstable:** Ensure all screws in the wooden frame are securely tightened. If the issue persists, disassemble and reassemble the frame, ensuring all parts are correctly aligned.
- **Fabric liner does not fit:** Ensure the liner is oriented correctly within the frame. If it still does not fit, check for any obstructions or misaligned frame parts.
- **Damage to components:** If any part of the wooden frame or fabric liner arrives damaged or becomes damaged during normal use, please contact customer support for assistance.

SPECIFICATIONS

Model Number	Five - Panier à Linge
Brand	Five
Dimensions (L x W x H)	42L x 30.2W x 62H cm
Capacity	50 Liters
Material	Polyester (liner), Wood (frame)
Color	Dark Natural and Black
Special Features	Portable, Removable and Washable Liner
Country of Origin	China



Figure 3: Product dimensions diagram.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Five

