

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [METOO](#) /

> METOO Flip Cover for REALME C20 / RMX3063 Instruction Manual

## METOO REALME C20, RMX3063

# METOO Flip Cover Instruction Manual

For REALME C20 and RMX3063 Models

## 1. PRODUCT OVERVIEW

---

The METOO Flip Cover is designed to protect your REALME C20 or RMX3063 smartphone while offering additional functionality. It features a durable faux leather exterior, precise cutouts for ports and buttons, and integrated wallet features.



*Image 1: The METOO Flip Cover in a closed position, showcasing its faux leather texture and magnetic clasp.*

### Key Features:

- **Premium Faux Leather:** Provides a sophisticated look and feel.
- **Anti-Slip Texture:** Enhances grip for secure handling.
- **Precise Cutouts:** Ensures full access to all camera, speaker, port, and button functions.

- **Magnetic Clasp:** Secures the cover in place when closed.
- **Wallet Stand Design:** Includes card slots, a bill compartment, and a kickstand function for hands-free viewing.
- **Shock Proof Technology:** Bumpers with anti-shock cushion technology protect against drops.
- **Raised Lips:** Protects the screen and camera from direct surface contact.



*Image 2: The METOO Flip Cover open, displaying its three card slots, one bill compartment, and a phone inserted, demonstrating its wallet design.*

## 2. INSTALLATION GUIDE

Follow these steps to properly install your REALME C20 or RMX3063 smartphone into the METOO Flip Cover.

1. **Prepare Your Device:** Ensure your smartphone is clean and free of dust or debris.
2. **Align the Phone:** Gently align your REALME C20 or RMX3063 with the soft inner casing of the flip cover. The hard but flexible material of the case is designed for easy fitting.
3. **Insert the Phone:** Carefully push your phone into the case, starting with one side, then pressing the other side until it snaps securely into place. Ensure all edges of the phone are seated within the case.
4. **Verify Fit:** Check that all buttons (power, volume) and ports (charging, headphone jack) are accessible through the precise cutouts. The case should fit snugly without obstructing any functions.
5. **Close the Cover:** Close the front flap of the cover and ensure the magnetic clasp engages to keep it securely shut.

## ACCURATE PORTS

Precise cut-out allows all ports & buttons accessible and also talking with the case closed



*Image 3: Detailed view of the METOO Flip Cover's precise cutouts, ensuring full access to all ports and buttons even when the case is closed.*

### 3. OPERATION

---

The METOO Flip Cover offers several operational features to enhance your smartphone experience.

- **Magnetic Closure:** The gentle yet firm magnetic clasp keeps the cover securely closed, protecting your screen when not in use. To open, simply lift the flap.
- **Wallet Functionality:** Utilize the integrated card slots for IDs or credit cards and the bill compartment for cash. This design minimizes bulk for everyday carry.
- **Kickstand Feature:** To activate the kickstand, fold the back of the cover to create a triangular support. This allows for hands-free viewing of videos or video calls in landscape mode.
- **Full Port Access:** The precise cutouts ensure that all ports, speakers, and buttons remain fully functional and accessible even with the cover installed. You can talk on the phone with the case closed.

## 4. MAINTENANCE AND CARE

---

To ensure the longevity and appearance of your METOO Flip Cover, follow these care instructions:

- **Cleaning:** Wipe the faux leather surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these can damage the material.
- **Avoid Extreme Conditions:** Do not expose the cover to direct sunlight for prolonged periods or to extreme temperatures, which can cause the material to fade or crack.
- **Prevent Scratches:** While the cover offers protection, avoid placing it with sharp objects that could scratch the faux leather.
- **Magnetic Clasp Care:** Ensure the magnetic clasp area remains clean and free of metallic debris that could interfere with its function.

## 5. TROUBLESHOOTING

---

If you encounter any issues with your METOO Flip Cover, consider the following common solutions:

- **Difficulty Installing/Removing Phone:** The case is designed to be snug. Apply gentle, even pressure. If it feels excessively tight, ensure your phone model (REALME C20 or RMX3063) is compatible with the cover.
- **Ports or Buttons Blocked:** Re-check the installation of your phone within the case. Ensure it is fully seated and aligned with all cutouts. The case features precise cutouts for full accessibility.
- **Magnetic Clasp Not Holding:** Ensure there is no debris obstructing the magnetic contact points. If the issue persists, the magnetic strength may be affected by excessive cards in the wallet slots. Try removing some cards.
- **Kickstand Not Stable:** Ensure the fold is firm and creates a stable triangular base. The stability may vary depending on the surface it is placed on.

## 6. SPECIFICATIONS

---

<b>Brand</b>	METOO
<b>Compatible Phone Models</b>	REALME C20, RMX3063
<b>Material</b>	Faux Leather
<b>Form Factor</b>	Flip
<b>Special Features</b>	Card Slot, Kickstand, Magnetic
<b>Color</b>	Black
<b>Manufacturer</b>	VIMLESH ENTERPRISES

## 7. WARRANTY AND SUPPORT

---

Specific warranty details for the METOO Flip Cover are not provided within this manual. For warranty claims, product support, or further assistance, please refer to the product packaging or contact the retailer or manufacturer.

directly.

Manufacturer: VIMLESH ENTERPRISES