

Skyworth 65SUE9350F

Skyworth 65SUE9350F 65-inch 4K UHD LED Google Smart TV User Manual

Model: 65SUE9350F

INTRODUCTION

This manual provides comprehensive instructions for the Skyworth 65SUE9350F 65-inch 4K UHD LED Google Smart TV. It covers setup, operation, maintenance, and troubleshooting to ensure you get the most out of your television. This smart TV features Google TV, built-in Chromecast, hands-free voice control, and supports various streaming services like Netflix, Prime Video, Disney+, and YouTube.

IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using your television. Keep this manual for future reference.

- **Power Supply:** Ensure the TV is connected to a power source within the specified voltage range (100-240V AC, 50/60Hz).
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Placement:** Place the TV on a stable, level surface. If wall-mounting, use a VESA-compatible mount (600 x 400 mm) and ensure it is securely installed.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that all the following items are included in your package:

- Skyworth 65SUE9350F 65-inch 4K UHD LED Google Smart TV
- Remote Control (requires 2 batteries)
- TV Stand
- Power Cable
- User Manual (this document)

SETUP GUIDE

1. Attaching the Stand

If you are not wall-mounting your TV, you will need to attach the included stand. Carefully place the TV face down on a soft, clean surface to prevent screen damage. Align the stand with the mounting holes on the bottom of the TV and secure it with the provided screws.



Image: Front view of the Skyworth 65SUE9350F TV with its stand attached, showing the sleek design.

2. Wall Mounting (Optional)

For wall mounting, ensure you use a VESA-compatible wall mount kit (600 x 400 mm). Follow the instructions provided with your wall mount kit. It is recommended to have professional assistance for wall mounting.




Image: Rear view of the Skyworth 65SUE9350F TV, highlighting the VESA mounting points and various input ports.

3. Connecting External Devices

Connect your external devices such as Blu-ray players, game consoles, or sound systems to the TV's ports. The TV features multiple connectivity options:

- **HDMI Ports (x3):** For high-definition audio and video.
- **USB Ports (x2):** For connecting USB storage devices.
- **Ethernet Port:** For a wired internet connection.
- **Bluetooth 5.1:** For wireless audio devices and remote control.
- **Wi-Fi:** For wireless internet connection.






Image: Side profile of the Skyworth 65SUE9350F TV, displaying the accessible HDMI, USB, and other input/output ports.

4. Power Connection

After connecting all necessary devices, plug the power cable into the TV and then into a wall outlet.

5. Initial Setup

Upon first power-on, the TV will guide you through the initial setup process. This includes:

1. Language selection.
2. Connecting to a Wi-Fi network or using an Ethernet connection.
3. Signing in with your Google account to access Google TV features and apps.

4. Scanning for available TV channels (if connecting an antenna/cable).

OPERATING YOUR TV

Remote Control and Voice Control

The included remote control allows you to navigate the Google TV interface. It also supports voice search. To use hands-free voice control, simply say "Hey Google" followed by your command or query. This allows you to search for shows, get recommendations, and control TV functions without pressing buttons.

Google TV Interface

Google TV organizes your content from various streaming services into a single, personalized interface. It provides recommendations based on your viewing history and preferences. You can access your favorite apps directly from the home screen.

Streaming Services and Apps

Your TV comes with popular streaming apps pre-installed, including Netflix, Prime Video, Disney+, and YouTube. You can download more applications from the Google Play Store.

Chromecast Built-in

Use the built-in Chromecast feature to easily cast content (movies, music, photos) from your compatible smartphone, tablet, or computer directly to your TV screen.

Picture and Sound Settings

Access the TV settings menu to adjust picture modes (e.g., Standard, Vivid, Movie, Game), brightness, contrast, and color. For audio, you can select different sound modes and adjust equalizer settings. The TV supports DTS Studio Sound and Dolby Digital Plus for an enhanced audio experience.

Game Mode

Activate Game Mode for optimized input lag and picture settings when playing video games, providing a smoother gaming experience.

MAINTENANCE

Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.

Cleaning the TV Body

Use a soft, dry cloth to wipe the TV's frame and back panel. Avoid using abrasive cleaners or solvents.

Software Updates

Periodically check for software updates in the TV's settings menu to ensure optimal performance and access to the latest features and security patches.

TROUBLESHOOTING

If you encounter any issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power cable is securely plugged into both the TV and the wall outlet. Check if the outlet is working.
No picture, but sound is present	Check the input source. Ensure external devices are powered on and connected correctly.
No sound, but picture is present	Check the volume level and mute settings. Verify audio output settings if using external speakers.
Remote control not working	Replace the batteries (requires 2). Ensure there are no obstructions between the remote and the TV. Re-pair the Bluetooth remote if necessary.
Wi-Fi connection issues	Restart your router and modem. Check TV network settings. Ensure the TV is within range of your Wi-Fi signal.
Voice control not responding	Ensure the microphone on the remote or TV is not blocked. Check internet connection. Re-pair the remote.

TECHNICAL SPECIFICATIONS

Detailed specifications for the Skyworth 65SUE9350F TV:




Image: Dimensional diagram of the Skyworth 65SUE9350F TV, including measurements for width, height, depth, and screen diagonal.

Feature	Detail
Brand	Skyworth
Model Name	65SUE9350F

Feature	Detail
Screen Size	65 inches
Display Technology	LED
Resolution	4K UHD (3840 x 2160)
Refresh Rate	60 Hz
HDR Format Support	HDR10, Dolby Vision HDR
Maximum Screen Brightness	250 Nit
Image Contrast Ratio	High
Viewing Angle	178 Degrees
Response Time	8 ms
Picture Quality Enhancement	Chameleon Extreme 2.0 Processor, QLED Technology, Dolby Vision HDR
Motion Enhancement Technology	Chameleon Extreme 2.0 Processor
Operating System	Google TV
Memory Storage Capacity	16 GB
RAM	2 GB
Connectivity Technology	HDMI, USB, Ethernet, Bluetooth, Wi-Fi
Hardware Interface	HDMI, USB, Ethernet, Bluetooth
Total HDMI Ports	3
Total USB Ports	2 (USB 2.0)
Bluetooth Version	5.1
Wireless Communication Technology	Wi-Fi
Screen Mirroring Technology	Chromecast
Supported Internet Services	Disney Plus, Netflix, Prime Video, YouTube
Audio Output Mode	Surround
Speaker Description	DTS Virtual X, Dolby Digital Plus
Maximum Speaker Output Power	16 Watts
Surround Sound Channel Configuration	7.1
Built-in Surround Sound Format	Dolby Digital Plus
Control Method	Voice, Remote, App

Feature	Detail
Remote Control Technology	Bluetooth
Special Features	Wide Screen, Chromecast, Hands-free Voice Control, Multiple Picture Modes, Game Mode
Product Dimensions (D x W x H)	9.8 cm x 144.5 cm x 83.8 cm
Item Weight	8 kg
Weight without Stand	16.1 kg
VESA Mounting Standard	600 x 400 mm
Color	Black
Power Input	100-240V AC, 50-60Hz
Recommended Uses	Indoor Home Entertainment
Year of Manufacture	2024
Model Year	2023

WARRANTY AND SUPPORT

This Skyworth 65SUE9350F TV comes with a manufacturer's warranty for two years. For warranty claims, technical support, or service inquiries, please contact Skyworth customer service or refer to the official Skyworth website for detailed support information.

Please retain your proof of purchase for warranty validation.