

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Mens Automatic Watch XBC-OS-G6670PZ-ML User Manual

OLEVS XBC-OS-G6670PZ-ML

OLEVS Mens Automatic Watch User Manual

Model: XBC-OS-G6670PZ-ML

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your OLEVS Mens Automatic Self-Winding Starry Sky Diamond Skeleton Luxury Wrist Watch, Model XBC-OS-G6670PZ-ML. Please read this guide thoroughly to ensure optimal performance and longevity of your timepiece.



Image: OLEVS Automatic Watch with Brown Strap and Blue Dial. This image displays the watch's overall design, including the skeleton dial, Roman numerals, and leather strap.

PRODUCT OVERVIEW

The OLEVS Automatic Watch features a sophisticated design with a self-winding mechanical movement. Key features include:

- **Skeleton Tourbillon Design:** An open-heart dial showcasing the intricate mechanical movement.
- **Self-Winding Movement:** Powered by wrist movement, eliminating the need for batteries.
- **Genuine Leather Strap:** Crafted for comfort and durability.
- **Luminous Display:** Hands and markers glow in low-light conditions.
- **30-Meter Water Resistance:** Suitable for daily use, splashes, and brief immersion.
- **High Hardness Glass:** Durable and scratch-resistant watch face.




Image: This four-panel image highlights key features: the watch's 30-meter water resistance, the high hardness glass coated mirror, the visible original mechanical movement, and the luminous display for night visibility.



Image: A detailed view of the watch's components, including the automatic movement, mineral glass lens, luminous elements, and the genuine leather strap.

SETUP

Initial Winding

As an automatic watch, this timepiece is powered by the motion of your wrist. For the first use, or if the watch has stopped due to lack of movement, manual winding is required:

1. Ensure the crown is in its normal, pushed-in position.
2. Turn the crown clockwise approximately 30 times. This will build up sufficient power reserve to start the watch.
3. Once started, regular wear will keep the watch wound. If worn daily for 8-10 hours, manual winding should not be necessary.

Wearing the Watch



Image: The OLEVS Automatic Watch comfortably worn on a wrist, demonstrating its fit and aesthetic.

Adjust the genuine leather strap to fit comfortably on your wrist. The watch should be snug enough to prevent excessive movement but not so tight as to restrict circulation.

OPERATING INSTRUCTIONS

Setting the Time

1. Gently pull the crown out to the first or second position (depending on the model, typically the outermost position for time setting).
2. Turn the crown to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to secure it and restart the watch movement.

Understanding the Dial Features

Your OLEVS watch features several indicators:

- **Main Hands:** Indicate hours and minutes.
- **Skeleton Dial:** The open design allows you to view the internal mechanical components.

- **12-Hour Subdial:** A smaller dial typically indicating a secondary time zone or a 12-hour format.
- **24-Hour Sun/Moon Indicator:** Displays whether it is day (sun) or night (moon) in a 24-hour format. This indicator moves in sync with the main hour hand.



Image: This image provides a close-up of the watch dial, illustrating the intricate skeleton design, the 12-hour subdial, and the 24-hour sun and moon phase indicator.

Luminous Display

The watch hands and certain markers are treated with a luminous material. After exposure to light, they will glow in dark conditions, providing visibility without external illumination.

MAINTENANCE

Water Resistance

Your OLEVS watch is rated for 30 meters (3ATM) of water resistance. This means it is suitable for:

- Daily use
- Splashes
- Rain
- Brief immersion in water

It is NOT suitable for showering, swimming, diving, or any water sports. Avoid operating the crown or pushers when the watch is wet to prevent water ingress.



Image: This banner visually explains the 30M waterproof rating, showing the watch being exposed to splashes during

Cleaning

To maintain the appearance of your watch:

- Wipe the watch case and glass with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a damp cloth and allow to air dry naturally.

Strap Care

The genuine leather strap is designed for comfort and durability. To extend its life, avoid bending it excessively or exposing it to extreme temperatures. If the strap becomes wet, dry it gently with a soft cloth and allow it to air dry completely before wearing.

TROUBLESHOOTING

Watch Not Running or Stopping

As an automatic watch, it requires kinetic energy to operate. If your watch stops or does not run:

- **Manual Winding:** Perform the initial winding procedure by turning the crown clockwise approximately 30 times.
- **Insufficient Movement:** Ensure you are wearing the watch regularly. If your daily activity is low, the watch may not receive enough kinetic energy to maintain its power reserve. Consider manually winding it daily if you have a sedentary lifestyle.
- **Power Reserve:** A fully wound automatic watch typically has a power reserve of 36-40 hours. If left unworn for longer than its power reserve, it will stop.

Time Inaccuracy

Minor variations in timekeeping are normal for mechanical watches. If you notice significant inaccuracy:

- Ensure the watch is fully wound.
- Avoid exposing the watch to strong magnetic fields, which can affect the movement's accuracy.

SPECIFICATIONS

Feature	Detail
Model Number	XBC-OS-G6670PZ-ML
Movement Type	Automatic Self-Winding Mechanical
Water Resistance	30 Meters (3ATM)
Strap Material	Genuine Leather
Case Material	Stainless Steel (implied by images)
Dial Features	Skeleton, 12-Hour Subdial, 24-Hour Sun/Moon Indicator, Luminous Hands
Manufacturer	OLEVS
ASIN	B0BW8717LW

WARRANTY AND SUPPORT

Warranty Information

Your OLEVS Automatic Watch comes with a **24-month assurance** from the date of purchase, covering manufacturing defects. Additionally, a **30-day no-reason refund** policy is offered.

This warranty does not cover:

- Damage resulting from improper handling or misuse.
- Normal wear and tear of the strap or case.
- Damage caused by unauthorized repairs or modifications.
- Water damage if the watch was exposed to conditions beyond its 30M water resistance rating.

Customer Support

If you encounter any issues with your watch or have questions regarding its operation or maintenance, please contact us through the Amazon platform. Our professional after-sales team is available to provide assistance.