

[Manuals.plus](#) /

› [Coleshome](#) /

› Coleshome 56-inch L-Shaped Gaming Desk with LED Lights and Power Outlets Instruction Manual

Coleshome B0BW8GK932

Coleshome 56-inch L-Shaped Gaming Desk Instruction Manual

Model: B0BW8GK932

INTRODUCTION

Thank you for choosing the Coleshome 56-inch L-Shaped Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

Always assemble the desk according to the provided instructions. Be cautious when lifting and moving the desk due to its weight. Keep the desk away from heat sources and do not place heavy objects on the desk that could cause it to tip over.

PACKAGE CONTENTS

Before assembly, verify that all components listed in the packing list are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk Boards (L-shaped sections, monitor stand, shelves)
- Steel Frame Components (legs, support bars)
- LED Light Strip with Controller
- Power Outlet Unit with USB Ports and Power Cord
- Adjustable Leg Pads
- Assembly Hardware (screws, bolts, nuts)
- Assembly Tools (Allen wrenches)
- Instruction Manual



Image: Detailed product dimensions for the L-shaped gaming desk, showing measurements for each section and shelf.

ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward with the included detailed instructions and tools. It is recommended to assemble the desk in the room where it will be used.


1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the parts list to ensure all pieces are present.
2. **Assemble the Frame:** Attach the steel frame components according to the diagrams in the separate assembly guide. Ensure all screws are tightened securely but do not overtighten until the desk is fully assembled.
3. **Attach Desk Boards:** Secure the L-shaped desk boards to the assembled frame. Pay attention to the orientation for left or right corner configuration, as the desk is reversible.
4. **Install Monitor Stand:** Place and secure the full monitor stand onto the main desk surface.
5. **Install Storage Shelves:** Attach the two-tier storage shelves to the designated areas on both sides of the desk.
6. **Mount Power Outlet Unit:** Secure the power outlet and USB charging unit to the designated recessed area on the desk.
7. **Apply LED Light Strip:** Carefully attach the LED light strip to the underside of the monitor stand or other desired locations. Ensure the surface is clean and dry for optimal adhesion.
8. **Adjust Leg Pads:** Once the desk is fully assembled and in its final position, adjust the leg pads to ensure

stability on uneven floors.

The assembly process typically takes about 1.5 hours for one person. All necessary tools, including Allen wrenches, are provided.

Ours:

Excellent Durability & Light Diffusion




Others:

Soft Light Strip

Short life span and vulnerable



Image: The full monitor stand integrated into the desk design, illustrating how it promotes an ergonomic viewing height for comfortable posture.



Full Monitor Stand

Ergonomic Design for Comfortable Viewing Height

Image: The double-sided storage shelves of the L-shaped gaming desk, designed to accommodate dual computer hosts and other accessories.

OPERATING INSTRUCTIONS

LED Lighting Effects

The integrated LED lighting system offers customizable illumination for your desk environment.

- **Colors:** Choose from 7 distinct colors.
- **Lighting Modes:** Select from 13 different lighting modes to suit your preference.
- **Brightness:** Adjust the intensity with 8 adjustable brightness levels.
- **Flicker Frequencies:** Customize the flicker rate with 9 available frequencies.
- **Memory Function:** The LED light system retains the last selected mode when powered off and on.

Use the inline controller to cycle through colors, modes, brightness, and flicker frequencies.

Power Outlets & USB Charging Ports

The desk is equipped with a convenient power strip for your electronic devices.

- **AC Outlets:** 3 standard 125V/12A AC outlets for powering computers, monitors, and other equipment.
- **USB Ports:** 2 USB 5V/2A ports for charging smartphones, tablets, gaming controllers, and other USB-powered devices.

- **Power Cord:** The unit includes a 6.5-foot power cord for connection to a wall outlet.

Ensure the power cord is securely plugged into a functional wall outlet before use. Do not overload the outlets beyond their specified capacity.



Image: Close-up view of the recessed power outlet unit, showing three AC outlets and two USB ports, with a phone charging.



Image: An illustration highlighting the durable design of the LED light strip, featuring a light diffusive lampshade, longevity LED beads, enhanced copper circuit board, and a rigid LED strip base.

MAINTENANCE

To ensure the longevity and appearance of your Coleshome gaming desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood surface.
- **LED Strip:** If the LED strip adhesive weakens over time, re-secure it with appropriate adhesive tape suitable for electronics.
- **Connections:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

LED Lights Not Functioning:

Ensure the LED light strip is properly connected to its power source and the power outlet unit is receiving power. Check the controller for proper function. If the adhesive has failed, re-secure the strip.

Power Outlets/USB Ports Not Working:

Verify that the desk's main power cord is securely plugged into a live wall outlet. Check if the wall outlet itself is functional by plugging in another device. Ensure the power unit is correctly installed on the desk.

Desk Instability/Wobbling:

Check that all assembly screws and bolts are fully tightened. Adjust the leg pads at the bottom of each leg to compensate for uneven floor surfaces.

Surface Stains/Marks:

The carbon fiber surface can be sensitive to skin oils. Clean regularly with a dry cloth. For persistent marks, a slightly damp cloth followed by immediate drying may be used, but test in an inconspicuous area first.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	B0BW8GK932
Shape	L-Shape
Product Dimensions (D x W x H)	18.9"D x 55.9"W x 35"H
Color	Black Carbon Fiber
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Finish Type	Steel
Special Features	LED Lights, Power Outlets, USB Ports, Full Monitor Stand, Double Shelves, Reversible Design, Adjustable Leg Pads
Item Weight	30.53 Kilograms
Number Of Shelves	4
Maximum Weight Recommendation	100 Pounds
Required Assembly	Yes
Recommended People for Assembly	1
Includes All Assembly Tools	Yes
Product Care Instructions	Wipe with Dry Cloth

WARRANTY INFORMATION

Coleshome products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact Coleshome customer support directly. Keep your proof of

purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues during assembly or operation, or if you have questions about your Coleshome L-Shaped Gaming Desk, please do not hesitate to contact our customer support team. Refer to the contact information provided in your product packaging or visit the official Coleshome website for assistance.

© 2024 Coleshome. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW8GK932>

More documents and user manuals: <https://manuals.plus/>