

Edifier W820NB Plus

Edifier W820NB Plus Over-Ear Active Noise Cancelling Headphones Instruction Manual

Model: W820NB Plus | Brand: Edifier

1. INTRODUCTION

The Edifier W820NB Plus headphones offer an immersive audio experience with advanced features designed for comfort and superior sound quality. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

2. WHAT'S IN THE BOX

- Edifier W820NB Plus Headphones
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

The Edifier W820NB Plus headphones feature a lightweight design with comfortable memory foam earcups and a cushioned headband for extended wear. The controls are intuitively placed on the earcup for easy access.

Lightweight Design Texture and Comfort Guaranteed



Image 3.1: Man wearing the Edifier W820NB Plus headphones, demonstrating the comfortable and lightweight fit.

Controls and Ports

- **Power/Multi-function Button:** Used for powering on/off, play/pause, answering/ending calls, and activating voice assistant.

- **Volume Up/Next Track Button:** Increases volume, skips to the next track.
- **Volume Down/Previous Track Button:** Decreases volume, skips to the previous track.
- **Mode Button:** Toggles between Active Noise Cancellation (ANC), Ambient Sound, and Wind Reduction modes. Double-tap to activate low latency gaming mode.
- **USB-C Port:** For charging and wired audio connection.
- **Microphone:** Integrated for clear calls.

App Customization

Create Your Own Music World



Edifier Connect



Image 3.2: Detailed view of the headphone controls and USB-C port on the earcup.

4. SETUP

Initial Charging

Before first use, fully charge your headphones using the provided USB-C cable. A 10-minute charge provides

approximately 7 hours of playback. A full charge can last up to 49 hours with ANC off, or 33 hours with ANC on.

49 Hours Long Battery Life No More Worry about Power Running Out

10
Minutes Charge for
7
Hours of Use



Approx. 49h
Noise Cancellation Off

Approx. 33h
Noise Cancellation On

Image 4.1: Battery life and fast charging capabilities of the Edifier W820NB Plus headphones.

Bluetooth Pairing

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power/Multi-function button until the indicator light blinks rapidly (usually blue/red), indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for