

Manuals.plus /

› IKEA /

› IKEA Pax Corner Wardrobe Instruction Manual, 160/188 x 236 cm, White/Flisberget Light Beige

IKEA Pax

IKEA Pax Corner Wardrobe Instruction Manual

Model: Pax | Dimensions: 160/188 x 236 x 60 cm | Color: White/Flisberget Light Beige

1. PRODUCT OVERVIEW

The IKEA Pax Corner Wardrobe system offers a versatile storage solution designed to maximize space in your room. This specific model features a white frame with Flisberget light beige doors, providing a modern and adaptable aesthetic. It includes adjustable shelves and a drawer for organized storage of clothing and accessories.

Important Safety Information:

- This wardrobe must be carefully assembled according to the provided instructions.
- Exercise caution when handling glass doors (if applicable to your specific configuration).
- Pay attention to the overall weight of the wardrobe and ensure the load is distributed evenly to maintain stability.
- Always secure the wardrobe to the wall using the included anti-tip devices to prevent tipping injuries.



Image 1: The IKEA Pax Corner Wardrobe integrated into a bedroom environment, showcasing its design and scale.

2. SETUP AND ASSEMBLY

Assembly of the IKEA Pax Corner Wardrobe is required. It is recommended to have at least two people for assembly due to the size and weight of the components. Ensure you have adequate space and the necessary tools before beginning. Follow the detailed graphical instructions provided with your product packaging for step-by-step guidance.

- Unpack all components and verify against the parts list.
- Assemble the frame structure on a clean, flat surface.
- Install shelves, drawers, and hanging rails as desired.
- Attach doors carefully, ensuring proper alignment.
- Secure the wardrobe to the wall using the provided wall-fastening devices to prevent tipping.



Image 2: Exterior view of the IKEA Pax Corner Wardrobe with its Flisberget light beige doors closed, illustrating its corner configuration.

3. OPERATING AND USAGE

The Pax Corner Wardrobe is designed for storing clothes and various personal items. Its adjustable shelves allow for flexible organization to suit your needs. The included drawer provides concealed storage for smaller items.

- **Adjustable Shelves:** Shelves can be repositioned to different heights to accommodate items of varying sizes. Refer to the assembly instructions for how to safely adjust shelf placement.

- **Drawer Usage:** The integrated drawer operates on smooth runners. Avoid overloading the drawer to ensure smooth operation and longevity.
- **Weight Distribution:** Distribute the weight of stored items evenly across shelves and hanging rails to maintain the wardrobe's stability and prevent warping.



Image 3: Interior view of the IKEA Pax Corner Wardrobe, showing various storage options including shelves, drawers, and hanging space for clothes and accessories.

4. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your Pax Corner Wardrobe.

- **Cleaning:** Wipe the surfaces with a dry cloth. For stubborn marks, a damp cloth with a mild cleaner can be used, followed by immediate drying with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Door Hinges:** Periodically check door hinges and drawer runners for smooth operation. Tighten any loose screws if necessary.
- **Environmental Conditions:** Avoid placing the wardrobe in direct sunlight or near heat sources, as this can cause discoloration or material damage over time.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your wardrobe.

- **Wobbly Wardrobe:** Ensure all assembly screws are tightened. Verify that the wardrobe is placed on a

level surface. If necessary, use shims under the legs to stabilize. Confirm that the wall-fastening devices are securely installed.

- **Doors Not Closing Properly:** Check hinge alignment. Adjust hinges as per the assembly manual to ensure doors close flush and evenly. Ensure no items are obstructing the door's path.
- **Drawer Sticking:** Check for obstructions in the drawer runners. Ensure the drawer is not overloaded. Verify that the drawer runners are correctly installed and screws are tight.

6. SPECIFICATIONS

Brand	IKEA
Model Name	Pax
Model Number	ec1bed51-9882-467c-9edc-4c734926b828
Part Number	IK.492.190.02
ASIN	B0BW8RFHSC
Color	White, Flisberget Light Beige
Material	Engineered Wood (Frame, Top, Back)
Dimensions (W x H x D)	160/188 x 236 x 60 cm
Special Feature	Adjustable shelves
Mounting Type	Floor Mount
Installation Type	Freestanding
Assembly Required	Yes
Number of Doors	2
Number of Shelves	6
Number of Drawers	1
Storage Options	Door, drawer, shelf

7. WARRANTY INFORMATION

IKEA products typically come with a limited warranty. For specific details regarding the warranty period and terms for your Pax Corner Wardrobe, please refer to the warranty documentation included with your purchase or visit the official IKEA website. Keep your proof of purchase for warranty claims.

8. SUPPORT

Should you require further assistance with assembly, parts, or general inquiries, please contact IKEA Customer Service. You can find contact information on the official IKEA website or in the documentation provided with your product.

- **Online Support:** Visit www.ikea.com for FAQs, assembly guides, and contact options.

- **In-Store Support:** Visit your local IKEA store for assistance.