



Manuals.plus /

› WANAI /

› WANAI 3.5 Cu.Ft Compact Chest Freezer User Manual (Model B63white)

## WANAI B63white

# WANAI 3.5 Cu.Ft Compact Chest Freezer User Manual

Model: B63white

## 1. INTRODUCTION

---

Thank you for choosing the WANAI 3.5 Cu.Ft Compact Chest Freezer. This manual provides essential information for the safe and efficient operation of your appliance. Please read it thoroughly before use and retain it for future reference.

## 2. IMPORTANT SAFETY INFORMATION

---

To reduce the risk of fire, electric shock, or injury when using your freezer, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Ensure the freezer is placed upright for at least 24 hours before plugging it in.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.


## 3. PRODUCT OVERVIEW

---

The WANAI 3.5 Cu.Ft Compact Chest Freezer is designed for efficient food storage in various settings such as kitchens, offices, dorms, and apartments.

## 3.1 Components

Familiarize yourself with the main parts of your freezer:



*Image: Labeled diagram showing the recessed door handle, door gasket, auto-hold hinges, embossed aluminum liner, hanging plastic basket, powder-coated steel exterior, drain outlet, and temperature control panel.*

- **Recessed Door Handle:** For opening and closing the lid.
- **Door Gasket:** Ensures an airtight seal to maintain temperature.
- **Auto Hold Hinges:** Allows the lid to stay open at various angles (45°, 60°, 90°).
- **Embossed Aluminum Liner:** Interior surface for efficient cooling.
- **Hanging Plastic Basket:** Removable basket for organized storage of smaller items.
- **Powder Coated Steel Exterior:** Durable outer casing.
- **Drain Outlet:** Located at the bottom for easy defrosting.
- **Temperature Control Panel:** Dial for adjusting the internal temperature.

## 3.2 Dimensions and Capacity

# Hanaí

## CHEST FREEZER WITH SLIDING BASKET

3.5 Cu.Ft



0.56 kWh  
Energy-Saving

3.5 Cu.Ft  
R600a Motor

Image: Diagram showing the dimensions of the WANAI chest freezer: 20.7" (W) x 16.3" (D) x 29.5" (H). Also highlights 3.5 Cu.Ft capacity and 0.56 kWh energy saving.

- **Capacity:** 3.5 Cu.Ft
- **Product Dimensions:** Approximately 20.7" (W) x 16.3" (D) x 29.5" (H)
- **Item Weight:** 35 pounds

## 4. SETUP AND INSTALLATION

### 4.1 Unpacking

Carefully remove all packaging materials. Inspect the freezer for any shipping damage. If damage is found, do not plug in the unit and contact customer service.

### 4.2 Placement

- Place the freezer on a flat, stable surface.

- Ensure adequate ventilation around the unit. Allow at least 4 inches of space from walls or other appliances.
- Avoid direct sunlight or heat sources.
- This appliance is designed for freestanding installation.

### **4.3 Initial Preparation**

After placing the freezer, it is crucial to allow it to stand upright for at least 24 hours before plugging it into a power outlet. This allows the refrigerant to settle, preventing potential damage to the cooling system.

### **4.4 Power Connection**

- Ensure the power outlet is properly grounded and matches the freezer's voltage requirements (110 Volts).
- Do not use extension cords or ungrounded adapters.

## **5. OPERATING INSTRUCTIONS**

---

### **5.1 Temperature Control**

The freezer features an adjustable thermostat located on the exterior. It has 7 temperature settings, allowing you to customize the cooling level.



Image: Close-up of the temperature control dial with settings 1 through 7. Surrounding images suggest optimal settings for various items: vegetables/fruit, soda/beer/wine, tea (refrigeration), ice cream, deep sea fish, shrimp/salmon, pork/beef (freezing).

- **Settings 1-2:** Refrigerator temperature range (approximately 32°F to 50°F). Suitable for fruits, vegetables, drinks, and wine.
- **Settings 3-7:** Freezer temperature range (approximately -11.2°F to 32°F). Suitable for meat, ice cream, seafood, and popsicles.
- Turn the dial to your desired setting. A higher number indicates a colder temperature.

## 5.2 Initial Operation

After the 24-hour settling period, plug in the freezer. Set the temperature control to a medium setting (e.g., 4 or 5) and allow the unit to cool for several hours before loading food. This ensures the freezer reaches the optimal temperature.

## 5.3 Organizing Contents

# Make good organization of your freezer



Image: Top-down view of the freezer interior showing various frozen food items neatly organized, with a removable basket on the right holding smaller items like ice cream and canned drinks.

Utilize the removable storage basket for smaller, frequently accessed items to maintain organization and easy access to contents.

## 6. MAINTENANCE

### 6.1 Cleaning

- Always unplug the freezer before cleaning.
- Clean the interior with a mild detergent and warm water. Avoid abrasive cleaners or harsh chemicals.
- Wipe down the exterior with a damp cloth.
- Ensure the door gasket is clean and free of debris to maintain a proper seal.

### 6.2 Defrosting

Over time, frost will accumulate inside the freezer. Defrost when the frost layer is about 1/4 to 1/2 inch thick.

1. Unplug the freezer from the power outlet.
2. Remove all food items and store them in another freezer or cooler.
3. Open the lid and place towels around the base of the freezer to absorb water.
4. Locate the drain outlet at the bottom of the freezer. Remove the drain dial/plug to allow water to escape.
5. Allow the frost to melt naturally. You can place bowls of warm water inside to speed up the process, but do not use sharp objects to scrape ice.
6. Once defrosted, clean and dry the interior thoroughly.
7. Replace the drain dial/plug, plug in the freezer, and allow it to cool before returning food.

## 7. TROUBLESHOOTING

Before contacting customer service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Freezer does not operate.	No power to the unit.	Check if the power cord is securely plugged in. Verify the outlet has power.
Freezer is not cold enough.	Temperature setting is too high (not cold enough). Excessive door opening. Poor ventilation.	Adjust the temperature control to a colder setting. Minimize door openings. Ensure adequate space around the freezer.
Excessive frost buildup.	Door not sealed properly. Frequent door openings. High humidity environment.	Check and clean the door gasket. Reduce frequency of door openings. Defrost the unit as needed.
Unusual noises.	Unit not level. Objects vibrating against the unit.	Ensure the freezer is on a level surface. Move any objects that may be touching the freezer. Normal operating sounds (e.g., refrigerant flow) are expected.

## 8. SPECIFICATIONS

Feature	Detail
Brand	WANAI
Model Number	B63white
Capacity	3.5 Cu.Ft
Product Dimensions (W x D x H)	20.7" x 16.3" x 29.5"
Item Weight	35 pounds
Installation Type	Freestanding
Color	White
Voltage	110 Volts
Wattage	70 watts
Door Hinges	Top
Door Material Type	PCM, Cyclopentane
Shelves	1 (Removable Basket)
Included Components	Side Handle, Switch

*Note on dimensions: The product description and visual aids indicate dimensions of 20.7"W x 16.3"D x 29.5"H. Some specifications may list different values (e.g., 30.3"D x 28.5"W x 18.8"H). Please refer to the physical product for exact measurements.*

## 9. WARRANTY AND CUSTOMER SUPPORT

WANAI is committed to providing high-quality products and customer satisfaction. For any questions, concerns, or assistance with your product, please contact WANAI customer service.

- Refer to your purchase documentation for specific warranty details.
- For support, please contact the seller or visit the official WANAI website.
- When contacting support, please have your model number (B63white) and purchase date available.

